

**SPEED LIMITATIONS**

On the left side instrument panel, above on the left, it is placed the following placard reporting the speed limitations:

**Maximum L.G. op. speed**

**$V_{LO} / V_{LE} = 122 \text{ KIAS}$**

INTENTIONALLY LEFT BLANK

**SUPPLEMENT NO. G12 – SOUTH AFRICAN AFM**

(SACAA APPROVED)

**Record of Revisions**

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval Or Under DOA Privileges
			DO	OoA	HDO	
<b>0</b>	All	Editorial Change	A. Sabino	C. Caruso	M. Oliva	See Note (*)

Note (\*): this Supplement has been originally issued on 2 May 2013, after EASA Third Country Validation process completion.

**LOEP**

Page	Revision	Page	Revision
<b>G11-1</b>	Rev 0	<b>G11-5</b>	Rev 0
<b>G11-2</b>	Rev 0	<b>G11-6</b>	Rev 0
<b>G11-3</b>	Rev 0	<b>G11-7</b>	Rev 0
<b>G11-4</b>	Rev 0	<b>G11-8</b>	Rev 0

**TABLE OF CONTENTS**

<b>INTRODUCTION .....</b>	<b>4</b>
<b>LIMITATIONS .....</b>	<b>5</b>
<b>Maximum operating altitude.....</b>	<b>5</b>
<b>Inflight engine restart.....</b>	<b>5</b>
<b>GPS systems .....</b>	<b>6</b>
<b>GPS GNS 430 or GNS 530 operation (for airplanes with autopilot installed) .....</b>	<b>6</b>
<b>GPS GNS 430 or GNS 530 operation (for airplanes without autopilot installed).....</b>	<b>6</b>
<b>WAAS and SBAS functionalities: .....</b>	<b>7</b>

## **INTRODUCTION**

This Supplement applies for South African registered aircraft

It contains supplemental information to the basic information approved in EASA aircraft Flight Manual when the aircraft is registered in South Africa.

For Limitations, procedures, and performance information not contained in this supplement, refer to the basic Aircraft Flight Manual.

The information contained herein supplements or supersedes the basic Aircraft Flight Manual or the Supplement G1, as applicable.

## **LIMITATIONS**

### **MAXIMUM OPERATING ALTITUDE**

Maximum operating altitude is 14000 ft (4260 m) MSL.




**CAUTION**

*At altitudes between 10 000 feet (3048 m) and 12 000 feet (3658 m) for longer than 120 minutes intended flight time, or above 12 000 feet, the aircraft shall not be operated unless the aircrew is provided with the supplemental oxygen as prescribed in Document SA-CATS 91 and such oxygen may be used continuously whenever these circumstances prevail."*

### **INFLIGHT ENGINE RESTART**

The inflight engine restart procedure is reported on a placard (shown below) installed on the central console.



---

**GPS SYSTEMS****GPS GNS 430 or GNS 530 OPERATION (FOR AIRPLANES WITH AUTOPILOT INSTALLED)**

- Use of GPS for precision approach navigation mode is not allowed.
- Use of GPS is prohibited as primary means for navigation. GPS is approved as supplemental means for navigation;
- Navigation using of the GPS system as the source of information is limited to IFR en route, terminal area and non-precision approach mode;
- During IFR in terminal area or non-precision approach using GPS, autopilot or flight director must be coupled to GPS.
- If RAIM function becomes unavailable in “en route” phase of flight, position must be verified every 15 minutes using other IFR approved navigation system;
- During IFR in terminal area or non-precision approach using GPS, in case RAIM function becomes unavailable, the GPS navigation must be discontinued;
- Before an IFR non-precision approach using GPS, the availability of the RAIM function must be checked to the time and place predicted (RAIM prediction). If predicted the unavailability of the RAIM function, navigation must be planned with others approved navigation systems;
- Before a non-precision approach using GPS, the database information must be compared with that in the approach chart, including transitions, position and altitude of waypoints;
- IFR non-precision approach using GPS must be based on the approved procedures of the equipment database. It cannot be done based on data manually included.

**GPS GNS 430 or GNS 530 OPERATION (FOR AIRPLANES WITHOUT AUTOPILOT INSTALLED)**

- Use of GPS for precision approach navigation mode is not allowed.
- Use of GPS is prohibited as primary means for navigation. GPS is approved as supplemental means for navigation;
- Use of GPS is prohibited for IFR in terminal area or in non-precision approach operations;
- If RAIM function becomes unavailable in en route phase of flight, position must be verified every 15 minutes using other IFR approved navigation system.



## **WAAS AND SBAS FUNCTIONALITIES**

The WAAS and SBAS functionalities are not available in South Africa and these functions are not tested or approved in South African air space.

INTENTIONALLY LEFT BLANK

## SUPPLEMENT NO. G13 – ALTERNATORS WITH 70 A INSTALLATION

### Record of Revisions

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval Or Under DOA Privileges
			DO	OoA	HDO	
0	all	Editorial change	A. Sabino	C. Caruso	M. Oliva	DOA Privileges.

### List of Effective Pages

Page	Revision
G13-1	Rev 0
G13-2	Rev 0
G13-3	Rev 0
G13-4	Rev 0
G13-5	Rev 0
G13-6	Rev 0

## Section 9 - Supplements

### Supplement no. G13 – Alternators with 70A installation

## **INTRODUCTION**

This section contains supplemental information to operate, in a safe and efficient manner, the aircraft when 70A alternators are installed replacing the standard, 40A ones (Design Change MOD 2006/202).

The information contained herein supplements or supersedes the basic Aircraft Flight Manual: detailed instructions are provided to allow the owner for replacing the AFM pages containing information amended as per the Design Change in subject.

**It is the owner's responsibility to replace the mentioned pages in the AFM in accordance with the instructions herein addressed section by section.**

## **GENERAL**

When 70A alternators are installed replacing the standard, 40A ones, the electrical system logic is not affected by any substantial change. Primary DC power is provided by two engine-driven alternators which, during normal operations, operate in parallel.

Each alternator is rated at 14,2-14,8 Vdc (through two external voltage regulators), 70 Amp and is provided with an automatic overvoltage device protecting the circuits and the electric components from an excessive voltage caused by alternator's failures.

The power rating of the each generator is such that if one generator fails the other one can still supply the airplane equipment to maintain flight safety.

## **SECTION 3 - EMERGENCY PROCEDURES**

This section report some procedures which replace the same procedure in the basic AFM. The procedures affected from the replacement of existing 40A alternators with 70A are the following:

- **Single alternator failure/overvoltage**
- **Both alternators failure**
- **Both alternators overvoltage**

**SINGLE ALTERNATOR FAILURE / OVERVOLTAGE**

Annunciation window	Alert window
<b>L ALT FAIL</b>	Lh Alternator

**OR**

<b>R ALT FAIL</b>	Rh Alternator
-------------------	---------------

1. FIELD LH (or RH) *OFF*
2. FIELD LH (or RH) *ON*

**If the LH (or RH) ALT caution stays displayed**

3. FIELD LH (or RH) *OFF*

**NOTE**

*The battery and a single generator are able to supply the electrical power necessary for flight, but redundancy is lost.*

Equipment will be lost accordingly to the following table:

LH Gen Bus	LH Avionic Bus	RH Avionic Bus	RH Gen Bus
Pitot Heat	DME	ADF	NAV Lights
Landing Light	Transponder	COM 2	Rudder Trim
Taxi Light	A/P	NAV 2	Stall Warning
	A/P Pitch Trim	MFD	
		AHRS/ADC	

4. *Land as soon as practicable*

## BOTH ALTERNATORS FAILURE

Annunciation window	Alert window
<b>L ALT FAIL</b>  <b>R ALT FAIL</b>	Lh Alternator
	Rh Alternator

In event of both L and R ALT FAIL caution alerts displayed:

1. FIELD LH and RH *BOTH OFF*
2. FIELD LH and RH *BOTH ON (one at a time)*

### If the LH (or RH) ALT caution stays displayed

1. Verify good ammeter indications on restored alternator
2. Refer to Single alternator failure / overvoltage drill (Para 2.1)

### If both LH and RH ALT cautions stay displayed

3. FIELD LH and RH *BOTH OFF*
4. CROSS BUS LH and RH *BOTH OFF*

### If engine starting battery modification is applied

5. EMERG BATT switch ON
6. Land as soon as possible.

### If engine starting battery modification is not applied

5. Land as soon as possible.

Equipment will be lost accordingly to the following table:

LH Gen Bus	LH Avionic Bus	RH Avionic Bus	RH Gen Bus
Pitot Heat	DME	ADF	NAV Lights
Landing Light	Transponder	COM 2	Rudder Trim
Taxi Light	A/P	NAV 2	Stall Warning
	A/P Pitch Trim	MFD	
		AHRS/ADC	

### NOTE

*The battery will supply electrical power for at least 30 minutes.*

### **BOTH ALTERNATORS OVERVOLTAGE**

<b>Annunciation window</b>	<b>Alert window</b>
<b>L BUS VOLT HIGH</b>	Lh overvoltage
<b>R BUS VOLT HIGH</b>	Rh overvoltage

In event of both L and R BUS VOLT HIGH warning alerts displayed:

1. FIELD LH and RH *BOTH OFF*
2. FIELD LH and RH *BOTH ON (one at a time)*

#### **If the LH (or RH) BUS VOLT HIGH caution stays displayed**

3. Verify good ammeter indications on restored alternator
4. Refer to Single alternator failure / overvoltage drill (Para 2.1)

#### **If both LH and RH BUS VOLT HIGH warning stay displayed**

3. CROSS BUS LH and RH *BOTH OFF*
4. FIELD LH and RH *BOTH OFF*
5. FIELD LH and RH *BOTH ON (one at a time)*

#### **If LH (or RH) BUS VOLT HIGH warning stays displayed**

6. Verify good ammeter indications on restored alternator
7. Switch CROSS BUS on the restored alternator side
8. Refer to Single alternator failure / overvoltage drill (Para 2.1)

#### **If both LH and RH BUS VOLT HIGH warning stay displayed**

7. FIELD LH and RH *BOTH OFF*

#### **If engine starting battery modification is applied**

7. EMERG BATT switch *ON*
8. Land as soon as possible.

#### **If engine starting battery modification is not applied**

8. Land as soon as possible.

Equipment will be lost accordingly to the following table:

<b>LH Gen Bus</b>	<b>LH Avionic Bus</b>	<b>RH Avionic Bus</b>	<b>RH Gen Bus</b>
Pitot Heat	DME	ADF	NAV Lights
Landing Light	Transponder	COM 2	Rudder Trim
Taxi Light	A/P	NAV 2	Stall Warning
	A/P Pitch Trim	MFD	
		AHRS/ADC	

#### **NOTE**

*The battery can supply electrical power for at least 30 minutes.*



## **SUPPLEMENT NO. G14 - SMP FOR DIGITAL CONFIGURATION**

### **RECORD OF REVISIONS**

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval Or Under DOA Privileges
			DO	OoA	HDO	
0	-	First issue	D. Ronca	C. Caruso	M. Oliva	DOA Approval
1	S4-26	Integration of information formerly contained in Supplement G18	A. Sabino	C. Caruso	M. Oliva	DOA Approval

## **LOEP**

	<b>Pages</b>	<b>Revision</b>
<b>Cover pages</b>	G14 – 3 thru 22	<i>Rev. 0</i>
	G14 – 1, 2	<i>Rev. 1</i>
<b>Section 2</b>	SMP2 – 3	<i>Rev. 0</i>
<b>Section 3</b>	SSMP3 – 3 thru 5	<i>Rev. 0</i>
	SSMP3 – 7 thru 9	<i>Rev. 0</i>
	SSMP3 – 21	<i>Rev. 0</i>
	SSMP3 – 29	<i>Rev. 0</i>
	SSMP3 – 36 thru 40	<i>Rev. 0</i>
	SSMP3 – 49 thru 53	<i>Rev. 0</i>
<b>Section 4</b>	SSMP4 – 27	<i>Rev. 0</i>
	SSMP4 – 26	<i>Rev. 1</i>
<b>Section 7</b>	SSMP7 – 41	<i>Rev. 0</i>
	SSMP7 – 44 thru 48	<i>Rev. 0</i>

## INTRODUCTION

This section contains supplemental information to operate, in a safe and efficient manner, the aircraft when equipped with Garmin G950 Integrated Flight Deck System (Design Change MOD 2006/002) and with Special Mission Platform. The Special Mission Platform refers to the following design changes:

- MOD2006/046 - Power supply from built-in generators
- MOD2006/202 - Replacement of existing 40A alternators with 70A
- MOD2006/204 - Installation of converter box

For the two first design changes the supplements (n° A15 and G13) are already approved by EASA and in this supplement we report the same information for reference.

The Rotax engine built-in generators, one for each engine, feed two bus bars made available for end user equipment, when the design change 2006/046 is installed.

When 70A alternators are installed replacing the standard, 40A ones, the electrical system logic is not affected by any substantial change. Primary DC power is provided by two engine-driven alternators which, during normal operations, operate in parallel.

Each alternator is rated at 14,2-14,8 Vdc (through two external, first fuselage frame installed voltage regulators), 70 Amp and is provided with an automatic overvoltage device protecting the circuits and the electric components from an excessive voltage caused by alternator's failures.

The power rating of the each generator is such that if one generator fails the other one can still supply the airplane equipment to maintain flight safety.

The information contained herein supplements or supersedes the basic Aircraft Flight Manual or the Supplement G1, as applicable: detailed instructions are provided to allow the owner for replacing the Basic AFM/Supplement G1 pages containing information amended as per the Design Changes in subject.

### NOTE

*Usually, the Special Mission Platform P2006T is also equipped with holes in the cabin and/or tailcone, ready for third parties sensor's integration. While the Tecnam intent is to offer a platform ready for sensors' integration, it is end-user responsibility to receive the approval from authority for each equipment installation.*

**It is the owner's/operator's responsibility to replace the mentioned pages in the AFM in accordance with the instructions herein addressed section by section.**

INTENTIONALLY LEFT BLANK

**Supplement G14: pages replacement instructions**

## **SECTION 1 – GENERAL**

Apply following instruction:

**See Basic AFM - Section 1**

INTENTIONALLY LEFT BLANK

**Supplement G14: pages replacement instructions**

## **SECTION 2 – LIMITATIONS**

Apply following pages replacement procedure:

<b>Supplement G14 - LIMITATIONS page</b>		<b>Basic AFM Section 2 page</b>
SMP2 – 3	<b>REPLACES</b>	Page 2 – 3 of Basic AFM, Section 2

INTENTIONALLY LEFT BLANK



## 1. INTRODUCTION

Section 2 includes operating limitations, instrument markings and basic placards necessary for safe operation of **P2006T** aircraft, its engines and standard systems and equipment.

LH and RH AUX FIELDS, enabling the converter box operations for Special Mission purposes, should be kept OFF during take-off, climb, landing and any abnormal procedure that affects electrical generating system (including single engine operation):

**During Take-off, Climb, Landing and Single Engine Operations:**

**LH and RH AUX FIELD switches**

***BOTH OFF***

**NOTE**

*This limitation only applies when both 70Amp alternators and converter box are installed.*

**NOTE**

*Safety provisions, as following described, automatically disengage the LH and RH AUX FIELDS in case of one main field malfunction (i.e. for OEI). Also, if only one AUX FIELD switch is ON, the converter box is not powered.*

INTENTIONALLY LEFT BLANK

## **Section 9 - Supplements**

**Supplement no. G14 – SMP FOR DIGITAL CONFIGURATION**

**Supplement G14: pages replacement instructions**

### **SECTION 3 – EMERGENCY PROCEDURES**

Apply following pages replacement procedure:

<b>Supplement G14 - EMERGENCY PROCEDURES page</b>		<b>Supplement G1 Section 3 page</b>
SSMP3 – 3 thru 5	<b>REPLACE</b>	Page S3 – 3 thru 5 of Supplement G1, Section 3
SSMP3 – 7 thru 9	<b>REPLACE</b>	Page S3 – 8 thru 11 of Supplement G1, Section 3
SSMP3 – 21	<b>REPLACES</b>	Page S3 – 21 of Supplement G1, Section 3
SSMP3 – 29	<b>REPLACES</b>	Page S3 – 29 of Supplement G1, Section 3
SSMP3 – 36 thru 40	<b>REPLACE</b>	Page S3 – 36 thru 40 of Supplement G1, Section 3
SSMP3 – 49 thru 53	<b>REPLACE</b>	Page S3 – 49 thru 53 of Supplement G1, Section 3

INTENTIONALLY LEFT BLANK

## **1. INTRODUCTION**

Section 3 includes checklists and detailed procedures for coping with various types of emergency conditions that could arise after a system failure.

The procedures affected from installation of the Special Mission Platform are the following:

- **Single alternator failure / overvoltage**
- **Both alternators failure**
- **Both alternators overvoltage**
- **Engine securing**
- **Total electrical failure**
- **Inflight engine restart**
- **Engine failure during takeoff run**
- **Engine failure during climb**
- **Engine failure in flight**
- **Engine fire on the ground**
- **Engine fire during takeoff run**
- **Engine fire in flight**
- **Electrical smoke in cabin on the ground**
- **Electrical smoke in cabin during flight**

The main difference regarding aircraft systems, compared with the basic AFM, is the presence of the Power supply from built-in generators, Alternators with 70A and Converter Box. The powering and disconnection of converter box is very simple and, in most of abnormal cases, is automatically managed by relays and safety provisions.

The converter box (following described in Section 7) is managed by the pilot only via two switches, located in the bottom LH side of pilot seat on a single panel provided by: two switches, two breakers and two indicating lamps.

Only when pilot selects BOTH switches ON (right and left AUX) and both alternators are operative the system allows a surplus of power generated by the engines and alternators to flow into 4x converters and, then, into mission equipment, when installed.

The health status of converters inside the box (located into the baggage compartment) is monitored by mission operator, via 4x failure indicating lamps. Following the key concepts when managing converter boxes:

1. Mission Power Switches: they enable the converter box ONLY when BOTH are set to ON;
2. Converter box power: enabled only if both LH and RH main alternators are generating power;
3. Converter box: automatically switches OFF in case LH or RH main alternators is faulty / not generating;
4. Converter box: automatically switches OFF in case LH or RH mission switch is set to OFF;

5. Failure lamp: when illuminated, indicates that the correspondent converter is not working properly and needs to be replaced if the maximum available power from converter box is needed. When all converters are working properly, the system is capable to output 40A@28V. If one converter fails, 12A@28V are lost. For this reason, the end-user mission can continue if the equipment demand is less than 25/28A. On the contrary, the converter needs to be replaced.

Before operating the aircraft, the pilot/operator should become thoroughly familiar with this manual and, in particular, with this Section. Further on a continued and appropriate training and self study should be done.

Two types of emergency procedures are hereby given.

- a. “BOLD FACES” which must be known by heart by the pilot and executed, in the correct and complete sequence, immediately after the failure is detected and confirmed.

These procedures characters are boxed and highlighted:

## 1.1 ENGINE FAILURE DURING TAKEOFF RUN

### BEFORE ROTATION: ABORT TAKE OFF

- |    |                |                             |
|----|----------------|-----------------------------|
| 1. | Throttle Lever | <b>BOTH IDLE</b>            |
| 2. | Rudder         | <b>Keep heading control</b> |
| 3. | --             |                             |
| 4. | --             |                             |

- b. “other procedures” which should be well theoretically known and mastered, but that can be executed entering and following step by step the AFM current section appropriate checklist.

Additionally operating the aircraft, the pilot should become thoroughly familiar with the Garmin G950 Pilot’s Guide for Tecnam P2006T (P/N 190-01146-XX) – last issue - and, in particular, with the present AFM Section.



*Garmin G950 Pilot’s Guide for Tecnam P2006T (P/N 190-01146-XX) – last issue - must be carried onboard the airplane at all times.*



*Garmin G950 has a very high degree of functional integrity. However, the pilot must recognize that providing monitoring and/or self-test capability for all conceivable system failures is not practical. Although unlikely, it may be possible for erroneous operation to occur without a fault indication shown by the G950. It is thus the responsibility of the pilot to detect such an occurrence by means of crosschecking with all redundant or correlated information available in the cockpit.*

*In any case, as a failure or abnormal behaviour is detected pilots should act as follows:*

- 1. Keep self-control and maintain aircraft flight attitude and parameters*
- 2. Analyse the situation identifying, if required, the area for a possible emergency landing*
- 3. Apply the pertinent procedure*
- 4. Inform the Air Traffic Control as applicable*

**NOTE**

*For the safe conduct of later flights, any anomaly and/or failure must be communicated to the National Authorities in charge, in order to put the aircraft in a fully operational and safe condition.*

**NOTE**

*In this Chapter, following definitions apply:*

***Land as soon as possible:*** land without delay at the nearest suitable area at which a safe approach and landing is assured.

***Land as soon as practical:*** land at the nearest approved landing area where suitable repairs can be made.

**2.1. SINGLE ALTERNATOR FAILURE / OVERVOLTAGE**

Annunciation window	Alert window
<b>L ALT FAIL</b>	Lh Alternator
<b>OR</b>	
<b>R ALT FAIL</b>	Rh Alternator

- |                               |                 |
|-------------------------------|-----------------|
| 1. FIELD LH (or RH)           | <i>OFF</i>      |
| 2. LH and RH AUX FIELD switch | <i>BOTH OFF</i> |
| 3. FIELD LH (or RH)           | <i>ON</i>       |

**If the LH (or RH) ALT caution stays displayed**

- |                     |            |
|---------------------|------------|
| 1. FIELD LH (or RH) | <i>OFF</i> |
|---------------------|------------|

**If the LH (or RH) GENERATOR caution persists displayed**

- |                               |            |
|-------------------------------|------------|
| 1. CROSS BUS LH (or RH)       | <i>OFF</i> |
| 2. Land as soon as practical. |            |

**NOTE**

*The battery and a single generator are able to supply the electrical power necessary for the entire mission, but redundancy is lost.*



## 2.2 BOTH ALTERNATORS FAILURE

Annunciation window	Alert window
<b>L ALT FAIL</b>  <b>R ALT FAIL</b>	Lh Alternator
	Rh Alternator

In event of both L and R ALT FAIL caution alerts displayed:

- |                               |                 |
|-------------------------------|-----------------|
| 1. FIELD LH and RH            | <i>BOTH OFF</i> |
| 2. LH and RH AUX FIELD switch | <i>BOTH OFF</i> |
| 3. FIELD LH and RH            | <i>BOTH ON</i>  |

### If both LH and RH ALT cautions stay displayed

- |                        |                 |
|------------------------|-----------------|
| 1. FIELD LH and RH     | <i>BOTH OFF</i> |
| 2. CROSS BUS LH and RH | <i>BOTH OFF</i> |

### If engine starting battery modification is applied

- |                              |    |
|------------------------------|----|
| 1. EMERG BATT switch         | ON |
| 2. Land as soon as possible. |    |

### If engine starting battery modification is not applied

1. Land as soon as possible.

#### **NOTE**

*The battery can supply electrical power for at least 30 minutes.*

## 2.3 BOTH ALTERNATORS OVERVOLTAGE

Annunciation window	Alert window
<b>L BUS VOLT HIGH</b>	Lh overvoltage
<b>R BUS VOLT HIGH</b>	Rh overvoltage

In event of both L and R BUS VOLT HIGH warning alerts displayed:

1. FIELD LH and RH *BOTH OFF*
2. LH and RH AUX FIELD switch *BOTH OFF*
3. FIELD LH and RH *BOTH ON (one at a time)*

### if LH (or RH) OVERVOLT warning stays displayed

1. FIELD LH (or RH) *OFF*

### if both LH and RH OVERVOLT warning stay displayed

1. CROSS BUS LH and RH *BOTH OFF*
2. FIELD LH and RH *BOTH OFF*
3. FIELD LH and RH *BOTH ON (one at a time)*

#### *If LH (or RH) OVERVOLT warningt stays displayed*

1. FIELD LH (or RH) *OFF*
2. CROSS BUS LH (or RH) *ON*

#### *If both LH and RH OVERVOLT warning stay displayed*

1. FIELD LH and RH *BOTH OFF*
2. CROSS BUS LH and RH *BOTH OFF*

#### If engine starting battery modification is applied

1. EMERG BATT switch *ON*
2. Land as soon as possible.

#### If engine starting battery modification is not applied

1. Land as soon as possible.

#### **NOTE**

*The battery can supply electrical power for at least 30 minutes.*

### 3. ENGINE SECURING

Following procedure is applicable to shut-down one engine in flight:

- |                               |                 |
|-------------------------------|-----------------|
| 1. Throttle Lever             | <b>IDLE</b>     |
| 2. Ignition                   | <b>BOTH OFF</b> |
| 3. Propeller Lever            | <b>FEATHER</b>  |
| 4. Fuel Selector              | <b>OFF</b>      |
| 5. Electrical fuel pump       | <b>OFF</b>      |
| 6. LH and RH AUX FIELD switch | <b>BOTH OFF</b> |

**NOTE**

*If necessary, this procedure is applicable to both engines. When both engines are secured, both CROSS BUS switches must be set to OFF.*

After securing engine(s), after analysing situation, refer immediately to following procedures:

- |                                  |                |
|----------------------------------|----------------|
| ENGINE FAILURE IN FLIGHT:        | see Para. 6.5  |
| SINGLE GENERATOR FAILURE:        | see Para. 2.1  |
| or BOTH GENERATOR FAILURE:       | see Para. 2.2  |
| INFLIGHT ENGINE RESTART:         | see Para. 6.2  |
| ONE ENGINE INOPERATIVE LANDING:  | see Para. 6.6  |
| or LANDING WITHOUT ENGINE POWER: | see Para. 10.1 |

## 5. OTHER EMERGENCIES

### 5.1 EMERGENCY DESCENT



CAUTION

*Descent with airspeed at VLE, idle power and gear down will provide high descent rates and pitch attitudes up to -15°.*

*Anticipate altitude capture and return to level flight during emergency descent in order to assure a safe and smooth recovery from maneuver.*

- |                 |                      |
|-----------------|----------------------|
| 1. Power levers | <i>IDLE</i>          |
| 2. Flaps        | <i>UP</i>            |
| 3. IAS          | <i>below VLO/VLE</i> |
| 4. Landing gear | <i>DOWN</i>          |
| 5. Airspeed     | <i>Up to VLE</i>     |

### 5.2 TOTAL ELECTRICAL FAILURE

In case of electrical system overall failure, apply following procedure:

- |                                      |                 |
|--------------------------------------|-----------------|
| 1. Emergency light                   | <i>ON</i>       |
| 2. Standby attitude indicator switch | <i>ON</i>       |
| 3. MASTER SWITCH                     | <i>OFF</i>      |
| 4. FIELD LH and RH                   | <i>BOTH OFF</i> |
| 5. LH and RH AUX FIELD switch        | <i>BOTH OFF</i> |
| 6. MASTER SWITCH                     | <i>ON</i>       |
| 7. FIELD LH and RH                   | <i>BOTH ON</i>  |

#### If failure persists

- |  |  |
|--|--|
| 9. EMERG BATT switch   | <i>ON (if engine starting battery installed)</i> |
| 10. <b>Land as soon as possible</b> applying <i>emergency landing gear extension</i> procedure (see Para. 7.1) |  |

**WARNING**

*An electrical system overall failure prevents flaps operation: landing distance without flaps increases of about 25%.*

**CAUTION**

*A fully charged battery can supply electrical power for at least 30 minutes.*

## 6.2 INFLIGHT ENGINE RESTART

*After:*



**WARNING**

- *mechanical engine seizure;*
- *fire;*
- *major propeller damage*

*engine restart is not recommended.*

- |                                    |  |
|------------------------------------|--|
| 1. Carburettor heat                | <i>ON if required</i>                  |
| 2. Electrical fuel pump            | <i>ON</i>                              |
| 3. Fuel quantity indicator         | <i>CHECK</i>                           |
| 4. Fuel Selector                   | <i>CHECK (Crossfeed if required)</i>   |
| 5. FIELD                           | <i>OFF</i>                             |
| 6. LH and RH AUX FIELD switch      | <i>BOTH OFF</i>                        |
| 7. Ignition                        | <i>BOTH ON</i>                         |
| 8. Operating engine Throttle Lever | <i>SET as practical</i>                |
| 9. Stopped engine Throttle Lever   | <i>IDLE</i>                            |
| 10. Stopped engine Propeller Lever | <i>FULL FORWARD</i>                    |
| 11. Start push-button              | <i>PUSH</i>                            |
| 12. Propeller Lever                | <i>SET at desired rpm</i>              |
| 13. FIELD                          | <i>ON (check for positive ammeter)</i> |
| 14. Engine throttle levers         | <i>SET as required</i>                 |

### **If engine restart is unsuccessful**

- |                                     |   |
|-------------------------------------|---|
| 15. EMERG BATT switch               | <i>ON (if starting battery installed)</i> |
| 16. Repeat engine restart procedure |   |



**CAUTION**

*After engine restart, if practical, moderate propeller rpm and throttle increase to allow OIL and CHT/CT temperatures for stabilizing in the green arcs.*

**NOTE**

*If the fuel quantity in the tank which feeds the stopped engine is low, select the opposite side fuel tank by means of the fuel selector.*

### **If engine restart is still unsuccessful:**

- |   |   |
|---|---|
| 17. Affected engine   | <i>SECURE (see engine securing procedure Para. 3)</i> |
| 18. Land as soon as possible applying one engine inoperative landing procedure. See Para. 6.6 |   |

### 6.3 ENGINE FAILURE DURING TAKEOFF RUN

#### BEFORE ROTATION: ABORT TAKE OFF

- |                   |                             |
|-------------------|-----------------------------|
| 1. Throttle Lever | <b>BOTH IDLE</b>            |
| 2. Rudder         | <b>Keep heading control</b> |
| 3. Brakes         | <b>As required</b>          |

#### When safely stopped:

- |                                       |                 |
|---------------------------------------|-----------------|
| 4. Failed Engine Ignition             | <b>BOTH OFF</b> |
| 5. Failed Engine Field                | <b>OFF</b>      |
| 6. LH and RH AUX FIELD switch         | <b>BOTH OFF</b> |
| 7. Failed Engine Electrical fuel pump | <b>OFF</b>      |

#### IF THE DECISION IS TAKEN TO CONTINUE THE TAKEOFF:



*A take-off abort should always be preferred if a safe stop can be performed on ground.*

*A suggested "GO-NO-GO" criteria is: abort take-off until LG is still down and locked.*

*Once airborne accelerate to Blue Line Speed ( $V_{YSE}$ ) before commanding LG retraction.*

*Take-off planning should take into account that high density altitude and aircraft mass may result in OEI negative climb rate.*

*$V_{YSE}$  with flap up shall be flown in order to achieve best possible rate of climb after landing gear retraction and engine feathering.*

- |  |  |
|--|--|
| 1. Operating engine Throttle Lever           | <b>FULL POWER</b>  |
| 2. Operating engine Propeller Lever          | <b>FULL FORWARD</b>  |
| 3. Heading                                   | <b>Keep control using rudder and ailerons</b>              |
| 4. Attitude                                  | <b>Reduce as appropriate to keep airspeed over 62 KIAS</b> |
| 5. <u>Inoperative engine</u> Propeller Lever | <b>FEATHER</b>   |
| 6. Landing gear control lever                | <b>UP</b>  |
| 7. Airspeed                                  | <b><math>V_{XSE}/V_{YSE}</math> as required</b>            |
| 8. Flaps                                     | <b>0°</b>  |
| 9. LH and RH AUX FIELD switch                | <b>BOTH OFF</b>  |

#### 6.4 ENGINE FAILURE DURING CLIMB

- |  |  |
|--|--|
| 1. Autopilot                                 | <b>OFF</b>   |
| 2. Heading                                   | <i>Keep control using rudder and ailerons</i>              |
| 3. Attitude                                  | <i>Reduce as appropriate to keep airspeed over 62 KIAS</i> |
|  |  |
| 4. Operating engine Throttle Lever           | <i>FULL THROTTLE</i>                                       |
| 5. Operating engine Propeller Lever          | <i>FULL FORWARD</i>  |
| 6. Operative engine Electrical fuel pump     | <i>Check ON</i>  |
| 7. LH and RH AUX FIELD switch                | <i>BOTH OFF</i>  |
| 8. <u>Inoperative engine</u> Propeller Lever | <i>FEATHER</i>   |
| 9. <u>Inoperative engine</u>                 | <i>Confirm and SECURE</i>                                  |

#### If engine restart is possible:

10. Apply INFLIGHT ENGINE RESTART procedure    *see Para 6.2*

#### If engine restart is unsuccessful or it is not recommended:

11. **Land as soon as possible**
12. One engine inoperative landing procedure.    *see Para. 6.6*



**WARNING**

*Following a mechanical engine seizure, fire or a major propeller damage engine restart is not recommended.*



**WARNING**

*Continuation of flight to a safe landing runway must be planned taking into account maximum operating ceiling in OEI condition. Refer to Section 5 Para 1, "One-engine rate of climb".*

## 6.5 ENGINE FAILURE IN FLIGHT

- |              |  |
|--------------|--|
| 1. Autopilot | <b>OFF</b>   |
| 2. Heading   | <i>Keep control using rudder and ailerons</i>              |
| 3. Attitude  | <i>Adjust as appropriate to keep airspeed over 62 KIAS</i> |

- |  |  |
|--|--|
| 4. LH and RH AUX FIELD switch            | <b>BOTH OFF</b>  |
| 5. Operating engine                      | <i>Monitor engine instruments</i>                      |
| 6. Operative engine Electrical fuel pump | <i>Check ON</i>  |
| 7. Operating engine Fuel Selector        | <i>Check correct feeding<br/>(crossfeed if needed)</i> |

### If engine restart is possible:

8. Apply INFLIGHT ENGINE RESTART procedure *see Para 6.2*

### If engine restart is unsuccessful or it is not recommended:

9. Land as soon as possible
10. One engine inoperative landing procedure. *see Para. 6.6*



**WARNING**

*Following a mechanical engine seizure, fire or a major propeller damage engine restart is not recommended.*



**WARNING**

*Continuation of flight to a safe landing runway must be planned taking into account maximum operating ceiling in OEI condition. Refer to Section 5 Para 12. Rate of climb with One Engine Inoperative.*



## 8 SMOKE AND FIRE OCCURRENCE

### 8.1 ENGINE FIRE ON THE GROUND

- |                               |                              |
|-------------------------------|------------------------------|
| 1. Fuel Selectors             | <b><i>BOTH OFF</i></b>       |
| 2. Ignitions                  | <b><i>ALL OFF</i></b>        |
| 3. LH and RH AUX FIELD switch | <b><i>BOTH OFF</i></b>       |
| 4. Electrical fuel pumps      | <b><i>BOTH OFF</i></b>       |
| 5. Cabin heat and defrost     | <b><i>OFF</i></b>            |
| 6. MASTER SWITCH              | <b><i>OFF</i></b>            |
| 7. Parking Brake              | <b><i>ENGAGED</i></b>        |
| 8. Aircraft Evacuation        | <b>carry out immediately</b> |



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

## 8.2 ENGINE FIRE DURING TAKEOFF RUN

### BEFORE ROTATION: ABORT TAKE OFF

- |                   |                             |
|-------------------|-----------------------------|
| 1. Throttle Lever | <b>BOTH IDLE</b>            |
| 2. Rudder         | <i>Keep heading control</i> |
| 3. Brakes         | <i>As required</i>          |

#### With aircraft under control

- |                               |                              |
|-------------------------------|------------------------------|
| 4. Fuel Selector              | <b>BOTH OFF</b>              |
| 5. Ignitions                  | <b>ALL OFF</b>               |
| 6. LH and RH AUX FIELD switch | <b>BOTH OFF</b>              |
| 7. Electrical fuel pump       | <b>BOTH OFF</b>              |
| 8. Cabin heat and defrost     | <b>OFF</b>                   |
| 9. MASTER SWITCH              | <b>OFF</b>                   |
| 10. Parking Brake             | <b>ENGAGED</b>               |
| 11. Aircraft Evacuation       | <i>carry out immediately</i> |

**WARNING**

*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

### IF THE DECISION IS TAKEN TO CONTINUE THE TAKEOFF:

*A take-off abort should always be preferred if a safe stop can be performed on ground.*

*A suggested "GO-NO-GO" criteria is: abort take-off until LG is still down and locked.*

**WARNING**

*Once airborne accelerate to Blue Line Speed ( $V_{YSE}$ ) before commanding LG retraction.*

*Take-off planning should take into account that high density altitude and aircraft mass may result in OEI negative climb rate.*

*$V_{YSE}$  with flap up shall be flown in order to achieve best possible rate of climb after landing gear retraction and engine feathering.*

- |  |  |
|--|--|
| 1. Operating engine Throttle Lever             | <b>FULL POWER</b>  |
| 2. Operating engine Propeller Lever            | <b>FULL FORWARD</b>  |
| 3. Heading                                     | <i>Keep control using rudder and ailerons</i>              |
| 4. Attitude                                    | <i>Reduce as appropriate to keep airspeed over 62 KIAS</i> |
| 5. <u>Fire affected engine</u> Propeller Lever | <b>FEATHER</b>   |
| 6. Landing gear control lever                  | <b>UP</b>  |
| 7. Airspeed                                    | $V_{XSE}/V_{YSE}$ as required                              |
| 8. Flaps                                       | <b>0°</b>  |

**At safe altitude**

- |     |  |                             |
|-----|--|-----------------------------|
| 9.  | LH and RH AUX FIELD switch   | <i>BOTH OFF</i>             |
| 10. | Cabin heat and defrost   | <i>BOTH OFF</i>             |
| 11. | <u>Fire affected engine</u> Fuel Selector  | <i>Confirm and OFF</i>      |
| 12. | <u>Fire affected engine</u> Ignitions  | <i>Confirm and BOTH OFF</i> |
| 13. | <u>Fire affected engine</u> Electrical fuel pump   | <i>Confirm and OFF</i>      |
| 14. | <u>Fire affected engine</u> FIELD  | <i>OFF</i>                  |
| 15. | <b>Land as soon as possible</b> applying <i>one engine inoperative landing</i> procedure.<br>See Para. 6.6 |                             |

### 8.3 ENGINE FIRE IN FLIGHT

- |  |  |
|--|--|
| 1. Cabin heat and defrost  | <b>BOTH OFF</b>  |
| 2. LH and RH AUX FIELD switch  | <b>BOTH OFF</b>  |
| 3. Autopilot   | <b>OFF</b>   |
| 4. <u>Fire affected engine</u> Fuel Selector   | <b>Confirm and OFF</b>                                     |
| 5. <u>Fire affected engine</u> Ignition  | <b>Confirm and BOTH OFF</b>                                |
| 6. <u>Fire affected engine</u> Throttle Lever  | <b>Confirm and FULL FORWARD</b>                            |
| 7. <u>Fire affected engine</u> Propeller Lever   | <b>Confirm and FEATHER</b>                                 |
| 8. <u>Fire affected engine</u> Electrical fuel pump  | <b>OFF</b>   |
| 9. Heading   | <b>Keep control using rudder and ailerons</b>              |
| 10. Attitude   | <b>Adjust as appropriate to keep airspeed over 62 KIAS</b> |
| 11. <u>Fire affected engine</u> Field  | <b>OFF</b>   |
| 12. Cabin ventilation  | <b>OPEN</b>  |
| 13. Land as soon as possible applying one engine inoperative landing procedure.<br>See Para. 6.6 |  |

### 8.4 ELECTRICAL SMOKE IN CABIN ON THE GROUND

- |                               |                              |
|-------------------------------|------------------------------|
| 1. MASTER SWITCH              | <b>OFF</b>                   |
| 2. Cabin heat and defrost     | <b>OFF</b>                   |
| 3. LH and RH AUX FIELD switch | <b>BOTH OFF</b>              |
| 4. Throttle Lever             | <b>BOTH IDLE</b>             |
| 5. Ignitions                  | <b>ALL OFF</b>               |
| 6. Fuel Selector              | <b>BOTH OFF</b>              |
| 7. Parking Brake              | <b>ENGAGED</b>               |
| 8. Aircraft Evacuation        | <b>carry out immediately</b> |

**WARNING**

Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.

## 8.5 ELECTRICAL SMOKE IN CABIN DURING FLIGHT

- |  |             |
|--|-------------|
| 1. Cabin ventilation                       | <i>OPEN</i> |
| 2. Emergency light                         | <i>ON</i>   |
| 3. Standby attitude indicator switch       | <i>ON</i>   |
| 4. Gain VMC conditions as soon as possible |             |

In case of cockpit fire:

- |                      |                                  |
|----------------------|----------------------------------|
| 5. Fire extinguisher | <i>use toward base of flames</i> |
|----------------------|----------------------------------|



**CAUTION**

*A tripped circuit breaker should not be reset.*

**If smoke persists, shed electrical supply in order to isolate faulty source by:**

- |                               |                 |
|-------------------------------|-----------------|
| 6. FIELD LH and RH            | <i>OFF</i>      |
| 7. LH and RH AUX FIELD switch | <i>BOTH OFF</i> |
| 8. AVIONICS LH and RH         | <i>OFF</i>      |
| 9. CROSS BUS LH and RH        | <i>BOTH OFF</i> |



**CAUTION**

*A fully charged battery can supply electrical power for at least 30 minutes.*

**If faulty source is found:**

10. It may be possible to restore non faulty power sources (one at a time)

**If smoke persists:**



**WARNING**

*Before total electrical system shutdown consider gaining VMC condition, at night set personal emergency light on.*

*Only emergency light and emergency ADI will be electrically powered.*

*All radio COM and NAV, Landing Gear lever (normal mode) and indication lights, electrical trims and flaps will be unserviceable.*

- |                              |            |
|------------------------------|------------|
| 11. MASTER SWITCH            | <i>OFF</i> |
| 12. Land as soon as possible |            |

INTENTIONALLY LEFT BLANK

**Supplement G14: pages replacement instructions**

## **SECTION 4 – NORMAL PROCEDURES**

Apply following pages replacement procedure:

<b>Supplement G14 - NORMAL PROCEDURES page</b>		<b>Supplement S1 Section 4 page</b>
SSMP4 – 26 thru 27	<b>REPLACE</b>	Page S4 – 26 thru 27 of Supplement G1, Section 4

INTENTIONALLY LEFT BLANK



### 3.10 CRUISE

- 1 LH and RH Propeller Lever *SET to 1900-2250 RPM*

**CAUTION**

*Throttles MAP decrease should be made before propeller speed reduction below 2200 RPM, as, contrariwise, Propeller Lever increase RPM should be set before engine Throttle Levers are advanced.*

- 2 Engine parameters check (LH and RH)

- Oil temperature: *90° - 110 °C*  
*(or 50° - 130° C, if MOD2006/002 is applied)*
- CHT / CT: *50° - 135° / 50° - 120 °C*
- Oil pressure: *2 - 5 bar.*
- Fuel pressure: *2.2 – 5.8 psi*  
*\*2.2 – 7.26 psi (0.15 – 0.50 bar)*

*\*applicable for fuel pump part no.893110 and no.893114*

- 3 Carburettor heat as needed *(see also instructions addressed on Section 3)*

**WARNING**

*Deselect and do not use Auto Pilot if possible icing condition area is inadvertently entered.*

- 4 Fuel balance and crossfeed *check as necessary*

**NOTE**

*To evaporate possibly accumulated condensation water, once per flight day (for approximately 5 minutes) 100° C (212° F) oil temperature must be reached.*

#### 3.10.1 CONVERTER BOX TURN ON

- 1 LH and RH AUX FIELD *ON*
- 2 Converter Box *Check enabled (no fail lamps)*
- 3 Mission systems *Use as required*

#### 3.10.2 CONVERTER BOX TURN OFF

- 1 Mission systems *Shut down as necessary*
- 2 LH and RH AUX FIELD *OFF*
- 3 Green lamps on switch panel *Check OFF*

### 3.11 TURBULENT AIR OPERATION

In keeping with good operating practice used in all aircraft, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural loads caused by gusts and to allow for inadvertent speed build-ups, which may occur as a result of the turbulence or of distractions caused by the conditions.

### 3.12 DESCENT AND APPROACH

- |   |                   |                                       |
|---|-------------------|---------------------------------------|
| 1 | Propellers        | <i>Set to Max Continuous 2250 RPM</i> |
| 2 | Carburettors heat | <i>As required</i>                    |
| 3 | Altimeter setting | <i>QNH set and crosscheck</i>         |

### 3.13 BEFORE LANDING

- | 1                              | Rear passengers seats   | <i>Seats set at full aft and lower position</i>   |              |                                |                                |                               |
|--------------------------------|---|---|--------------|--------------------------------|--------------------------------|-------------------------------|
| 2                              | LH and RH Electrical Fuel pump  | <i>BOTH ON</i>  |              |                                |                                |                               |
| 3                              | On downwind leg:  |   |              |                                |                                |                               |
|                                | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 50%; padding: 5px;">MTOW 1180kg</th> <th style="width: 50%; padding: 5px;">MTOW 1230 kg</th> </tr> <tr> <td style="padding: 5px;"><i>V<sub>FE</sub>= 119KIAS</i></td> <td style="padding: 5px;"><i>V<sub>FE</sub>=122KIAS</i></td> </tr> </table> | MTOW 1180kg   | MTOW 1230 kg | <i>V<sub>FE</sub>= 119KIAS</i> | <i>V<sub>FE</sub>=122KIAS</i>  | <i>Flaps T/O</i>              |
| MTOW 1180kg                    | MTOW 1230 kg  |   |              |                                |                                |                               |
| <i>V<sub>FE</sub>= 119KIAS</i> | <i>V<sub>FE</sub>=122KIAS</i>   |   |              |                                |                                |                               |
| 4                              | Speed below applicable VLO/VLE  | <i>Landing gear control knob - DOWN –<br/>Check green lights ON</i>   |              |                                |                                |                               |
| 5                              | Carburettors heat   | <i>CHECK OFF</i>  |              |                                |                                |                               |
| 6                              | LH and RH Propeller Lever   | <i>FULL FORWARD</i>   |              |                                |                                |                               |
| 7                              | On final leg: speed below 93 KIAS   | <i>Flaps FULL</i>   |              |                                |                                |                               |
| 8                              | Final Approach Speed  | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 50%; padding: 5px;">MTOW 1180kg</th> <th style="width: 50%; padding: 5px;">MTOW 1230 kg</th> </tr> <tr> <td style="padding: 5px;"><i>V<sub>APP</sub>= 70KIAS</i></td> <td style="padding: 5px;"><i>V<sub>APP</sub>=71KIAS</i></td> </tr> </table> | MTOW 1180kg  | MTOW 1230 kg                   | <i>V<sub>APP</sub>= 70KIAS</i> | <i>V<sub>APP</sub>=71KIAS</i> |
| MTOW 1180kg                    | MTOW 1230 kg  |   |              |                                |                                |                               |
| <i>V<sub>APP</sub>= 70KIAS</i> | <i>V<sub>APP</sub>=71KIAS</i>   |   |              |                                |                                |                               |
| 9                              | Landing and taxi light  | <i>ON</i>   |              |                                |                                |                               |
| 10                             | Touchdown speed   | <i>65 KIAS</i>  |              |                                |                                |                               |

**Supplement G14: pages replacement instructions**

## **SECTION 5 – PERFORMANCE**

Apply following instruction:

**See Basic AFM - Section 5**

### **NOTE**

*Usually, the Special Mission Platform P2006T is also equipped with holes in the cabin and/or tailcone, ready for third parties sensor's integration. While the Tecnam intent is to offer a platform ready for sensors' integration, it is end-user responsibility to receive the approval from authority for each equipment installation, including the supplement of Section 5, should the equipment affect it (i.e. protruding cameras).*

INTENTIONALLY LEFT BLANK

Supplement G14: pages replacement instructions

## **SECTION 6 – WEIGHT AND BALANCE**

Apply following instruction:

**See Basic AFM - Section 6**

INTENTIONALLY LEFT BLANK

**Supplement G14: pages replacement instructions**

## **SECTION 7 – AIRFRAME AND SYSTEMS DESCRIPTION**

Apply following pages replacement procedure:

<b>Supplement G14 - AIRFRAME AND SYSTEMS DESCRIPTION page</b>		<b>Supplement S1 Section 7 page</b>
SSMP7 – 41	<b>REPLACES</b>	Page S7 – 41 of Supplement G1, Section 7
SSMP7 – 44 thru 48	<b>REPLACE</b>	Page S7 – 44 thru 46 of Supplement G1, Section 7

INTENTIONALLY LEFT BLANK



## **18. ELECTRICAL SYSTEMS**

Primary DC power is provided by two engine-driven alternators which, during normal operations, operate in parallel.

Each alternator is rated at 14,2-14,8 VDC, 70 Amp, and it is fitted with an external voltage regulator, which acts to maintain a constant output voltage, and with an automatic overvoltage device protecting the circuits and the electric components from an excessive voltage caused by alternator failures.

The power rating of the each alternator is such that if one alternator fails the other one can still supply the airplane equipment to maintain flight safety.

Secondary DC power is provided by a battery (lead type - Gill Teledyne G35, 12 V, 23-Ah in 1h run time) and an external DC power source can be connected to the aircraft DC distribution system.

On the instruments panel, right side, it is installed a voltmeter/ammeter. The ammeter section can indicate the current supplied by either left or right alternator switching a dedicated selector.

There are five different busses (make reference to Figure 11):

- Battery bus
- LH Alternator bus
- RH Alternator bus
- LH Avionic bus
- RH Avionic bus

The distribution system operates as a single bus with power being supplied by the battery and both alternator but it is possible to separate the left busses from the right busses when required by means of the Cross Bus switches.

All electrical loads are divided among the five busses on the basis of their importance and required power: equipment with duplicate functions are connected to separate busses.

The Battery bus, which supplies the most important loads, is energized from three sources: the battery and both alternator. This allows the bus for remaining active also in case of two independent faults in the supply paths.

The second ones allow, through a relay, for cutting off the power supply to the pertinent avionic bus.

When both generators are correctly operating and all above mentioned switches are in ON position, all the busses are connected to the generators.

The ignition switches, two for each engine and grouped on the over head panel, are instead independent from the airplane electrical system (generation and distribution); they only control and open the engine electrical circuit.



**WARNING**

*If ignition switches are turned ON, a propeller movement can cause the engine starting with consequent hazard for people nearby.*


## 18.1 MISSION POWER CONTROL

When the airplane embodies the design change “Power supply from built-in generators”, the Rotax engine built-in generators are enabled in order to supply power to two available bus bars.

Each built-in generator is activated by means of a switch (LH and RH AUX FIELD) located on the LH breakers rack where are located also the breakers related to the auxiliary power generation system.

The light (switch built-in light) indicates that the electrical power is being generated.

The below figure presents the control panel for the built-in generators which in turn activate the converter box:



**Switches panels**

Next paragraph describes the converter and connector box installed in the P2006T baggage compartment floor. This box allows the operator to have a source of 28Volt/40Amp electrical power for different mission equipment.

### 18.1.1 CONVERTER BOX

The following points illustrate how the converter box works:

1. A closed, light alloy made box incorporates 4x converters Ameri-King AK-550-12, each one capable of 12Amp/28VDC output using a 14VDC input;
2. Each converter is fed by one different power generation:
  - 20Amp coming directly from the LH aux generator bus;
  - 20Amp coming directly from the RH aux generator bus;
  - 30Amp coming from the LH external alternator bus;
  - 30Amp coming from the RH external alternator bus;
3. Each converter is protected with circuit breakers on the INPUT and OUTPUT sides;
4. The 30Amp current coming from the LH and RH external alternators is the amount of power surplus available due to the 2006/202 design change;
5. The same switches shown in the MOD2006/046 and reported in the figure above enable the relays that feed the converters;
6. Four relays enable the external power to feed also the converter box for ground test purposes, when external socket is connected;
7. A connector box allows the end user to have a maximum current of 40Amp at 28VDC available (1120W).

#### NOTE


*When using the ground power unit to test on-ground the mission equipment, remember that:*

- 14VDC GPU only can be used, as done on standard P2006T.
- the minimum GPU capacity to properly feed mission equipment should be at least 150Amp @14VDC
- The FIELD AUX switches needs to be "ON" to test converter box connected equipment, "OFF" to test the aircraft avionics

#### NOTE

*When connecting mission equipment to the system please note tha the amount of current provided depends on engine rpm setting. The maximum electrical power is available from 1.900rpm on.*

In the following figures the new Electrical system schematic is reported.



Electrical system schematic (Page 1)





Figure 25 – Electrical system schematic (Page 2)



Electrical system schematic (Page 3)

INTENTIONALLY LEFT BLANK

Supplement G14: pages replacement instructions

## **SECTION 8 – GROUND HANDLING & SERVICE**

Apply following instruction:

See Basic AFM - Section 8

INTENTIONALLY LEFT BLANK



**SUPPLEMENT NO. G15  
JAPANESE AFMS****Record of Revisions**

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval Or Under DOA Privileges
			DO	OoA	HDO	
0	--	First issue	D. Ronca	C. Caruso	M. Oliva	See Note (*)

Note (\*): this Supplement has been originally issued after EASA Third Country Validation process.

**LOEP**

Page	Revision	Page	Revision
<b>G15-1</b>	Rev 0		
<b>G15-2</b>	Rev 0		
<b>G15-3</b>	Rev 0		
<b>G15-4</b>	Rev 0		
<b>G15-5</b>	Rev 0		
<b>G15-6</b>	Rev 0		
<b>G15-7</b>	Rev 0		
<b>G15-8</b>	Rev 0		

## TABLE OF CONTENTS

INTRODUCTION .....	4
LIMITATION .....	5
1. Approved Fuel.....	5
2. Japanese Placards.....	6
2.1. Operating Limitations .....	6
2.2. Rear Seats.....	6
2.3. Other Placards .....	7

## INTRODUCTION

This Supplement applies for Japanese registered aircraft.

It contains supplemental information to the basic information approved in EASA aircraft Flight Manual when the aircraft is registered in Japan.

This supplement is applicable to both P2006T digital and analogue configuration.

For Limitations, procedures, and performance information not contained in this supplement, refer to the basic Aircraft Flight Manual.

## **LIMITATION**

### **1. Approved Fuel**

- MOGAS compliant with PRC National Standard GB17930-2006 - Octane Rating (RON) 97
- MOGAS ASTM D4814
- MOGAS EN 228 Super/Super plus (min. RON 95)
- AVGAS 100 LL (ASTM D910)

NOTE: For additional information, refer to Rotax Service Instruction No. 912-016, latest issue.



Prolonged use of Aviation Fuel Avgas 100LL results in greater wear of valve seats and greater combustion deposits inside cylinders due to higher lead content. It is therefore suggested to avoid using this type of fuel unless strictly necessary. Make reference to Rotax Maintenance Manual who provides dedicated checks due to the prolonged use of Avgas.

## 2. Japanese Placards

Hereinafter the placards, related to the operating limitations and installed on P2006T, are reported.

### 2.1. Operating Limitations


On the instrument panel, it is placed the following placard reminding the observance of aircraft operating limitations; make reference to Para. 22 for the list of equipment required on board to allow flight operations in VFR Day, VFR Night, IFR Day and IFR Night conditions.



### 2.2. Rear Seats

During Taxi, Take Off, Landing (including Emergency Landing), both rear seats must be kept in the lowest and full aft position.

The following placard is located aside both rear seats.



### 2.3.Other Placards

Description	Placard (English and Japanese)	Place
Smoking ban.	<b>NO SMOKING   禁煙</b>	Instruments panel, right side
Ditching emergency exit: opening instructions		Ditching emergency exit handle: internal side
Ditching emergency exit: opening instructions		Ditching emergency exit handle: external side
Door locking system: by-pass instructions		Main door and emergency exit: internal side

Door locking system: by-pass instructions		Main door and emergency exit: external side
Emergency exit label		Emergency exit: internal and external side
Main door: exit instructions		Main door, internal side



## SUPPLEMENT NO. G16 - MD302 ALTERNATIVE STAND-BY INSTRUMENT

### RECORD OF REVISIONS

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval Or Under DOA Privileges
			DO	OoA	HDO	
0	-	First issue	D. Ronca	C. Caruso	M. Oliva	EASA Approval No. 10058288
1	SMD4-15, SMD4-6	S4-15 replaced by S4-6	A. Sabino	C. Caruso	M. Oliva	DOA Privileges
	SMD2-12	Cancelled. Information integrated in basic AFM.				

## **LOEP**

	<b>Pages</b>	<b>Revision</b>
<b>Cover pages</b>	G16–1 thru 10	<i>Rev. 1</i>
<b>Section 3</b>	SMD3 – 15 thru 16	<i>Rev. 0</i>
	SMD3 – 30	<i>Rev. 0</i>
<b>Section 4</b>	SMD4 – 6	<i>Rev. 1</i>
<b>Section 7</b>	MD7 – 29	<i>Rev. 0</i>
	SMD7 – 37	<i>Rev. 0</i>
	SMD7 – 39	<i>Rev. 0</i>

## **INTRODUCTION**

This section contains supplemental information to operate, in a safe and efficient manner, the aircraft when equipped with Garmin G950 Integrated Flight Deck System (Design Change MOD 2006/002) and with MD302. The MD302 refers to the following design change:

- MOD2006/212 - MD302 Alternative Stand-By Instrument

The information contained herein supplements or supersedes the basic Aircraft Flight Manual or the Supplement G1, as applicable: detailed instructions are provided to allow the owner for replacing the Basic AFM/Supplement G1 pages containing information amended as per the Design Change in subject.

**It is the owner's/operator's responsibility to replace the mentioned pages in the AFM in accordance with the instructions herein addressed section by section.**

**Supplement G16: pages replacement instructions**

## **SECTION 1 – GENERAL**

Apply following instruction:

**See Basic AFM - Section 1**

**Supplement G16: pages replacement instructions**

## **SECTION 2 – LIMITATIONS**

Apply following instructions:

**See Basic AFM - Section 2**

**Supplement G16: pages replacement instructions**

### **SECTION 3 – EMERGENCY PROCEDURES**

Apply following pages replacement procedure:

<b>Supplement G16 - EMERGENCY PROCEDURES page</b>		<b>Supplement S1 Section 3 page</b>
MD3 – 15 thru 16	<b>REPLACE</b>	Page S3–15 thru 16 of Supplement G1, Section 3
MD3 – 30	<b>REPLACES</b>	Page S3–30 of Supplement G1, Section 3


## 2.9 LOSS OF INFORMATION DISPLAYED

When a LRU or a LRU function fails, a large red 'X' is typically displayed on the display field associated with the failed data.

### NOTE


*In most of cases, the red "X" annunciation is accompanied by a message advisory alert issuing a flashing ADVISORY Softkey annunciation which, once selected, acknowledges the presence of the message advisory alert and displays the alert text message in the Alerts Window. Refer to G950 Pilot's Guide for Tecnam P2006T (P/N 190-01146-00), last issue, Appendix A, Message Advisories list.*

## 2.10 LOSS OF AIRSPEED INFORMATION

	<p><b>AIRSPEED FAIL</b> (RED X ON DISPLAY FIELD)</p>
	<p>Display system is not receiving airspeed input from the Air Data Computer.</p>


**INSTRUCTION:** revert to stand-by airspeed indicator

## 2.10 LOSS OF ATTITUDE INFORMATION

	<p><b>ATTITUDE FAIL</b> (RED X ON DISPLAY FIELD)</p>
	<p>Display system is not receiving attitude information from the AHRS.</p>

**INSTRUCTION:** revert to stand-by attitude indicator

## 2.11 LOSS OF ALTITUDE INFORMATION

	<p><b>ALTITUDE FAIL</b> (RED X ON DISPLAY FIELD)</p>
	<p>Display system is not receiving altitude input from the Air Data Computer.</p>

**INSTRUCTION:** revert to stand-by altitude indicator



### 5.3 MD 302 BATTERY FAILURE



*The MD302 internal battery will recharge itself from aircraft power while in normal mode. A battery capacity check occurs each time the unit is powered on. If the battery capacity is determined to be less than 80%, there will be a battery pack warning. If the warning persists more than once in a short time the battery must be replaced.*

### 5.4 STATIC PORTS FAILURE

In case of static ports failure, the alternate static port in the cabin (shown below) must be activated.



- |                                |                               |
|--------------------------------|-------------------------------|
| 1. Cabin ventilation           | <i>OFF (hot and cold air)</i> |
| 2. ALTERNATE STATIC PORT VALVE | <i>OPEN</i>                   |
| 3. Continue the mission        |                               |

**Supplement G16: pages replacement instructions**

## **SECTION 4 – NORMAL PROCEDURES**

Apply following pages replacement procedure:

<b>Supplement G16 - NORMAL PROCEDURES page</b>		<b>Supplement S1 Section 4 page</b>
SMD4 – 6	<b>REPLACES</b>	Page S4–6 Supplement G01, Section 4

**WARNING**

*The altitude calculated by G950 GPS receivers is geometric height above Mean Sea Level and could vary significantly from the altitude displayed by pressure altimeters, such as the GDC 74A Air Data Computer, or other altimeters in aircraft. GPS altitude should never be used for vertical navigation. Always use pressure altitude displayed by the G950 PFD or other pressure altimeters in aircraft.*

**NOTE**

*If the pilot profile is changed during the flight, the HSI could not indicate the correct LOC or VOR indication until the pilot manually tunes the active frequency. Make sure that the displayed indication on the HSI indicator is consistent with the selected frequency.*

**NOTE**

*The data contained in the terrain and obstacle databases comes from government agencies. Garmin accurately processes and cross-validates the data, but cannot guarantee the accuracy and completeness of the data. Reference “Garmin G950 Pilot’s Guide for the Tecnam P2006T” (P/N 190-01146-XX), last issue, Appendix B concerning SD card use and databases.*

**NOTE**

*Use of polarized eyewear may cause the flight displays to appear dim or blank.*

**MD302 system use****WARNING**

*“The detailed description, operation and functionalities of MD302 Stand By Attitude Module are provided on MD302 Stand-By Attitude Module Pilot’s Guide” document P/N 9017846 rev.D, which is to be considered to be attached to this AFM and kept onboard the aircraft.*

Supplement G16: pages replacement instructions

## **SECTION 5 – PERFORMANCE**

Apply following instruction:

See Basic AFM - Section 5

Supplement G16: pages replacement instructions

## **SECTION 6 – WEIGHT AND BALANCE**

Apply following instruction:

See Basic AFM - Section 6

**Supplement G16: pages replacement instructions**

## **SECTION 7 – AIRFRAME AND SYSTEMS DESCRIPTION**

Apply following pages replacement procedure:

<b>Supplement G16 - AIRFRAME AND SYSTEM DESCRIPTION page</b>		<b>Basis AFM/Supplement S1 Section 7 page</b>
MD7 – 29	<b>REPLACES</b>	Page 7 – 29 of Basic AFM, Section 7
SMD7 – 37	<b>REPLACES</b>	Page 7 – 37 of Supplement S1, Section 7
SMD7 – 39	<b>REPLACES</b>	Page 7 – 39 of Supplement S1, Section 7

## 16. MD302 ALTERNATIVE STAND-BY INSTRUMENT

In order to improve the digital version cockpit layout of the P2006T in terms of human-machine interface, weight saving and reliability this backup instrument V.1.0.5 is installed.

For more details refer to MOD2006/212.



**WARNING**


*All MD302 Stand-by Attitude Module settings, set up during the aircraft delivery or after a maintenance activity, must not be modified.*




**WARNING**

*In case of replacement of MD302 Stand-by Attitude Module, verify proper software load and confirm that its software version number is compliance with that one showed above, before install it.*

## 17. INSTRUMENTS PANEL



GARMIN G950 IFDS - Instruments panel (typical layout)



GARMIN G950 IFDS - Instruments panel - layout with MD302 digital stand-by instrument(MOD2006/212)



Item	Description
31	RH Field
32	LH Cross bus switch
33	Master switch
34	RH Avionic switch
35	LH Field
36	LH Avionic switch
37	Standby Airspeed indicator
38	Chronometer
39	LG control knob
40	Voltammeter Indicator
41	ADF control panel
42	Cockpit light dimmer
43	Cabin heat (warm air from RH engine)
44	Avionics lights dimmer
45	Cabin heat (warm air from LH engine)
46	LH ram air inlet
47	Trim rudder indicator
48	Switches built-in lights dimmer
49	ELT Indicator
50	RH breakers panel
51	Pitch trim indicator
52	Pitot heat switch
53	A/P Master switch
54	A/P trim master switch
55	Fire Detector push-to-test
56	LH/RH Ammeter selector switch
57	Mid-Continent MD302 Stand-By Instrument

**Supplement G16: pages replacement instructions**

## **SECTION 8 – GROUND HANDLING & SERVICE**

Apply following instruction:

**See Basic AFM - Section 8**

INTENTIONALLY LEFT BLANK

## SUPPLEMENT NO. G17 - STORMSCOPE

### RECORD OF REVISIONS

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval Or Under DOA Privileges
			DO	OoA	HDO	
0	-	First issue	D. Ronca	C. Caruso	M. Oliva	DOA Approval
1	all	Page replacement and equipment list suppressed	A. Sabino	C. Caruso	M. Oliva	DOA Approval

### LOEP

	Pages	Revision
Cover pages	G17 – 1 thru 6	Rev. 1

## **INTRODUCTION**

This supplement contains supplemental information to operate, in a safe and efficient manner, the aircraft when equipped with WX500 Stormscope; this equipment refers to the following design change:

- MOD2006/216 – Stormscope installation

The information contained herein supplements or supersedes the basic Aircraft Flight Manual or the Supplement G1, as applicable.

## **SECTION 1 – GENERAL**

The following information supplements Section 1 of basic AFM and related supplements.

### **NOTE**

*The Stormscope does neither replace a weather radar nor weather information. The Stormscope is only used as an additional source of information beside approved weather information.*

## **SECTION 2 – LIMITATIONS**

See Section 2 of basic AFM and related supplements.

## **SECTION 3 – EMERGENCY PROCEDURES**

See Section 3 of basic AFM and related supplements.

## **SECTION 4 – NORMAL PROCEDURES**

See Section 4 of basic AFM and related supplements.

## **SECTION 5 – EMERGENCY PROCEDURES**

See Section 5 of basic AFM and related supplements.

## **SECTION 6 – WEIGHT AND BALANCE**

See Section 6 of basic AFM and related supplements.

## SECTION AIRFRAME AND SYSTEMS DESCRIPTION

The following information supplements Section 7 of basic AFM and related supplements.

### WX500 STORMSCOPE SYSTEM

The thunderstorm detection passive sensor WX500 Stormscope is fully operated and displayed via the Garmin G950 Multi function display, in the map menu. It is installed in order to show the lightning data.


The sensor maps discharge the electrical activity for 360 degrees around the aircraft to a distance of 200 nautical miles, in relation to the aircraft's *Stormscope* antenna. The estimated distance from the aircraft to the discharge point is reported in NM while the bearing represents the angle between the fore and aft axis of the antenna, which is in line with the longitudinal axis (nose) of the aircraft.

The WX-500 processor is installed in the right side of the baggage compartment while the NY-163 antenna is installed on the bottom side of the tail.

For more details see WX-500 Installation Manual and the latest revision of the Garmin G950 Pilot's guide Doc. No.: 190-00726-00.

### W D C

In the following figure the *Stormscope* wiring diagram is reported.



**Wiring diagram**

## **SECTION 8 – AIRCRAFT CARE AND MAINTENANCE**

See Section 8 of basic AFM and related supplements.



INTENTIONALLY LEFT BLANK

## SUPPLEMENT No. G19

### G1000 NXi, Increased MTOW, Increased $V_{LE}/V_{LO}$ and MD302

#### RECORD OF REVISIONS

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval or Under DOA Privileges
			DO	OoA	HDO	
0	-	Initial issue	A. Sabino	C. Caruso	M. Oliva	EASA Approval N° 10062361
1	S2-6,8,12,16	Suppressed, information reported in basic AFM	A. Sabino	C. Caruso	M. Oliva	DOA Approval
	S4-3,4,13,18,19,21,22,24,27	Oil T indication for MOD 2006/002 and Recommendations for governor check				

**LOEP**

	Pages	Revision
<b>Cover pages</b>	G19-1,2,7	Rev 1
	3 thru 6, 8 thru 20	Rev 0
<b>Section S2</b>	5,7, 13 thru 15, 21,22,29,30	Rev 0
<b>Section S3</b>	1 thru 62	Rev 0
<b>Section S4</b>	3,4,13,18,19,21,22,24,27	Rev 1
	1,2,5 thru 12,14 thru 17, 20, 23, 25,28 thru 38	Rev 0
<b>Section S5</b>	1 thru 22	Rev 0
<b>Section S7</b>	1, 2, 29 thru 42	Rev 0

## INTRODUCTION

This section contains supplemental information to operate, in a safe and efficient manner, the aircraft when equipped with the following design changes:

- Weight Increment (Design Change MOD2006/015)
- $V_{LE}$  and  $V_{LO}$  Increment (Design Change MOD2006/033)
- MD302 Alternative Stand-By Instrument (Design Change MOD2006/212)
- Garmin G1000 NXi Avionic Suite (Design Change MOD2006/271).

The information herein contained supplements or supersedes the basic Aircraft Flight Manual: detailed instructions are provided to allow the owner for replacing the AFM pages containing information amended as per the Design Change in subject.

**It is the owner's responsibility to replace the mentioned pages in the AFM in accordance with the instructions herein addressed section by section.**



*Garmin G1000 NXi Pilot's Guide for Tecnam P2006T (P/N 190-02286-00) – last issue – must be carried on board the airplane at all times.*



*MD302 Stand-By Attitude Module Pilot's Guide" document P/N 9017846 rev.D is to be considered to be attached to this AFM and kept onboard the aircraft.*

INTENTIONALLY LEFT BLANK

**Supplement G19: pages replacement instructions**

## SECTION 1 - GENERAL

**See Basic AFM - Section 1**

INTENTIONALLY LEFT BLANK

**Supplement G19: pages replacement instructions**

## SECTION 2 - LIMITATIONS

Apply following pages replacement procedure:

<b>Supplement G19 – LIMITATIONS page</b>		<b>Basic AFM Section 2 page</b>
S2-5	<b>REPLACES</b>	2-5
S2-7	<b>REPLACES</b>	2-7
S2-13	<b>REPLACES</b>	2-13
S2-14	<b>REPLACES</b>	2-14
S2-15	<b>REPLACES</b>	2-15
S2-21	<b>REPLACES</b>	2-21
S2-22	<b>REPLACES</b>	2-22
S2-29	<b>REPLACES</b>	2-29
S2-30	<b>REPLACES</b>	2-30



INTENTIONALLY LEFT BLANK

## 2. SPEED LIMITATIONS

The following table addresses the airspeed limitations and their operational significance:

SPEED			KIAS	KCAS	REMARKS
V <sub>NE</sub>	Never exceed speed		171	172	Do not exceed this speed in any operation.
V <sub>NO</sub>	Maximum Structural Cruising Speed		138	136	Do not exceed this speed except in smooth air, and only with caution.
V <sub>A</sub>	Design Manoeuvring speed		122	119	Do not make full or abrupt control movement above this speed, because under certain conditions the aircraft may be overstressed by full control movement.
V <sub>O</sub>	Operating Manoeuvring speed				
V <sub>LE</sub>	Maximum Landing Gear extended speed		122	119	Do not exceed this speed with the landing gear extended.
V <sub>LO</sub>	Maximum Landing Gear operating speed		122	119	Do not exceed this speed when operating the landing gear.
V <sub>FE</sub>	Maximum flaps extended speed	<i><b>FULL</b></i>	93	93	Do not exceed this speed for indicated flaps setting.
		<i><b>T.O.</b></i>	122	119	
V <sub>MC</sub>	Aircraft minimum control speed with one engine inoperative		62	62	Do not reduce speed below this value in event of one engine inoperative condition.

### 3. AIRSPEED INDICATOR MARKINGS

The Airspeed Indicator displays airspeed on a rolling number gauge using a moving tape.

The airspeed is displayed inside the black pointer. The pointer remains black until reaching never-exceed speed ( $V_{NE}$ ), at which point it turns red.

Airspeed indicator markings and their colour code are explained in the following table.

MARKING	KIAS	EXPLANATION
White band	<b>54-93</b>	Lower limit is $V_{SO}$ , upper limit is the maximum allowable speed with flaps extended in <i>FULL</i> position.
Red line	<b>62</b>	Minimum aircraft control speed with one engine inoperative and flaps set to T.O.
Green band	<b>66-138</b>	Normal aircraft operating range (lower limit is $V_{SI}$ , stall speed in “clean” configuration, and upper limit is the maximum structural cruise speed $V_{NO}$ ).
Blue line	<b>84</b>	Best rate-of-climb speed with one engine inoperative.
Yellow band	<b>138-171</b>	Speed range where manoeuvres must be conducted with caution and only in smooth air.
Red line	<b>171</b>	Maximum speed for all operations.

## 13. WARNINGS, CAUTIONS AND ADVISORIES LIGHTS

Following table addresses the warning and caution alerts and safe operating annunciations shown (unless differently specified) on the Annunciation Window:

Warning alert (RED)	Cause
L BUS VOLT HIGH	LH electric system overvoltage
R BUS VOLT HIGH	RH electric system overvoltage
L COOLANT LOW	Left engine - coolant liquid low level
L COOLANT LOW	Right engine - coolant liquid low level
PILOT DR OPEN	Main door open and/or unlocked
REAR DR OPEN	Rear door open and/or unlocked
LH ENGINE FIRE	Left engine compartment: fire detected
RH ENGINE FIRE	Right engine compartment: fire detected
LG TRANSITION	One or more legs are in transition phase and/or the selected retracted/extended position is not yet reached
Caution alert (AMBER)	Cause
L ALT FAIL	LH generator failure
R ALT FAIL	RH generator failure
PITOT HEAT	Pitot heating system failure/not activated
EXT POWER ON	External electrical supply connected
GEAR PUMP ON	LG pump electrically supplied
Safe operating annunciation (GREEN)	Indication
L FUEL PUMP ON	Left engine - electrical fuel pump ON
R FUEL PUMP ON	Right engine - electrical fuel pump ON
PITOT HEAT ON	Pitot heating system ON
LG Down & Locked	Landing gear extended and locked

Aural means are provided by Garmin G1000 NXi: a repeating tone is associated to the warning alerts and a single chime is associated to the caution alerts. Safe operating annunciations do not have any aural chime generated.

Make reference to Garmin G1000 NXi Pilot's Guide for P2006T (P/N 190-02286-00), last issue.

## 14 WEIGHTS

Condition	Weight	
Maximum takeoff weight	1230 kg	2712 lb
Maximum landing weight	1230 kg	2712 lb
Maximum zero wing fuel weight	1195 kg	2635 lb

**NOTE**

*Refer to Para. 21.4 of this AFM Section for baggage loading limitations.*

## 21. LIMITATIONS PLACARDS

Hereinafter the placards, related to the operating limitations and installed on **P2006T**, are reported.

### 21.1. SPEED LIMITATIONS

On the left side instrument panel, the following placards reporting the speed limitations are placed:

Operating Manoeuvring speed  
 **$V_o = 122\text{KIAS}$**

Maximum L.G. op. speed  
 **$V_{LO} / V_{LE} = 122\text{KIAS}$**

## 21.2. OPERATING LIMITATIONS

On the instrument panel, it is placed the following placard reminding the observance of aircraft operating limitations; make reference to Para. 22 for the list of equipment required on board to allow flight operations in VFR Day, VFR Night, IFR Day and IFR Night conditions.

This A/C can be operated only in normal category DAY-NIGHT-VFR-IFR (with required equipment) in non-icing conditions. All aerobatics manoeuvres including spinning are prohibited. For operational limitations refer to FLIGHT MANUAL



## 22. KINDS OF OPERATIONS EQUIPMENT LIST

This paragraph reports the KOEL table, concerning the equipment list required on board under CS-23 regulations to allow flight operations in VFR Day, VFR Night, IFR Day and IFR Night conditions.

Flight in VFR Day and Night, IFR Day and Night is permitted only if the prescribed equipment is installed and operational.

Additional equipment, or a different equipment list, for the intended operation may be required by national operational requirements and also depends on the route to be flown.

Equipment	VFR Day	VFR Night	IFR Day	IFR Night
Magnetic compass	•	•	•	•
GDU 1050 - Display Unit (2)	•	•	•	•
GIA 63W - Integrated Avionics Unit (2)	•	•	•	•
GDC 72 - Air Data Computer	•	•	•	•
GTP 59 - OAT sensor	•	•	•	•
GRS 79 - AHRS	•	•	•	•
GMU 44 - Magnetometer	•	•	•	•
GMA 1347 - Audio panel / MKR Receiver	•	•	•	•
GTX 345R - Transponder	•	•	•	•
MD-302 - Standby Attitude Module	•	•	•	•
Pitot heating system	•	•	•	•
Breakers panels	•	•	•	•
First Aid kit	•	•	•	•
Fire extinguisher	•	•	•	•
Fire detectors (2)	•	•	•	•
Position lights	•	•	•	•
Landing light	•	•	•	•
Taxi light	•	•	•	•
Strobe lights	•	•	•	•
Torch		•	•	•
Cabin light		•	•	•
Panel lights		•	•	•
Map lights		•	•	•
Cockpit lights		•	•	•
Emergency light	•	•	•	•
Volt-Ammeter	•	•	•	•
ELT	•	•	•	•
Alternate static source	•	•	•	•
Stall warning system	•	•	•	•
KN63 - DME			•	•
	VFR Day	VFR Night	IFR Day	IFR Night

**Supplement G19: pages replacement instructions**

## SECTION 3 - EMERGENCY PROCEDURES

**Supplement G19 Section 3 – EMERGENCY PROCEDURES  
replaces Basic AFM Section 3 as a whole**

INTENTIONALLY LEFT IN BLANK

**SECTION 3 – EMERGENCY PROCEDURES****INDEX**

1.	INTRODUCTION .....	3
1.1.	Engine failure during takeoff run .....	3
2.	AIRPLANE ALERTS .....	6
2.1	Single alternator failure / overvoltage .....	7
2.2	Both alternators failure.....	8
2.3	Both alternators overvoltage.....	9
2.4	Failed door closure .....	10
2.5	Pitot heating system failure.....	11
2.6	Coolant liquid low level.....	12
2.7	Gear Pump failure .....	13
2.8	Engine fire .....	14
2.9	Loss of information displayed.....	15
2.10	Loss of airspeed information .....	15
2.10	Loss of attitude information .....	16
2.11	Loss of altitude information.....	16
2.12	Loss of vertical speed information .....	17
2.13	Loss of heading information .....	17
2.14	Display failure .....	19
3.	ENGINE SECURING .....	21
4.	POWERPLANT EMERGENCIES .....	23
4.1	Propeller overspeeding .....	23
4.2	CHT limit exceedance.....	24
4.3	Oil temperature limit exceedance .....	25
4.4	Oil pressure limits exceedance .....	26
4.5	Low fuel pressure.....	27
5.	OTHER EMERGENCIES.....	29
5.1	Emergency descent .....	29
5.2	Total electrical failure .....	29
5.3	Static ports failure .....	30
5.4	Unintentional flight into icing conditions .....	31
5.5	Carburettor icing.....	32
5.6	Flaps control failure .....	33
6	ONE ENGINE INOPERATIVE PROCEDURES .....	34
6.1	Characteristic airspeeds with one engine inoperative .....	35
6.2	Inflight engine restart .....	36
6.3	Engine failure during takeoff run .....	37
6.4	Engine failure during climb .....	39
6.5	Engine failure in flight.....	40

6.6	One engine inoperative landing .....	41
7	LANDING GEAR SYSTEM FAILURES .....	42
7.1	Emergency landing gear extension .....	42
7.2	Complete Gear up or nose gear up landing .....	43
7.3	Partial Main LG extension .....	45
7.4	Failed retraction.....	47
7.5	Unintentional landing gear extension.....	47
8	SMOKE AND FIRE OCCURRENCE.....	49
8.1	Engine fire on the ground.....	49
8.2	Engine fire during takeoff run .....	50
8.3	Engine fire in flight .....	52
8.4	Electrical smoke in cabin on the ground .....	52
8.5	Electrical smoke in cabin during flight.....	53
9	UNINTENTIONAL SPIN RECOVERY.....	55
10	LANDING EMERGENCIES .....	56
10.1	Landing without engine power .....	56
10.2	Landing with Nose landing gear tire deflated .....	58
10.3	Landing with a known main landing gear tire deflated .....	59
10.4	Landing without brakes .....	60
11	AIRCRAFT EVACUATION.....	61
12	DITCHING .....	62

## 1. INTRODUCTION

Section 3 includes checklists and detailed procedures for coping with various types of emergency conditions that could arise after a system failure.

Before operating the aircraft, the pilot should become thoroughly familiar with this manual and, in particular, with this Section. Further on a continued and appropriate training and self study should be done.

Two types of emergency procedures are hereby given.

- a. “BOLD FACES” which must be known by heart by the pilot and executed, in the correct and complete sequence, immediately after the failure is detected and confirmed.

These procedures characters are boxed and highlighted:

### 1.1. ENGINE FAILURE DURING TAKEOFF RUN

#### **BEFORE ROTATION: ABORT TAKE OFF**

- |    |                       |                                    |
|----|-----------------------|------------------------------------|
| 1. | <b>Throttle Lever</b> | <b><i>BOTH IDLE</i></b>            |
| 2. | <b>Rudder</b>         | <b><i>Keep heading control</i></b> |
| 3. | --                    |                                    |
| 4. | --                    |                                    |

- b. “other procedures” which should be well theoretically known and mastered, but that can be executed entering and following step by step the AFM current section appropriate checklist.

Additionally operating the aircraft, the pilot should become thoroughly familiar with the Garmin G1000 NXI Pilot’s Guide for Tecnam P2006T(P/N 190-02286-00) – last issue - and, in particular, with the present AFM Section.



**CAUTION**

*Garmin G1000 NXI Pilot’s Guide for Tecnam P2006T (P/N 190-02286-00) – last issue - must be carried onboard the airplane at all times.*



*Garmin G1000 NXI has a very high degree of functional integrity. However, the pilot must recognize that providing monitoring and/or self-test capability for all conceivable system failures is not practical. Although unlikely, it may be possible for erroneous operation to occur without a fault indication shown by the G1000 NXI. It is thus the responsibility of the pilot to detect such an occurrence by means of crosschecking with all redundant or correlated information available in the cockpit.*

***In any case, as a failure or abnormal behaviour is detected pilots should act as follows:***

1. *Keep self-control and maintain aircraft flight attitude and parameters*
2. *Analyse the situation identifying, if required, the area for a possible emergency landing*
3. *Apply the pertinent procedure*
4. *Inform the Air Traffic Control as applicable*

**NOTE**

*For the safe conduct of later flights, any anomaly and/or failure must be communicated to the National Authorities in charge, in order to put the aircraft in a fully operational and safe condition.*

**NOTE**

*In this Chapter, following definitions apply:*

***Land as soon as possible:*** land without delay at the nearest suitable area at which a safe approach and landing is assured.

***Land as soon as practical:*** land at the nearest approved landing area where suitable repairs can be made.



INTENTIONALLY LEFT BLANK

## 2. AIRPLANE ALERTS

Annunciation Window, located to the right of the Altimeter and Vertical Speed Indicator, supplies 16 alerts for warnings and cautions along with safe operating annunciations. The colours are as follows:

<b><u>GREEN:</u></b>	to indicate that pertinent device is turned ON
<b><u>AMBER:</u></b>	to indicate no-hazard situations which have to be considered and which require a proper crew action
<b><u>RED:</u></b>	to indicate emergency conditions

**Warning** alert text is shown in red in the Annunciation Window and is accompanied by a continuous chime and a flashing WARNING Softkey annunciation. Selecting the WARNING Softkey acknowledges the presence of the warning alert and stops the aural chime.

**Caution** alert text is shown in yellow in the Annunciation Window and is accompanied by a single chime and a flashing CAUTION Softkey annunciation. Selecting the CAUTION Softkey acknowledges the presence of the caution alert. Caution voice alerts repeat three times or until acknowledged by selecting the CAUTION Softkey.

All aircraft annunciations can be displayed simultaneously in the Annunciation Window. A white horizontal line separates annunciations that are acknowledged from annunciations that are not yet acknowledged. Higher priority annunciations are displayed towards the top of the window.

In order to give a short description about the airplane alerts, text messages are displayed on the Alerts Window: pressing the ALERTS Softkey displays the Alerts Window, pressing the ALERTS Softkey a second time removes the Alerts Window from the display. When the Alerts Window is displayed, the FMS knob can be used to scroll through the alert message list.

## 2.1 SINGLE ALTERNATOR FAILURE / OVERVOLTAGE

Annunciation window	Alert window
<b>L ALT FAIL</b>	Lh Alternator
<b>OR</b>	
<b>R ALT FAIL</b>	Rh Alternator

1. FIELD LH (or RH) OFF
2. FIELD LH (or RH) ON

**If the LH (or RH) ALT caution stays displayed**

3. FIELD LH (or RH) OFF
4. Avionic LH OFF
5. ADF (if installed) OFF

**NOTE**

*Switching OFF avionic LH and ADF (if installed) will permit to shed non-essential electrical power.*

*The battery and a single generator are able to supply the electrical power necessary for flight, but redundancy is lost.*

**If conditions permit:****NOTE**

*Switching CROSS BUS OFF will further reduce alternator load; the decision mainly depends on weather conditions.*

6. CROSS BUS LH (or RH) OFF

Equipment will be lost accordingly to the following table:

LH Gen Bus	LH Avionic Bus	RH Avionic Bus	RH Gen Bus
Pitot Heat	DME	ADF (if installed)	NAV Lights
Landing Light	Transponder	COM 2	Rudder Trim
Taxi Light	A/P	NAV 2	Stall Warning
	A/P Pitch Trim	MFD	
		AHRS/ADC*	

\* AHRS /ADC are fed from battery bus if Mod 2006/135 is embodied

7. Land as soon as practicable

## 2.2 BOTH ALTERNATORS FAILURE

Annunciation window	Alert window
<b>L ALT FAIL</b>	Lh Alternator
<b>R ALT FAIL</b>	Rh Alternator

In event of both L and R ALT FAIL caution alerts displayed:

1. FIELD LH and RH *BOTH OFF*
2. FIELD LH and RH *BOTH ON*

**If the LH (or RH) ALT caution stays displayed**

1. Verify good ammeter indications on restored alternator
2. Refer to Single alternator failure / overvoltage drill (Para 2.1)

**If both LH and RH ALT cautions stay displayed**

3. FIELD LH and RH *BOTH OFF*
4. CROSS BUS LH and RH *BOTH OFF*

**If engine starting battery modification is applied**

5. EMERG BATT switch *ON*
6. Land as soon as possible.

**If engine starting battery modification is not applied**

5. Land as soon as possible.

Equipment will be lost accordingly to the following table:

LH Gen Bus	LH Avionic Bus	RH Avionic Bus	RH Gen Bus
Pitot Heat	DME	ADF (if installed)	NAV Lights
Landing Light	Transponder	COM 2	Rudder Trim
Taxi Light	A/P	NAV 2	Stall Warning
	A/P Pitch Trim	MFD	
		AHRS/ADC*	

*AHRS/ADC are fed from battery bus if Mod 2006/135 is embodied*

**NOTE**

*The battery can supply electrical power for at least 30 minutes.*

## 2.3 BOTH ALTERNATORS OVERVOLTAGE

Annunciation window	Alert window
<b>L BUS VOLT HIGH</b>	Lh overvoltage
<b>R BUS VOLT HIGH</b>	Rh overvoltage

In event of both L and R BUS VOLT HIGH warning alerts displayed:

1. FIELD LH and RH *BOTH OFF*
2. FIELD LH and RH *BOTH ON (one at a time)*

**If the LH (or RH) BUS VOLT HIGH warning is still displayed**

3. Verify good ammeter indications on restored alternator
4. Refer to Single alternator failure / overvoltage drill (Para 2.1)

**If both LH and RH BUS VOLT HIGH warning are still displayed**

3. CROSS BUS LH and RH *BOTH OFF*
4. FIELD LH and RH *BOTH OFF*
5. FIELD LH and RH *BOTH ON (one at a time)*

**If LH (or RH) BUS VOLT HIGH warning is still displayed**

6. Verify good ammeter indications on restored alternator
7. Switch CROSS BUS on the restored alternator side
8. Refer to Single alternator failure / overvoltage drill (Para 2.1)

**If both LH and RH BUS VOLT HIGH warning are still displayed**

6. FIELD LH and RH *BOTH OFF*

**If engine starting battery modification is applied**

7. EMERG BATT switch *ON*
8. **Land as soon as possible.**

**If engine starting battery modification is not applied**

7. **Land as soon as possible**

Equipment will be lost accordingly to the following table:

LH Gen Bus	LH Avionic Bus	RH Avionic Bus	RH Gen Bus
Pitot Heat	DME	ADF (if installed)	NAV Lights
Landing Light	Transponder	COM 2	Rudder Trim
Taxi Light	A/P	NAV 2	Stall Warning
	A/P Pitch Trim	MFD	
		AHRS/ADC*	

*AHRS /ADC are fed from battery bus if Mod 2006/135 is embodied*

**NOTE**

*The battery can supply electrical power for at least 30 minutes.*

## 2.4 FAILED DOOR CLOSURE

Annunciation window	Alert window
<b>PILOT DR OPEN</b>	Main door open
<b>OR</b>	
<b>REAR DR OPEN</b>	Rear door open

In case of door opening / unlocking, related PILOT or REAR DR OPEN alert is displayed. In this case, apply following procedure:

**ON THE GROUND**

1. Passengers and crew seat belts      *Fasten and tighten*
2. Affected door      *Verify correctly closed*

**If door is open**

3. Relevant engine      *Shut down*
4. Affected door      *Close and check*

**If door is closed**

3. Locking device      *Check*

**If down in unlocked position**

4. Abort mission.

**IN FLIGHT**

1. Passengers and crew seat belts      *Fasten and tighten*
2. Affected door and locked device      *Verify correctly closed*

**If door is open or locking device is unlocked**

3. Land as soon as possible

## 2.5 PITOT HEATING SYSTEM FAILURE

Annunciation window	Alert window
<b>PITOT HEAT ON</b>  <b>PITOT HEAT</b>	Pitot heat
	Pitot heat

When the Pitot Heating system is activated, the green PITOT HEAT advisory light is turned ON.

If the amber PITOT HEAT caution light turns OFF, then the Pitot Heating system is functioning properly. Anytime the amber PITOT HEAT caution light is ON at the same time the green PITOT HEAT light is ON, then the Pitot Heating system is not functioning properly.

1. Pitot heat switch *OFF*
2. Verify Pitot Heating circuit breaker is IN
3. Pitot heat switch *ON*
4. Check PITOT HEAT caution light:

If the amber light stays ON, assume a failure in the pitot heating system.  
Avoid visible moisture and OATs below 10 deg C.

## 2.6 COOLANT LIQUID LOW LEVEL

Annunciation window	Alert window
<b>L COOLANT LOW</b>	Lh Low Coolant
OR	
<b>R COOLANT LOW</b>	Rh Low Coolant

When the engine coolant liquid level goes under the lower limit, the related L or R COOLANT LOW warning alert is displayed. Low coolant level condition may lead to high CHT/CT. When the warning is displayed, apply following procedure:

1. Check affected engine CHT/CT

**If CHT is above 135°C or CT is above 120°C**

2. Affected engine *Reduce power setting to reduce CHT/CT up to the minimum practical*
3. **Land as soon as practical**

**If CH/CT continues to rise and engine shows roughness or power loss**

4. Affected engine *SECURE (securing procedure on Para. 4)*
5. **Land as soon as possible** applying *one engine inoperative landing procedure*. See Para. 6.6



## 2.7 GEAR PUMP FAILURE

Annunciation window	Alert window
<b>GEAR PUMP ON</b>	Gear powered

The GEAR PUMP ON caution light turns ON when the landing gear hydraulic pump is electrically supplied.

After the landing gear retraction, if the red TRANS light turns OFF and the GEAR PUMP ON caution stays turned ON, this could indicate a gear pump relay failure to ON.

**If TRANS light is OFF**

1. Continue the mission monitoring the caution light.

**If TRANS light is ON**

2. Landing gear is not locked in UP position

**NOTE**

*The electrical gear pump, continuously supplied, causes a current absorption which does not affect the mission unless this failure is coupled with the overall electrical failure. In this case, the residual battery endurance may be consistently lower than 30 minutes.*

## 2.8 ENGINE FIRE

Annunciation window	Alert window
<b>LH ENGINE FIRE</b>	Left engine fire detected
OR	
<b>RH ENGINE FIRE</b>	Right engine fire detected

In event of engine fire, the LH or RH ENGINE FIRE warning alert is displayed.  
Refer to following procedures:

FIRE ON THE GROUND:	see Para. 8.1
FIRE DURING TAKEOFF RUN:	see Para. 8.2
FIRE IN FLIGHT:	see Para. 8.3


## 2.9 LOSS OF INFORMATION DISPLAYED

When a LRU or a LRU function fails, a large red 'X' is typically displayed on the display field associated with the failed data.

### NOTE


*In most of cases, the red "X" annunciation is accompanied by a message advisory alert issuing a flashing ADVISORY Softkey annunciation which, once selected, acknowledges the presence of the message advisory alert and displays the alert text message in the Alerts Window. Refer to G1000 NXI Pilot's Guide for Tecnam P2006T (P/N 190-02286-00), last issue, Appendix A, Message Advisories list.*

## 2.10 LOSS OF AIRSPEED INFORMATION

	<p align="center"><b>AIRSPEED FAIL</b> (RED X ON DISPLAY FIELD)</p>
	<p align="center">Display system is not receiving airspeed input from the Air Data Computer.</p>


**INSTRUCTION:** revert to standby airspeed indicator

## 2.11 LOSS OF ATTITUDE INFORMATION

	<p style="text-align: center;"><b>ATTITUDE FAIL</b> (RED X ON DISPLAY FIELD)</p> <hr/> <p>Display system is not receiving attitude information from the AHRS.</p>
---	---


**INSTRUCTION:** revert to standby attitude indicator

## 2.12 LOSS OF ALTITUDE INFORMATION

	<p style="text-align: center;"><b>ALTITUDE FAIL</b> (RED X ON DISPLAY FIELD)</p> <hr/> <p>Display system is not receiving altitude input from the Air Data Computer.</p>
--	--


**INSTRUCTION:** revert to standby altitude indicator

## 2.13 LOSS OF VERTICAL SPEED INFORMATION

	<p align="center"><b>VERT SPEED FAIL</b> (RED X ON DISPLAY FIELD)</p>
	<p align="center">Display system is not receiving vertical speed input from the Air Data Computer.</p>

**INSTRUCTION:** determine vertical speed on the basis of altitude information

## 2.14 LOSS OF HEADING INFORMATION

	<p align="center"><b>HDG</b> (RED X ON DISPLAY FIELD)</p>
	<p align="center">Display system is not receiving valid heading input from AHRS.</p>

**INSTRUCTION:** revert to magnetic compass

INTENTIONALLY LEFT BLANK

## 2.15 DISPLAY FAILURE

In the event of a display failure, the G1000 NXi System automatically switches to reversionary (backup) mode. In reversionary mode, all important flight information is presented on the remaining display in the same format as in normal operating mode. The change to backup paths is completely automated for all LRUs and no pilot action is required.

### **if the system fails to detect a display problem**

1. DISPLAY BACKUP button

*PUSH*



*If a display fails, the related Integrated Avionics Unit (IAU) is cut off and can no longer communicate with the remaining display: consequently the NAV and COM functions provided to the failed display by the Integrated Avionics Unit are flagged as invalid on the remaining display.*

INTENTIONALLY LEFT BLANK



**3. ENGINE SECURING**

Following procedure is applicable to shut-down one engine in flight:

- |                                |                        |
|--------------------------------|------------------------|
| 1. <b>Throttle Lever</b>       | <b><i>IDLE</i></b>     |
| 2. <b>Ignition</b>             | <b><i>BOTH OFF</i></b> |
| 3. <b>Propeller Lever</b>      | <b><i>FEATHER</i></b>  |
| 4. <b>Fuel Selector</b>        | <b><i>OFF</i></b>      |
| 5. <b>Electrical fuel pump</b> | <b><i>OFF</i></b>      |

After securing engine(s), after analysing situation, refer immediately to following procedures:

ENGINE FAILURE IN FLIGHT:	see Para. 6.5
SINGLE GENERATOR FAILURE:	see Para. 2.1
or BOTH GENERATOR FAILURE:	see Para. 2.2
INFLIGHT ENGINE RESTART:	see Para. 6.2
ONE ENGINE INOPERATIVE LANDING:	see Para. 6.6
or LANDING WITHOUT ENGINE POWER:	see Para. 10.1

INTENTIONALLY LEFT BLANK

## 4. POWERPLANT EMERGENCIES

### 4.1 PROPELLER OVERSPEEDING

The aircraft is fitted with propeller/governor set by MT-Propeller such a way that the maximum propeller rpm exceedance is prevented. In case of propeller overspeeding in flight, apply following procedure:

- |                    |   |
|--------------------|---|
| 1. Throttle Lever  | <i>REDUCE power to minimum practical</i>              |
| 2. Propeller Lever | <i>REDUCE as practical (<u>not in feathering</u>)</i> |
| 3. RPM indicator   | <i>CHECK</i>  |

If it is not possible to decrease propeller rpm, apply *engine securing procedure* (see Para. 3) and **land as soon as possible** applying *one engine inoperative landing procedure* (See Para. 6.6).



*Maximum propeller rpm exceedance may cause the engine components damage. Propeller and engine shall be inspected in accordance with related Operators Manuals.*

#### 4.2 CHT LIMIT EXCEEDANCE

If CHT/CT exceeds its limit, apply following procedure:

1. Check affected engine CHT/CT

**If CHT is above 135°C or CT is above 120°C**

2. Affected engine *Reduce power setting to reduce CHT/CT up to the minimum practical*
3. **Land as soon as practical**

**If CHT/CT continues to rise and engine shows roughness or power loss**

4. Affected engine *SECURE (securing procedure on Para. 3)*
5. **Land as soon as possible** applying one engine inoperative landing procedure. See Para. 6.6

## 4.3 OIL TEMPERATURE LIMIT EXCEEDANCE

If oil temperature exceeds maximum limit (130°C):

1. OIL PRESS *CHECK*

**If oil pressure is within limits**

2. Affected engine *Reduce power setting to minimum applicable*
3. Affected engine *Keep propeller speed higher than 2000 RPM*

**If oil pressure does not decrease**

4. Airspeed *INCREASE*

**NOTE**

*If oil temperature does not come back within limits, the thermostatic valve, regulating the oil flow to the heat exchangers, could be damaged or an oil leakage can be present in the oil supply line.*

5. **Land as soon as practical** keeping the affected engine to the minimum necessary power
6. Monitor OIL PRESS and CHT/CT

**if engine roughness / vibrations or erratic behaviour is detected:**

7. Affected engine *SECURE (engine securing procedure on Para. 3)*
8. **Land as soon as possible** applying one engine inoperative landing procedure. See Para. 6.6



*Excessive oil pressure drop leads to a high pitch propeller configuration with consequent propeller feathering and engine stopping.*

## 4.4 OIL PRESSURE LIMITS EXCEEDANCE

If oil pressure exceeds its lower or upper limit (0.8 – 7 bar), apply following procedure:



*Excessive oil pressure drop leads to a high pitch propeller configuration with consequent propeller feathering and engine stopping.*

**NOTE**

*An excessive oil pressure value can be counteracted by decreasing propeller rpm.*

1. OIL PRESS *CHECK***If oil pressure exceeds upper limit (7 bar)**

2. Throttle Lever *first REDUCE affected engine power by 10%*
3. Propeller Lever *Keep low rpm*
4. OIL PRESS *CHECK (verify if came back within the limits)*
5. **Land as soon as practical**

**If oil pressure is under the lower limit (0.8 bar)**

2. **Land as soon as practical**

**If oil pressure is continuously decreasing**

3. **Affected engine** *SECURE (see engine securing procedure on Para. 3)*
4. **Land as soon as possible** applying one engine inoperative landing procedure.  
See Para. 6.6

#### 4.5 LOW FUEL PRESSURE

If fuel pressure decreases below the lower limit (2.2 psi), apply following procedure:

- |                     |                |
|---------------------|----------------|
| 1. Fuel press       | <i>CHECK</i>   |
| 2. Fuel quantity    | <i>CHECK</i>   |
| 3. Fuel consumption | <i>MONITOR</i> |

**If a fuel leakage is deemed likely**

5. **Land as soon as possible.**

**If a fuel leakage can be excluded:**

- |   |           |
|---|-----------|
| 4. Electrical fuel pump   | <i>ON</i> |
| 5. Feed the affected engine by means of opposite side fuel tank |           |

**If pressure does not come back within the limits**

6. **Land as soon as practical**

INTENTIONALLY LEFT BLANK



## 5. OTHER EMERGENCIES

### 5.1 EMERGENCY DESCENT



CAUTION

*Descent with airspeed at V<sub>LE</sub>, idle power and gear down will provide high descent rates and pitch attitudes up to -15°.*

*Anticipate altitude capture and return to level flight during emergency descent in order to assure a safe and smooth recovery from maneuver.*

- |                 |  |
|-----------------|--|
| 1. Power levers | <i>IDLE</i>                                |
| 2. Flaps        | <i>UP</i>                                  |
| 3. IAS          | <i>below V<sub>LO</sub>/V<sub>LE</sub></i> |
| 4. Landing gear | <i>DOWN</i>                                |
| 5. Airspeed     | <i>Up to V<sub>LE</sub></i>                |

### 5.2 TOTAL ELECTRICAL FAILURE

In case of electrical system overall failure, apply following procedure:

- |                    |                        |
|--------------------|------------------------|
| 1. Emergency light | <i>ON if necessary</i> |
| 2. MASTER SWITCH   | <i>OFF</i>             |
| 3. FIELD LH and RH | <i>BOTH OFF</i>        |
| 4. MASTER SWITCH   | <i>ON</i>              |
| 5. FIELD LH and RH | <i>BOTH ON</i>         |

#### **If failure persists**

- |  |   |
|--|---|
| 9. EMERG BATT switch   | ON (if engine starting battery installed) |
| 10. <b>Land as soon as possible</b> applying <i>emergency landing gear extension procedure</i> (see Para. 7.1) |   |

**WARNING**

*An electrical system overall failure prevents flaps operation: landing distance without flaps increases of about 25%.*

**CAUTION**

*A fully charged battery can supply electrical power for at least 30 minutes.*

## 5.3 MD 302 BATTERY FAILURE



*The MD302 internal battery will recharge itself from aircraft power while in normal mode. A battery capacity check occurs each time the unit is powered on. If the battery capacity is determined to be less than 80%, there will be a battery pack warning. If the warning persists more than once in a short time the battery must be replaced.*

## 5.4 STATIC PORTS FAILURE

In case of static ports failure, the alternate static port in the cabin (shown below) must be activated.



- |                                |                               |
|--------------------------------|-------------------------------|
| 1. Cabin ventilation           | <i>OFF (hot and cold air)</i> |
| 2. ALTERNATE STATIC PORT VALVE | <i>OPEN</i>                   |
| 3. Continue the mission        |                               |

#### 5.4 UNINTENTIONAL FLIGHT INTO ICING CONDITIONS

1. Carburettor heat *BOTH ON*
2. Pitot heat *ON*
3. Fly as soon as practical toward a zone clear of visible moisture, precipitation and with higher temperature, changing altitude and/or direction.
4. Control surfaces *Move continuously to avoid locking*
5. Propellers rpm *INCREASE to prevent ice build-up on the blades*

**WARNING**

*In event of ice build-up in correspondence of wing leading edges, stall speed increases.*

**WARNING**

*Ice build-up on wing, tail fin or flight control surfaces unexpected sudden roll and/or pitch tendencies can be experienced and may lead to unusual attitude and loss of aircraft control.*

**WARNING**

*Do not use Autopilot when icing formation is suspected or detected.*

## 5.5 CARBURETTOR ICING

### **DURING TAKEOFF**

The carburettor icing in “full throttle” mode is unlikely.

Take off in known or suspected icing formation is forbidden; in order to dispose of full engine take off power, take-off must be performed with carburettor heating OFF.

### **IN FLIGHT**

Carburettor icing is considered probable when external air temperature is below 15° C and visible air moisture (clouds, mist, haze or fog) or atmospheric precipitation are present.

Generally, an OAT-to-dew point temperature spread lower than 10°C and OAT less than 15°C with visibility lower than 5 km is a positive indication of likely icing formation condition.

Should an inadvertent flight into known or forecast icing condition happen carburettor heating should be selected “ON” as soon as possible: the greater the advance carburettors are warmed the better the chances not to form ice and avoid engine power loss or reduction.

Keep Carb Heating “ON” until engine power is restored and area of possible icing condition is exited.



**CAUTION**

*Carburettor Heating selected to “ON” will cause engine RPM reduction of about 100 RPM causing a sensible available engine power decrease.*

## 5.6 FLAPS CONTROL FAILURE

### DURING TAKEOFF



CAUTION

*Flap UP take off, requires a T/O distance (50 ft height obstacle distance) increased by about 20%.*

1. Airspeed *Keep below 93 KIAS*
2. **Land as soon as practical**

### DURING APPROACH/LANDING



CAUTION

*If the flaps control fails, consider the higher stall speed (see Section 5, Para. 6, "Stall Speed") and an increased landing distance of about 25%.*

1. Airspeed *Keep over 75 KIAS*
2. **Land as soon as practical** on a runway of appropriate length

## 6 ONE ENGINE INOPERATIVE PROCEDURES

**CAUTION**

*The ineffectiveness of one engine results in asymmetric traction which tends to yaw and bank the aircraft towards the inoperative engine. In this condition it is essential to maintain the direction of flight compensating the lower traction and counteracting the yawing effects by mean of rudder pedals. To improve directional control, it is advisable to bank the aircraft of about  $5^\circ$  to the side of the operating engine.*

*In addition, reduced available overall power and extended control surfaces will lead to a performances drop: a quick pitch attitude reduction will allow to keep a minimum safety airspeed.*

*The higher is the airspeed the better will be lateral and directional control efficiency: never allow airspeed to drop below  $V_{MCA}$ .*

**CAUTION**

*Best residual climb performances in OEI (One Engine Inoperative) condition have been recorded in Flap Up configuration and at  $V_{YSE}$ , which is marked as a Blue Line on the Airspeed indicator (calculated for maximum Take Off Weight and Sea, Level ISA condition) For actual condition  $V_{YSE}$  refer to Section 5 Para. 13, "One engine rate of climb".*

*$V_{XSE}$  is actually very close to  $V_{YSE}$  in any condition, thus best climb performance will also be associated with best climb angle (gradient) performance. Refer to Section 5 Para. 14, One-Engine Rate of Climb at  $V_{XSE}$ , for relevant data.*

## 6.1 CHARACTERISTIC AIRSPEEDS WITH ONE ENGINE INOPERATIVE

In case of one engine inoperative condition (OEI), pilot shall take into account the airspeeds shown below:

Conditions	Speed (KIAS)	
Minimum aircraft control speed with one engine inoperative and flaps set to T.O. ( $V_{MC}$ )	62	
Best rate-of-climb speed OEI ( $V_{YSE}$ )	MTOW 1180 kg	MTOW 1230 kg
	80	84
Best gradient speed OEI ( $V_{XSE}$ )	79	83

## 6.2 INFLIGHT ENGINE RESTART

After:



**WARNING**

- *mechanical engine seizure;*
- *fire;*
- *major propeller damage*

*engine restart is not recommended.*

- |                                    |  |
|------------------------------------|--|
| 1. Carburettor heat                | <i>ON if required</i>                  |
| 2. Electrical fuel pump            | <i>ON</i>                              |
| 3. Fuel quantity indicator         | <i>CHECK</i>                           |
| 4. Fuel Selector                   | <i>CHECK (Crossfeed if required)</i>   |
| 5. FIELD                           | <i>OFF</i>                             |
| 6. Ignition                        | <i>BOTH ON</i>                         |
| 7. Operating engine Throttle Lever | <i>SET as practical</i>                |
| 8. Stopped engine Throttle Lever   | <i>IDLE</i>                            |
| 9. Stopped engine Propeller Lever  | <i>FULL FORWARD</i>                    |
| 10. Start push-button              | <i>PUSH</i>                            |
| 11. Propeller Lever                | <i>SET at desired rpm</i>              |
| 12. FIELD                          | <i>ON (check for positive ammeter)</i> |
| 13. Engine throttle levers         | <i>SET as required</i>                 |

### **If engine restart is unsuccessful**

- |                                     |   |
|-------------------------------------|---|
| 14. EMERG BATT switch               | <i>ON (if starting battery installed)</i> |
| 15. Repeat engine restart procedure |   |



**CAUTION**

*After engine restart, if practical, moderate propeller rpm and throttle increase to allow OIL and CHT/CT temperatures for stabilizing in the green arcs.*

**NOTE**

*If the fuel quantity in the tank which feeds the stopped engine is low, select the opposite side fuel tank by means of the fuel selector.*

### **If engine restart is still unsuccessful:**

- |  |   |
|--|---|
| 16. Affected engine  | <i>SECURE (see engine securing procedure Para. 3)</i> |
| 17. <b>Land as soon as possible</b> applying one engine inoperative landing procedure. See Para. 6.6 |   |



## 6.3 ENGINE FAILURE DURING TAKEOFF RUN

**BEFORE ROTATION: ABORT TAKE OFF**

- |                          |                                    |
|--------------------------|------------------------------------|
| 1. <b>Throttle Lever</b> | <b><i>BOTH IDLE</i></b>            |
| 2. <b>Rudder</b>         | <b><i>Keep heading control</i></b> |
| 3. <b>Brakes</b>         | <b><i>As required</i></b>          |

**When safely stopped:**

- |                                       |                        |
|---------------------------------------|------------------------|
| 4. Failed Engine Ignition             | <b><i>BOTH OFF</i></b> |
| 5. Failed Engine Field                | <b><i>OFF</i></b>      |
| 6. Failed Engine Electrical fuel pump | <b><i>OFF</i></b>      |

**IF THE DECISION IS TAKEN TO CONTINUE THE TAKEOFF:**

*A take-off abort should always be preferred if a safe stop can be performed on ground.*

*A suggested "GO-NO-GO" criteria is: abort take-off until LG is still down and locked.*

*Once airborne accelerate to Blue Line Speed (V<sub>YSE</sub>) before commanding LG retraction.*

*Take-off planning should take into account that high density altitude and aircraft mass may result in OEI negative climb rate.*

*V<sub>YSE</sub> with flap up shall be flown in order to achieve best possible rate of climb after landing gear retraction and engine feathering.*

- |   |   |
|---|---|
| 1. <b>Operating engine Throttle Lever</b>           | <b><i>FULL POWER</i></b>  |
| 2. <b>Operating engine Propeller Lever</b>          | <b><i>FULL FORWARD</i></b>  |
| 3. <b>Heading</b>                                   | <b><i>Keep control using rudder and ailerons</i></b>              |
| 4. <b>Attitude</b>                                  | <b><i>Reduce as appropriate to keep airspeed over 62 KIAS</i></b> |
| 5. <b><u>Inoperative engine</u> Propeller Lever</b> | <b><i>FEATHER</i></b>   |
| 6. <b>Landing gear control lever</b>                | <b><i>UP</i></b>  |
| 7. <b>Airspeed</b>                                  | <b><i>V<sub>XSE</sub>/V<sub>YSE</sub> as required</i></b>         |
| 8. <b>Flaps</b>                                     | <b><i>0°</i></b>  |

**At safe altitude**

- |   |  |
|---|--|
| 9. <u>Inoperative engine</u>              | <i>Confirm and SECURE</i>                          |
| 10. Operative engine Electrical fuel pump | <i>Check ON</i>                                    |
| 11. Operating engine                      | <i>Check engine instruments</i>                    |
| 12. Operating engine Fuel Selector        | <i>Check correct feeding (crossfeed if needed)</i> |

**If engine restart is recommended:**

13. Apply INFLIGHT ENGINE RESTART procedure *see Para 6.2*

**If engine restart is unsuccessful or it is not recommended:**

13. **Land as soon as possible**
14. One engine inoperative landing procedure. *see Para. 6.6*

**WARNING***Following:*

- *mechanical engine seizure;*
  - *fire;*
  - *major propeller damage*
- engine restart is not recommended.*

## 6.4 ENGINE FAILURE DURING CLIMB

- |              |  |
|--------------|--|
| 1. Autopilot | <b>OFF</b>   |
| 2. Heading   | <i>Keep control using rudder and ailerons</i>              |
| 3. Attitude  | <i>Reduce as appropriate to keep airspeed over 62 KIAS</i> |
- 
- |  |                           |
|--|---------------------------|
| 4. Operating engine Throttle Lever           | <i>FULL THROTTLE</i>      |
| 5. Operating engine Propeller Lever          | <i>FULL FORWARD</i>       |
| 6. Operative engine Electrical fuel pump     | <i>Check ON</i>           |
| 7. <u>Inoperative engine</u> Propeller Lever | <i>FEATHER</i>            |
| 8. <u>Inoperative engine</u>                 | Confirm and <i>SECURE</i> |

**If engine restart is possible:**

9. Apply INFLIGHT ENGINE RESTART procedure *see Para 6.2*

**If engine restart is unsuccessful or it is not recommended:**

9. **Land as soon as possible**
10. One engine inoperative landing procedure. *see Para. 6.6*



*Following a mechanical engine seizure, fire or a major propeller damage engine restart is not recommended.*



*Continuation of flight to a safe landing runway must be planned taking into account maximum operating ceiling in OEI condition. Refer to Section 5 Para 1, "One-engine rate of climb".*

## 6.5 ENGINE FAILURE IN FLIGHT

- |              |  |
|--------------|--|
| 1. Autopilot | <b>OFF</b>   |
| 2. Heading   | <b>Keep control using rudder and ailerons</b>              |
| 3. Attitude  | <b>Adjust as appropriate to keep airspeed over 62 KIAS</b> |

- |  |  |
|--|--|
| 4. Operating engine                      | <i>Monitor engine instruments</i>                      |
| 5. Operative engine Electrical fuel pump | <i>Check ON</i>  |
| 6. Operating engine Fuel Selector        | <i>Check correct feeding<br/>(crossfeed if needed)</i> |

**If engine restart is possible:**

7. Apply INFLIGHT ENGINE RESTART procedure *see Para 6.2*

**If engine restart is unsuccessful or it is not recommended:**

8. Land as soon as possible
9. One engine inoperative landing procedure. *see Para. 6.6*



*Following a mechanical engine seizure, fire or a major propeller damage engine restart is not recommended.*



*Continuation of flight to a safe landing runway must be planned taking into account maximum operating ceiling in OEI condition. Refer to Section 5 Para 12. Rate of climb with One Engine Inoperative.*

## 6.6 ONE ENGINE INOPERATIVE LANDING



*Thoroughly evaluate residual Single Engine Go-Around capabilities and expected climb gradient should a Missed Approach / bailed landing be executed.*

*Refer to Section 5, Para. Single engine go around/Bailed landing/climb and Para. 13 and 14- One-engine Rate of Climb at  $V_{YSE}$  and  $V_{XSE}$*



*Autopilot must be kept OFF*

- |  |  |
|--|--|
| 1. Seat belts                                | <i>Tightly fastened</i>                          |
| 2. Landing lights                            | <i>As required</i>                               |
| 3. Operating engine Fuel Selector            | <i>Check correct feeding/crossfeed if needed</i> |
| 4. <u>Inoperative engine</u> Propeller Lever | <b>CHECK FEATHER</b>                             |
| 5. <u>Inoperative engine</u>                 | <b>CHECK SECURED</b>                             |
| 6. Operative engine Electrical fuel pump     | <b>ON</b>  |

**When on final leg:**

- |                      |  |
|----------------------|--|
| 7. Flap              | <i>T/O</i>   |
| 8. Landing gear      | <i>Select DOWN and check three green lights on</i> |
| 9. Approach Airspeed | $V_{YSE}$  |
| 10. Touchdown speed  | <b>70 KIAS</b>                                     |

## 7 LANDING GEAR SYSTEM FAILURES

### 7.1 EMERGENCY LANDING GEAR EXTENSION

#### NOTE

*Landing gear extension failure is identified by means of the green lights not illuminated: relevant gear leg may not be fully extended and/or locked.*

*Light bulb operating status can be verified by pressing the LDG push-to-test button. Additionally, the red light TRANS indicates that one or more legs are moving and the PUMP ON amber light on the annunciator panel indicates the hydraulic gear pump is operating.*

- |   |                                    |
|---|------------------------------------|
| 1. Airspeed                             | <i>below applicable VLO/VLE</i>    |
| 2. Landing gear control lever           | <i>DOWN</i>                        |
| 3. Emergency gear extension access door | <i>REMOVE</i>                      |
| 4. RH control lever                     | <i>ROTATE 90° counterclockwise</i> |
| 5. Wait at least 20 seconds             |                                    |

#### NOTE

*Main Landing Gear legs green lights may be turned on, thus indicating effective main gear legs blocked in down position by mere effect of gravity force.*

- |                                     |                                     |
|-------------------------------------|-------------------------------------|
| 6. LH control lever                 | <i>ROTATE 180° counterclockwise</i> |
| 7. <b>Land as soon as practical</b> |                                     |



#### NOTE

*The emergency landing gear extension operation takes about 20- sec.*

## 7.2 COMPLETE GEAR UP OR NOSE GEAR UP LANDING

**CAUTION**

*The following procedure applies if Nose Landing Gear is not extended and locked even after emergency extension procedure.*

**WARNING**

*A Nose Landing Gear up leg not down and locked might lead to a hazardous situation, especially on uneven runways.*

**WARNING**

*If landing gear position is not known, perform a tower fly-by at safe speed and altitude to have confirmation about its situation.*

*If possible coordinate fire brigade intervention along runway and report number of persons on board and remaining fuel type and quantity.*

**If a complete Landing Gear up or a Nose Landing Gear up position is reported:****Preparation**

- |   |                                     |
|---|-------------------------------------|
| 1. Reduce fuel load if time and conditions permit |                                     |
| 2. Crew and passengers safety belts               | <i>Tightly fastened</i>             |
| 3. Landing gear control lever                     | <i>UP</i>                           |
| 4. Green lights and TRANS light                   | <i>CHECK OFF</i>                    |
| 5. Flap setting                                   | <i>plan approach with Flap Land</i> |

**Before ground contact:**

- |                                   |                 |
|-----------------------------------|-----------------|
| 6. LH and RH Fuel Selector        | <i>BOTH OFF</i> |
| 7. LH and RH Electrical fuel pump | <i>BOTH OFF</i> |
| 8. Ignitions                      | <i>ALL OFF</i>  |

**On touch down:**

- |                     |   |
|---------------------|---|
| 9. Landing attitude | <i>slight nose-up and wings levelled,</i> |
| 10. Touchdown speed | <i>as low as 50 KIAS with flap</i>        |
| 11. Aircraft nose   | <i>gently lower as speed bleeds off</i>   |

**After aircraft stops:**

- |                     |                 |
|---------------------|-----------------|
| 12. FIELD LH and RH | <i>BOTH OFF</i> |
| 13. MASTER SWITCH   | <i>OFF</i>      |

**CAUTION**

*Master switch to OFF impairs radio communication and outside aircraft lighting.*

14. Aircraft Evacuation

*carry out if necessary*



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*



## 7.3 PARTIAL MAIN LG EXTENSION



*The following procedure applies if one or both Main Landing Gear legs are not completely extended and locked even after emergency extension procedure.*



*A partial gear landing (RH and/or LH leg not down and locked) might turn into a hazardous situation, especially on uneven runways.*

*If possible try to obtain a symmetric gear extension (e.g. by trying further landing gear retraction) in order to avoid swerving after touchdown. A gear up landing is generally considered safer.*



*If landing gear position is not known, perform a tower fly-by at safe speed and altitude to have confirmation about its situation.*

*If possible coordinate fire brigade intervention along runway and report number of persons on board and remaining fuel type and quantity.*

**Preparation**

- |   |                                     |
|---|-------------------------------------|
| 1. Reduce fuel load if time and conditions permit |                                     |
| 2. Crew and passengers safety belts               | <i>Tightly fastened</i>             |
| 3. Landing gear control lever                     | <i>UP</i>                           |
| 4. Green lights and TRANS light                   | <i>CHECK OFF</i>                    |
| 5. Flap setting                                   | <i>plan approach with Flap Land</i> |

**If partially extended landing gear is confirmed:****Before ground contact:**

- |                                   |                 |
|-----------------------------------|-----------------|
| 6. LH and RH Fuel Selector        | <i>BOTH OFF</i> |
| 7. LH and RH Electrical fuel pump | <i>BOTH OFF</i> |
| 8. Ignitions                      | <i>ALL OFF</i>  |

**On touch down:**

- |                           |  |
|---------------------------|--|
| 9. Align for approach     | <i>on the runway centreline</i>  |
| 10. Touchdown speed       | <i>as low as 50 KIAS</i>   |
| 11. Touchdown             | <i>on the extended gear only</i>   |
| 12. Heading and direction | <i>maintain applying appropriate aileron and rudder/steering control</i> |
| 13. Retracted leg         | <i>keep off the ground as long as possible</i>                           |

**After aircraft stops:**

- |                     |                 |
|---------------------|-----------------|
| 14. FIELD LH and RH | <i>BOTH OFF</i> |
| 15. MASTER SWITCH   | <i>OFF</i>      |



**CAUTION**

*Master switch to OFF impairs radio communication and outside aircraft lighting.*

- |                         |                               |
|-------------------------|-------------------------------|
| 16. Aircraft Evacuation | <i>carry out if necessary</i> |
|-------------------------|-------------------------------|



**WARNING**

*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

## 7.4 FAILED RETRACTION

- |    |                            |                                      |
|----|----------------------------|--------------------------------------|
| 1. | Airspeed                   | <i>Keep below applicable VLO/VLE</i> |
| 2. | Landing gear control lever | <i>DOWN</i>                          |

**WARNING**

*A Landing Gear lever recycle (further retraction attempt) may result in a final partial Landing Gear Extension, which may then compromise safe landing aircraft capability.*

- |    |                     |              |
|----|---------------------|--------------|
| 3. | Landing Gear lights | <i>Check</i> |
|----|---------------------|--------------|

**If a safe landing configuration is obtained (3 greens)**

- |    |               |  |
|----|---------------|--|
| 4. | Land normally |  |
|----|---------------|--|

**If a safe landing gear configuration is not obtained:**

- |    |                                  |                              |
|----|----------------------------------|------------------------------|
| 4. | Emergency LG extension procedure | <i>Apply (See Para. 7.1)</i> |
| 5. | Land as soon as practical        |                              |

## 7.5 UNINTENTIONAL LANDING GEAR EXTENSION

**CAUTION**

*An unwanted landing gear extension, with at least one leg moving downward, may be caused by hydraulic fluid loss and it is signaled by*

- significant aerodynamic noise increase;
- light and counteractable nose down pitch moment;
- red TRANS light turned on.

- |    |                            |                                      |
|----|----------------------------|--------------------------------------|
| 1. | Airspeed                   | <i>Keep below applicable VLO/VLE</i> |
| 2. | Landing gear control lever | <i>DOWN</i>                          |
| 3. | Landing Gear lights        | <i>Check</i>                         |

**If a safe landing configuration is obtained (3 greens)**

- |    |               |  |
|----|---------------|--|
| 4. | Land normally |  |
|----|---------------|--|

**If a safe landing gear configuration is not obtained:**

- |    |                                  |                              |
|----|----------------------------------|------------------------------|
| 4. | Emergency LG extension procedure | <i>Apply (See Para. 7.1)</i> |
| 5. | <b>Land as soon as practical</b> |                              |

INTENTIONALLY LEFT BLANK

## 8 SMOKE AND FIRE OCCURRENCE

### 8.1 ENGINE FIRE ON THE GROUND

- |                                  |                              |
|----------------------------------|------------------------------|
| 1. <b>Fuel Selectors</b>         | <b><i>BOTH OFF</i></b>       |
| 2. <b>Ignitions</b>              | <b><i>ALL OFF</i></b>        |
| 3. <b>Electrical fuel pumps</b>  | <b><i>BOTH OFF</i></b>       |
| 4. <b>Cabin heat and defrost</b> | <b><i>OFF</i></b>            |
| 5. <b>MASTER SWITCH</b>          | <b><i>OFF</i></b>            |
| 6. <b>Parking Brake</b>          | <b><i>ENGAGED</i></b>        |
| 7. <b>Aircraft Evacuation</b>    | <b>carry out immediately</b> |

**WARNING**

*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

## 8.2 ENGINE FIRE DURING TAKEOFF RUN

**BEFORE ROTATION: ABORT TAKE OFF**

- |                   |                             |
|-------------------|-----------------------------|
| 1. Throttle Lever | <b>BOTH IDLE</b>            |
| 2. Rudder         | <i>Keep heading control</i> |
| 3. Brakes         | <i>As required</i>          |

**With aircraft under control**

- |                           |                              |
|---------------------------|------------------------------|
| 4. Fuel Selector          | <b>BOTH OFF</b>              |
| 5. Ignitions              | <b>ALL OFF</b>               |
| 6. Electrical fuel pump   | <b>BOTH OFF</b>              |
| 7. Cabin heat and defrost | <b>OFF</b>                   |
| 8. MASTER SWITCH          | <b>OFF</b>                   |
| 9. Parking Brake          | <b>ENGAGED</b>               |
| 10. Aircraft Evacuation   | <i>carry out immediately</i> |



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

**IF THE DECISION IS TAKEN TO CONTINUE THE TAKEOFF:**

*A take-off abort should always be preferred if a safe stop can be performed on ground.*

*A suggested "GO-NO-GO" criteria is: abort take-off until LG is still down and locked.*



*Once airborne accelerate to Blue Line Speed (V<sub>YSE</sub>) before commanding LG retraction.*

*Take-off planning should take into account that high density altitude and aircraft mass may result in OEI negative climb rate.*

*V<sub>YSE</sub> with flap up shall be flown in order to achieve best possible rate of climb after landing gear retraction and engine feathering.*

- |  |  |
|--|--|
| 1. Operating engine Throttle Lever             | <b>FULL POWER</b>  |
| 2. Operating engine Propeller Lever            | <b>FULL FORWARD</b>  |
| 3. Heading                                     | <i>Keep control using rudder and ailerons</i>              |
| 4. Attitude                                    | <i>Reduce as appropriate to keep airspeed over 62 KIAS</i> |
| 5. <u>Fire affected engine</u> Propeller Lever | <b>FEATHER</b>   |
| 6. Landing gear control lever                  | <b>UP</b>  |
| 7. Airspeed                                    | <b>V<sub>XSE</sub>/V<sub>YSE</sub> as required</b>         |
| 8. Flaps                                       | <b>0°</b>  |

**At safe altitude**

- |     |  |                             |
|-----|--|-----------------------------|
| 9.  | Cabin heat and defrost   | <i>BOTH OFF</i>             |
| 10. | <u>Fire affected engine</u> Fuel Selector  | <i>Confirm and OFF</i>      |
| 11. | <u>Fire affected engine</u> Ignitions  | <i>Confirm and BOTH OFF</i> |
| 12. | <u>Fire affected engine</u> Electrical fuel pump   | <i>Confirm and OFF</i>      |
| 13. | <u>Fire affected engine</u> FIELD  | <i>OFF</i>                  |
| 14. | <b>Land as soon as possible</b> applying <i>one engine inoperative landing</i> procedure.<br>See Para. 6.6 |                             |

### 8.3 ENGINE FIRE IN FLIGHT

- |  |  |
|--|--|
| 1. Cabin heat and defrost  | <b>BOTH OFF</b>  |
| 2. Autopilot   | <b>OFF</b>   |
| 3. <u>Fire affected engine</u> Fuel Selector   | <b>Confirm and OFF</b>                                     |
| 4. <u>Fire affected engine</u> Ignition  | <b>Confirm and BOTH OFF</b>                                |
| 5. <u>Fire affected engine</u> Throttle Lever  | <b>Confirm and FULL FORWARD</b>                            |
| 6. <u>Fire affected engine</u> Propeller Lever   | <b>Confirm and FEATHER</b>                                 |
| 7. <u>Fire affected engine</u> Electrical fuel pump  | <b>OFF</b>   |
| 8. Heading   | <b>Keep control using rudder and ailerons</b>              |
| 9. Attitude  | <b>Adjust as appropriate to keep airspeed over 62 KIAS</b> |
| 10. <u>Fire affected engine</u> Field  | <b>OFF</b>   |
| 11. Cabin ventilation  | <b>OPEN</b>  |
| 12. Land as soon as possible applying one engine inoperative landing procedure.<br>See Para. 6.6 |  |

### 8.4 ELECTRICAL SMOKE IN CABIN ON THE GROUND

- |                           |                              |
|---------------------------|------------------------------|
| 1. MASTER SWITCH          | <b>OFF</b>                   |
| 2. Cabin heat and defrost | <b>OFF</b>                   |
| 3. Throttle Lever         | <b>BOTH IDLE</b>             |
| 4. Ignitions              | <b>ALL OFF</b>               |
| 5. Fuel Selector          | <b>BOTH OFF</b>              |
| 6. Parking Brake          | <b>ENGAGED</b>               |
| 7. Aircraft Evacuation    | <b>carry out immediately</b> |

**WARNING**

*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*



## 8.5 ELECTRICAL SMOKE IN CABIN DURING FLIGHT

- |  |             |
|--|-------------|
| 1. Cabin ventilation                       | <b>OPEN</b> |
| 2. Emergency light                         | <b>ON</b>   |
| 3. Standby attitude indicator switch       | <b>ON</b>   |
| 4. Gain VMC conditions as soon as possible |             |

**In case of cockpit fire:**

- |                      |                                  |
|----------------------|----------------------------------|
| 5. Fire extinguisher | <i>use toward base of flames</i> |
|----------------------|----------------------------------|

**CAUTION***A tripped circuit breaker should not be reset.***If smoke persists, shed electrical supply in order to isolate faulty source by:**

- |                        |                 |
|------------------------|-----------------|
| 6. FIELD LH and RH     | <b>OFF</b>      |
| 7. AVIONICS LH and RH  | <b>OFF</b>      |
| 8. CROSS BUS LH and RH | <b>BOTH OFF</b> |

**CAUTION***A fully charged battery can supply electrical power for at least 30 minutes.***If faulty source is found:**

9. It may be possible to restore non faulty power sources (one at a time)

**If smoke persists:****WARNING***Before total electrical system shutdown consider gaining VMC condition, at night set personal emergency light on.**Only emergency light and emergency ADI will be electrically powered.**All radio COM and NAV, Landing Gear lever (normal mode) and indication lights, electrical trims and flaps will be unserviceable.*

- |                   |            |
|-------------------|------------|
| 10. MASTER SWITCH | <b>OFF</b> |
|-------------------|------------|

11. Land as soon as possible

**When on ground:**

12. Aircraft Evacuation

*carry out as necessary*



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

## 9 UNINTENTIONAL SPIN RECOVERY

**WARNING**

*Spin behaviour has not been demonstrated since certification process does not required it for this aircraft category.*

*Intentional spin is forbidden.*

*Stall with one engine inoperative is forbidden.*

*Should an unintentional spin occur, the classic recovery manoeuvre is deemed as being the best action to undertake:*

- |                                  |  |
|----------------------------------|--|
| 1. <b>Both engines throttles</b> | <i>idle</i>                                  |
| 2. <b>Flight Controls</b>        | <i>centralize</i>                            |
| 3. <b>Rudder</b>                 | <i>fully against rotation until it stops</i> |

## 10 LANDING EMERGENCIES

### 10.1 LANDING WITHOUT ENGINE POWER

*In case of double engine failure both propellers should be feathered to achieve maximum efficiency. Best glide speed is attained with flap UP and equals  $V_Y$  for current aircraft mass and air density altitude. Refer to Section 5, Para. "Enroute Rate of Climb".*

**CAUTION**

*Normal landing gear extension requires MASTER switch ON, an efficient battery and takes around 20 seconds.*

*LG selection should be appropriately anticipated when sure on final.*

*Flap can be set to T/O or LAND when sure on final to reduce landing ground roll on short field.*

*Touchdown speed can be as low as 50 kt with flap down.*

1. Airspeed

MTOW 1180kg	MTOW 1230 kg
$V_Y = 83 \text{ KIAS}$	$V_Y = 84 \text{ KIAS}$

2. Flaps *UP*
3. Emergency landing field *Select*

**WARNING**

*Emergency landing strip should be chosen considering surface condition, length and obstacles. Wind can be guessed by smoke plumes direction and tree tops or grass bending. Select touchdown direction according to the furrows of a plowed field, not across.*

4. Safety belts *FASTEN and tighten*
5. Flaps *Set when landing is assured*
6. Landing gear control lever *DOWN when landing is assured*

**CAUTION**

*To reduce landing gear extension time, evaluate use of emergency control system which requires about 12 sec.*

*Before touch down*

- |                         |                 |
|-------------------------|-----------------|
| 7. Fuel Selector        | <i>BOTH OFF</i> |
| 8. Electrical fuel pump | <i>BOTH OFF</i> |
| 9. Ignitions            | <i>ALL OFF</i>  |
| 10. MASTER SWITCH       | <i>OFF</i>      |

*When stopped*

- |                         |                               |
|-------------------------|-------------------------------|
| 11. Aircraft Evacuation | <i>carry out if necessary</i> |
|-------------------------|-------------------------------|



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

## 10.2 LANDING WITH NOSE LANDING GEAR TIRE DEFLATED



*If possible, as a nose landing gear flat tire condition is known, coordinate fire brigade intervention along runway and report number of persons on board and remaining fuel type and quantity.*

**If Nose Landing Gear flat tire is confirmed:****Preparation**

- |                                     |  |
|-------------------------------------|--|
| 1. Crew and passengers safety belts | <i>Tightly fastened</i>                  |
| 2. If time permits                  | <i>Burn fuel to lower landing weight</i> |
| 3. Flap setting                     | <i>plan approach with Flap Land</i>      |

**Before ground contact:**

- |                         |                 |
|-------------------------|-----------------|
| 4. Fuel Selector        | <i>BOTH OFF</i> |
| 5. Electrical fuel pump | <i>BOTH OFF</i> |
| 6. Ignitions            | <i>ALL OFF</i>  |

**On touch down:**

- |                     |   |
|---------------------|---|
| 7. Landing attitude | <i>slight nose-up and wings levelled,</i> |
| 8. Touchdown speed  | <i>as low as 50 KIAS with flap</i>        |
| 9. Aircraft nose    | <i>gently lower as speed bleeds off</i>   |

**After aircraft stops:**

- |                     |                 |
|---------------------|-----------------|
| 10. FIELD LH and RH | <i>BOTH OFF</i> |
| 11. MASTER SWITCH   | <i>OFF</i>      |



*Master switch to OFF impairs radio communication and outside aircraft lighting.*

- |                         |                               |
|-------------------------|-------------------------------|
| 12. Aircraft Evacuation | <i>carry out if necessary</i> |
|-------------------------|-------------------------------|



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

### 10.3 LANDING WITH A KNOWN MAIN LANDING GEAR TIRE DEFLATED



*An asymmetrical landing gear tire condition (RH and/or LH tires deflated) might turn into a hazardous situation, especially on uneven runways.*



*If possible, as a landing gear tires condition is known, coordinate fire brigade intervention along runway and report number of persons on board and remaining fuel type and quantity.*

#### **If a main Landing Gear flat tire is confirmed:**

##### **Preparation**

- |                                     |                                     |
|-------------------------------------|-------------------------------------|
| 1. Crew and passengers safety belts | <i>Tightly fastened</i>             |
| 2. Flap setting                     | <i>plan approach with Flap Land</i> |

##### **Before ground contact:**

- |                                   |          |
|-----------------------------------|----------|
| 3. Ignitions                      | ALL OFF  |
| 4. LH and RH Fuel Selector        | BOTH OFF |
| 5. LH and RH Electrical fuel pump | BOTH OFF |

##### **On touch down:**

- |                          |  |
|--------------------------|--|
| 6. Align for approach    | <i>on the runway centreline</i>  |
| 7. Touchdown speed       | <i>as low as 50 KIAS</i>   |
| 8. Touchdown             | <i>on the good tire gear only</i>  |
| 9. Heading and direction | <i>maintain applying appropriate aileron and rudder/steering control</i> |
| 10. Flattened tire       | <i>keep off the ground as long as possible</i>                           |

##### **After aircraft stops (or if runway departure is imminent):**

- |                     |                 |
|---------------------|-----------------|
| 11. FIELD LH and RH | <i>BOTH OFF</i> |
| 12. MASTER SWITCH   | <i>OFF</i>      |



*Master switch to OFF impairs radio communication and outside aircraft lighting.*

- |                         |                               |
|-------------------------|-------------------------------|
| 13. Aircraft Evacuation | <i>carry out if necessary</i> |
|-------------------------|-------------------------------|



*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*

## 10.4 LANDING WITHOUT BRAKES

**CAUTION**

*If possible, select an airport with suitable runway length.*

*Otherwise, evaluate the possibility to perform a gear up landing (refer to procedure reported on Para. 7.2). In the latter case consider the increasing hazard of an uneven pavement.*

1. Safety belts

*FASTEN***After touch down if runway is deemed insufficient to decelerate:**

2. Fuel Selector

*BOTH OFF*

3. Electrical fuel pumps

*BOTH OFF*

4. Ignitions

*ALL OFF*

5. FIELD LH and RH

*BOTH OFF*

6. MASTER SWITCH

*OFF***CAUTION**

*Master switch to OFF impairs radio communication and outside aircraft lighting.*

**Before end of runway or if runway departure is imminent:**

1. Landing gear control lever

*UP***After aircraft stops:**

2. Aircraft Evacuation

*carry out if necessary***WARNING**

*Consider use of ditching emergency exit to escape in case pilot or passenger doors are blocked, watch for engine hot parts, fuel, hydraulic fluid or oil spills. Leave aircraft in upwind direction.*



## 11 AIRCRAFT EVACUATION



**WARNING**

*Leave the aircraft when engines are fully stopped. Watch for engine hot parts and fuel, hydraulic fluid or oil spills when using fuselage doors. If fuselage doors are unserviceable escape through the ditching emergency exit*

*In case of engine fire escape from opposite or upwind aircraft side.*

**Verify (if not yet performed):**

- |  |                        |
|--|------------------------|
| 1. <b>Fuel Selectors</b>                           | <b><i>BOTH OFF</i></b> |
| 2. <b>Ignitions</b>                                | <b><i>ALL OFF</i></b>  |
| 3. <b>Electrical fuel pumps</b>                    | <b><i>BOTH OFF</i></b> |
| 4. <b>MASTER SWITCH</b>                            | <b><i>OFF</i></b>      |
| 5. <b>Parking Brake</b>                            | <b><i>ENGAGED</i></b>  |
| 6. <b>Leave the aircraft using emergency exits</b> |                        |

## 12 DITCHING

**WARNING**

*Contact with water shall happen with aircraft longitudinal axis and direction of motion parallel to the wave at the minimum possible speed. Keep the nose up as long as possible.*

*Once in the water, the aircraft shall be evacuated through the ditching emergency exit, if available put life vest on and set dinghy out first. Inflate them only outside the aircraft.*

*If available, try to approach any existing ship in the vicinity in order to be rapidly located and rescued right after ditching.*

- |                 |                             |
|-----------------|-----------------------------|
| 1. Landing gear | <i>UP</i>                   |
| 2. Safety belts | <i>Tighten and fastened</i> |
| 3. Flaps        | <i>FULL</i>                 |

### **Before water impact**

- |                         |                 |
|-------------------------|-----------------|
| 4. Fuel Selector        | <i>BOTH OFF</i> |
| 5. Electrical fuel pump | <i>BOTH OFF</i> |
| 6. Ignitions            | <i>ALL OFF</i>  |
| 7. MASTER SWITCH        | <i>OFF</i>      |
| 8. FIELD LH and RH      | <i>BOTH OFF</i> |
| 9. Impact speed         | <i>50 KIAS</i>  |

### **Aircraft evacuation**

- |                           |                         |
|---------------------------|-------------------------|
| 10. Emergency exit handle | <i>rotate clockwise</i> |
| 11. Latch door            | <i>push outward</i>     |
| 12. Life vests            | <i>don</i>              |
| 13. Evacuate the aircraft |                         |

<b>Supplement G19: pages replacement instructions</b>
---

## SECTION 4 - NORMAL PROCEDURES

**Supplement G19 Section 4 – NORMAL PROCEDURES**  
**replaces Basic AFM Section 4 as a whole**

INTENTIONALLY LEFT BLANK

**SECTION 4 – NORMAL PROCEDURES****INDEX**

1.	INTRODUCTION .....	3
1.1.	Normal ops general recommendations .....	3
2.	AIRSPEEDS .....	7
2.2.	Normal operations .....	7
2.3.	Single engine training .....	8
3.	NORMAL PROCEDURES CHECKLIST .....	9
3.1	Recommendations for cold weather operations .....	9
3.2	Pre-flight check – aircraft walk-around .....	11
3.3	Cockpit inspections .....	17
3.4	Engine starting .....	18
3.5	Before taxiing .....	20
3.6	Taxiing .....	20
3.7	Prior to takeoff .....	21
3.8	Line-up .....	22
3.9	Takeoff and climb .....	23
3.10	Cruise .....	24
3.11	Turbulent air operation .....	24
3.12	Descent and approach .....	25
3.13	Before landing .....	25
3.14	Balked landing/missed approach .....	26
3.15	After landing .....	26
3.16	Parking/shut down .....	27
3.17	Postflight checks .....	28
4.	ADDITIONAL GUIDANCE FOR RNAV .....	29
4.1.	Approach Applications .....	351
4.2.	PBN (RNAV & RNP) Operational Eligibility .....	354
5.	GROUND TOWING, PARKING AND MOORING .....	35
5.1.	Towing .....	35
5.2.	Parking .....	35
5.3.	Mooring .....	36

INTENTIONALLY LEFT BLANK

## 1. INTRODUCTION

Section 4 describes checklists and recommended procedures for the conduct of normal operations for **P2006T** aircraft.

### 1.1. NORMAL OPS GENERAL RECOMMENDATIONS

The following points should be always brought to attention to pilot/instructor/operator when operating a Tecnam aircraft equipped with variable pitch propeller:

#### **1. Propeller governor ground check.**

As prescribed by the propeller/governor manufacturer, a drop of 400/500 propeller RPM should be produced during this check. Its aim is to confirm the governor efficiency, not its complete feathering function.

Especially during the first cycle of propeller lever pulling, the governor tendency is to respond to the input with consistent delay, causing the pilot to continue moving back the propeller lever until an abrupt RPM change is observed. This causes an excessive drop in propeller speed that may reach up to 800 RPM in some cases and, consequently, a drop of up to 2000 engine shaft RPM. The long term result is a major wear of engine gearbox, bushings and pistons. In some cases, it may also result in detonation.

In order to avoid these long term adverse effects, the governor ground check should be performed by slowly and gently pulling the propeller lever. The purging cycle should be repeated 3 times, making sure that the governor closely and firmly controls the rpm.

The following recommendations have to be followed during the test:

- ***propeller speed drops shall be of 400/500 propeller RPM***
- ***the cycle shall be repeated 3 times***
- ***the pilot shall be ready to push the propeller lever if a drop of >500 RPM is recorded***


#### **2. Power changes.**

When power setting changes are required in any flight condition, remember the following correct procedure:

☐ ☐ **Power increase = FIRST Prop THEN Map**

☐ ☐ **Power reduction = FIRST Map THEN Prop**

Useful guideline chart that could be used for best propeller/manifold combination is following reported:



### 3. Suitable Fuels.

Tecnam remember operators to fill the aircraft with approved and suitable fuels. Use of not approved/unknown fuels may cause damages to the engine.

#### ONLY USE APPROVED FUELS

For details refer to Section 2 of this manual (or applicable Supplement) and latest issue of Rotax SI-912-016



## G1000 NXi system use

For safety reasons, G1000 NXi operational procedures must be learned on the ground.

Document Garmin G1000 NXi Pilot's Guide for Tecnam P2006T (P/N 190-02286-00) – last issue, reports detailed instructions to operate the system in subject. Make always reference to the above mentioned document.

**CAUTION**

*Garmin G1000 NXi Pilot's Guide for Tecnam P2006T (P/N 190-02286-00) – last issue - must be carried onboard the airplane at all times.*

**WARNING**

*To reduce the risk of unsafe operation, carefully review and understand all aspects of the G1000 NXi Pilot's Guide (P/N 190-02286-00) documentation at the last issue and the AFM for the aircraft. Thoroughly practice basic operation prior to actual use. During flight operations, carefully compare indications from the G1000 NXi to all available navigation sources, including the information from other NAVAIDS, visual sightings, charts, etc. For safety purposes, always resolve any discrepancies before continuing navigation.*

**WARNING**

*Do not use basemap (land and water data) information for primary navigation. Basemap data is intended only to supplement other approved navigation data sources and should be considered as an aid to enhance situational awareness. Do not use outdated database information. Databases used in the G1000 NXi system must be updated regularly in order to ensure that the information remains current. Pilots using any outdated database do so entirely at their own risk. Reference "Garmin G1000 NXi Pilot's Guide for the Tecnam P2006T (P/N 190-02286-00)", last issue, Appendix B concerning SD card use and databases.*

**WARNING**

*For safety reasons, G1000 NXi operational procedures must be learned on the ground.*

**WARNING**

*Because of variation in the earth's magnetic field, operating the G1000 NXi within the following areas could result in loss of reliable attitude and heading indications.*

*North of 72° North latitude at all longitudes; South of 70° South latitude at all longitudes; North of 65° North latitude between longitude 75° W and 120° W. (Northern Canada); North of 70° North latitude between longitude 70° W and 128° W. (Northern Canada); North of 70° North latitude between longitude 85° E and 114° E. (Northern Russia); South of 55° South latitude between longitude 120° E and 165° E. (Region south of Australia and New Zealand).*



*The altitude calculated by G1000 NXi GPS receivers is geometric height above Mean Sea Level and could vary significantly from the altitude displayed by pressure altimeters, such as the GDC 72 Air Data Computer, or other altimeters in aircraft. GPS altitude should never be used for vertical navigation. Always use pressure altitude displayed by the G1000 NXi PFD or other pressure altimeters in aircraft.*

**NOTE**

*If the pilot profile is changed during the flight, the HSI could not indicate the correct LOC or VOR indication until the pilot manually tunes the active frequency. Make sure that the displayed indication on the HSI indicator is consistent with the selected frequency.*

**NOTE**

*The data contained in the terrain and obstacle databases comes from government agencies. Garmin accurately processes and cross-validates the data, but cannot guarantee the accuracy and completeness of the data. Reference “Garmin G1000 NXi Pilot’s Guide for the Tecnam P2006T” (P/N 190-02286-00), last issue, Appendix B concerning SD card use and databases.*

**NOTE**

*Use of polarized eyewear may cause the flight displays to appear dim or blank.*

## MD302 system use



*“The detailed description, operation and functionalities of MD302 Stand By Attitude Module are provided on MD302 Stand-By Attitude Module Pilot’s Guide” document P/N 9017846 rev.D, which is to be considered to be attached to this AFM and kept onboard the aircraft.*

## 2. AIRSPEEDS

### 2.1. NORMAL OPERATIONS

The following airspeeds are those which are significant for normal operations, with reference to both MTOW: 1180 kg and 1230 kg (if Supplement G10 - Increased MTOW @1230 KG - is applicable).

	FLAPS	MTOW	
		1180kg	1230 kg
Rotation Speed (in takeoff, $V_R$ )	T/O	<b>64 KIAS</b>	<b>65 KIAS</b>
Best Angle-of-Climb Speed ( $V_X$ )	0°	<b>73 KIAS</b>	<b>72 KIAS</b>
Best Rate-of-Climb speed ( $V_Y$ )	0°	<b>80 KIAS</b>	<b>84 KIAS</b>
Approach speed	T/O	<b>90 KIAS</b>	<b>90 KIAS</b>
Final Approach Speed	FULL	<b>70 KIAS</b>	<b>71 KIAS</b>
Manoeuvring speed ( $V_A$ )	0°	<b>118 KIAS</b>	<b>122 KIAS</b>
Never Exceed Speed ( $V_{NE}$ )	0°	<b>167 KIAS</b>	<b>171 KIAS</b>

## 2.2. SINGLE ENGINE TRAINING

$V_{SSE}$  is a speed selected as training aid for pilots in the handling of multi-engine aircraft. It is the minimum speed for intentionally rendering on engine inoperative in flight. This minimum speed provides the margin the manufacturer recommends for us when intentionally performing engine inoperative maneuvers during training. Shutting down an engine for training shall not become a habit; for safety purpose, and in order to optimise training, engine shutdown to perform OEI shall be executed only when necessary and required by regulations (e.g. during flight check, skill tests or demonstration as per 14CFR Part61 or similar).

**A simulated feather condition is obtained with propeller lever full forward and throttle lever set at 13.5 in Hg MAP at 70-90 KIAS and 2000-4000 ft (density altitude).**

Recommended safe simulated OEI speed ( $V_{SSE}$ )	<b>70 KIAS</b>
--	----------------

### NOTE

*Keep speed above  $V_{SSE}$  for simulated OEI training operations.*

In normal operations, shutting down an engine for training shall not become a habit, in particular for safety reasons and in order to optimise training; engine shutdown to perform OEI shall be executed only when required by regulations (e.g. during flight check, skill tests or demonstration as per 14CFR Part61 or equivalent rule).

The continuous operation of engine securing for training may indeed cause long term damages to the engine itself due to the high load coming from propeller (which is in feathering angle during the engine re-starting).

### 3. NORMAL PROCEDURES CHECKLIST

#### 3.1 RECOMMENDATIONS FOR COLD WEATHER OPERATIONS

##### **Engine cold weather operation**

Refer to Rotax 912 Series Operators Manual, last issue, providing instructions for operating media (lubricant and coolant specifications) to be used in cold weather operation.

##### **Parking**

When the airplane is parked in cold weather conditions and it is expected to be soaked at temperatures below freezing, some precautions need to be taken.

Clear snow, slush, and ice in the parking area, or at least clear the area around the tires to prevent them from freezing to the ground. Apply plugs on Pitot and static ports.

The exposed airframe parts should be protected, especially the engines, the wheels, the blades and the gears against the snow or ice accumulation. Water and other freezable liquids should be removed from the airplane.

Standing water that could freeze should be removed from critical parts, as flaps and ailerons hinges, trim tabs hinges, drain points, LG doors, cabin doors etc.

With an ambient temperature of below -20°C, remove battery and store in a warm dry place; additionally in order to prevent a heavy discharge and to increase the battery life time, it is recommended to use an external power source for engine starting at temperatures lower than -15°C.

When wheel brakes come in contact with ice, slush, or snow with freezing conditions, the brake disk may freeze: park the aircraft with parking brake control knob in OFF position and ensure the aircraft is properly chocked and moored.

In any case, when the probability of ice, snow, or heavy frost is forecast, the use of a hangar is strongly recommended.

An external inspection of the aircraft is performed before each flight, as prescribed on Section 3.1.

For cold weather operations, the crew must focus on the check of following parts of airplane (free of snow/ice/standing water).

- control surfaces
- fuselage
- wings
- vertical and horizontal stabilator
- stall warning switch
- engine inlets
- engines draining points
- propeller blades
- LG doors
- Pitot, and static ports
- fuel tank vents

Tires show low pressure in cold weather: the required adjustments to inflation pressure should be performed on tires cooled to ambient temperature.

If the crew detects ice, anti icing products are not allowed. To remove ice, tow the aircraft in the hangar and operate with a soft brush or a humid cloth.



**WARNING**

*Removal of snow/ice accumulations is necessary prior to take-off because they will seriously affect airplane performance. Aircraft with ice/snow accumulation is not cleared for flight.*

If the aircraft must be operated in cold weather conditions within the range -25°C to -5°C, it is suggested to perform following procedure in order to speed up the engine warm-up:

- Tow the airplane in a warm hangar (warmer than -5°C);
- Let airplane temperature stabilize;
- Check pressure in hydraulic system, recharge if necessary;
- Heat the cabin to a suitable value to avoid windshield frost in flight; an electrical fan heater may be used inside the cabin;
- Tow airplane outside and perform engine starting as soon as possible.

### 3.2 PRE-FLIGHT CHECK – AIRCRAFT WALK-AROUND

To perform the aircraft walk-around, carry out the checklists according to the pattern shown in Figure 4-1.



**WARNING**

*If ignition switches are turned ON, a propeller movement can cause the engine starting with consequent hazard for people nearby.*

**NOTE**

*Visual inspection is defined as follows: check for defects, cracks, delamination, excessive play, unsafe or improper installation as well as for general condition, presence of foreign objects, slippage markers etc. For control surfaces, visual inspection also involves additional check for freedom of movement. Always check the ground in the area of the aircraft for evidence of fuel, oil or operating fluids leakages.*




Figure 4.1



1.	Pilot door and cabin	<i>Check door for integrity. Turn ON the Master Switch and check Stall Warning switch for operation and condition; check lighting of Landing/Taxi/Nav/Strobe lights, then turn OFF the Master Switch.</i>
2.	Left main landing gear	<i>Check fuselage skin status, tire status (cuts, bruises, cracks and excessive wear), slippage markers integrity, gear structure and shock absorber, hoses, gear door attachments and gear micro-switches. There should be no sign of hydraulic fluid leakage.</i>
3.	Wheel chock	<i>Remove if employed</i>
4.	Propeller and spinner	<i>The propeller blades and spinner should be free of cracks, nicks, dents and other defects and should rotate freely. Check fixing and lack of play between blades and hub.</i>
5.	Left engine nacelle	<p><i>Perform following inspections:</i></p> <ul style="list-style-type: none"> <li><i>a) Check the surface conditions.</i></li> <li><i>b) Nacelle inlets and exhausts openings must be free of obstructions. If inlet and outlet plugs are installed, they should be removed.</i></li> <li><i>c) Check radiators. There should be no indication of leakage of fluid and they have to be free of obstructions.</i></li> <li><i>d) <u>Only before the first flight of a day:</u></i> <ul style="list-style-type: none"> <li><i>(1) Verify coolant level in the expansion tank, replenish as required up to top (level must be at least 2/3 of the expansion tank).</i></li> <li><i>(2) Verify coolant level in the overflow bottle through the slot under the nacelle: level must be between min. and max. mark. Replenish if required removing the upper cowling; after that, install upper cowling checking for interferences with radiators</i></li> <li><i>(3) Turn the propeller by hand to and fro, feeling the free rotation of 15° or 30° before the crankshaft starts to rotate. If the propeller can be turned between the dogs with practically no friction at all further investigation is necessary. Turn propeller by hand in direction of engine rotation several times and observe engine for odd noises or excessive resistance and normal compression.</i></li> </ul> </li> </ul>



		<p>e) Check oil level and replenish as required. Prior to oil check, switch off both ignitions circuits and turn the propeller by hand in direction of engine rotation several times to pump oil from the engine into the oil tank. This process is finished when air is returning back to the oil tank and can be noticed by a murmur from the open oil tank. Prior to long flights oil should be added so that the oil level reaches the “max” mark.</p> <p>f) Drain off Gascolator for water and sediment (drain until no water comes off). Then make sure drain valve is closed.</p> <p>g) Check drainage hoses clamps</p> <p>h) Verify all parts are fixed or locked.</p> <p>i) Verify all inspection doors are closed.</p>
6.	Air induction system	Check engine air inlet for integrity and correct fixing. The air intake filter must be free of obstructions.
7.	Left fuel tank	Check that the refuelling port cap is properly secured, then perform the fuel tank sump drainage operating the related valve which, after operation, must be checked closed. Fuel must be checked for water and sediment. Verify the tank vent outlet is clear.
8.	Landing and taxi lights	Visual inspection
9.	Left wing leading edge	Visual inspection. Check cabin ventilation inlet and carburettor heating inlet for condition and free of obstruction. Check stall strip.
10.	Left wing top and bottom panels	Visual inspection
11.	Left winglet, nav and strobe lights, static discharge wick	Check for integrity and fixing
12.	Left aileron and balance mass	Visual inspection, remove tie-down devices and control locks if employed.
13.	Left Flap and hinges	Visual inspection
14.	Left static port	Remove protective cap – Visual inspection
15.	Antennas	Check for integrity

16.	Gear pump, external power and battery compartment	<i>Check emergency landing gear extension system pressure (low pressure limit: 20 bar), external power and battery compartments closure.</i>
17.	Horizontal and vertical empennage and tabs. Static discharge wicks.	<i>Check the actuating mechanism of control surfaces and the connection with related tabs. Check wicks for integrity. Remove tie-down device if employed.</i>
18.	Stabilator leading edge	<i>Check for integrity</i>
19.	Fuselage top and bottom skin	<i>Visual inspection</i>
20.	Right static port	<i>Remove protective cap – Visual inspection</i>
21.	Right Flap and hinges	<i>Visual inspection</i>
22.	Right aileron and balance weight	<i>Visual inspection, remove tie-down devices and control locks if employed.</i>
23.	Right winglet, nav and strobe lights, static discharge wick	<i>Check for integrity and fixing and lighting</i>
24.	Right wing top and bottom panels	<i>Visual inspection</i>
25.	Right wing leading edge	<i>Visual inspection. Check cabin ventilation inlet and carburettor heating inlet for condition and free of obstruction. Check stall strip.</i>
26.	Right fuel tank	<i>Check that the refuelling port cap is properly secured, then perform the fuel tank sump drainage operating the related valve which, after operation, must be checked closed. Fuel must be checked for water and sediment. Verify the tank vent outlet is clear.</i>
27.	Propeller and spinner:	<i>The propeller blades and spinner should be free of cracks, nicks, dents and other defects and should rotate freely. Check fixing and lack of play between blades and hub.</i>
28.	Right engine nacelle	<i>Apply check procedure reported in the walk-around station 5 and 6.</i>
29.	Passenger door and cabin	<i>Check door for integrity. Check safety belts for integrity and baggage for correct positioning and fastening. Check ditching emergency exit safety lock. Check passengers ventilation ports for proper setting.</i>

30.	Right main landing gear	<i>Apply check procedure reported in the walk-around Station 2</i>
31.	Wheel chock	<i>Remove if employed</i>
32.	Bottom fuselage antennas	<i>Check for integrity</i>
33.	Right cabin ram-air inlet	<i>Visual inspection</i>
34.	Right Pitot tube	<i>Remove protective cap and check for any obstruction</i>
35.	Nose landing gear	<i>Check tire status (cuts, bruises, cracks and excessive wear),slippage markers integrity, gear structure and re-traction mechanism, shock absorber and gear doors attachments. There should be no sign of hydraulic fluid leakage.</i>
36.	Radome	<i>Check for integrity</i>
37.	Radome access door	<i>Visual inspection</i>
38.	Left Pitot tube	<i>Remove protective cap and check for any obstruction</i>

**NOTE**

*Avoid blowing inside Pitot-tube and inside airspeed indicator system's static ports as this may damage instruments.*

INTENTIONALLY LEFT BLANK

### 3.3 COCKPIT INSPECTIONS



*Instruct passengers on how to use safety belts and normal / emergency exits. Passenger embarkation should be done, avoiding contact with hot / oily parts such as engine exhaust pipes, drainage tubes and wheel brakes, or sharp wing control surfaces edges. Do not smoke on board.*



*Clean the displays using a clean, lint-free cloth and an eyeglass lens cleaner that is specified as safe for anti-reflective coatings. Cleaners containing ammonia will harm the anti-reflective coating.*

- |                                 |   |
|---------------------------------|---|
| 1. Parking brake                | <i>CHECK ENGAGED</i>                                    |
| 2. AFM and Garmin Pilot's Guide | <i>CHECK on board</i>                                   |
| 3. Weight and balance           | <i>CHECK if within the limits</i>                       |
| 4. Flight controls              | <i>Remove seat belt used as lock</i>                    |
| 5. PFD and MFD                  | <i>CHECK clean</i>                                      |
| 6. Seat                         | <i>Adjust as required</i>                               |
| 7. Seat belt                    | <i>Fastened</i>   |
| 8. Passenger briefing           | <i>Completed</i>  |
| 9. Doors                        | <i>CLOSED AND LOCKED</i>                                |
| 10. Landing gear control lever  | <i>CHECK DOWN</i>                                       |
| 11. Breakers                    | <i>All IN</i>   |
| 12. MASTER SWITCH               | <i>ON</i>   |
| 13. Fuel quantity               | <i>CHECK</i>  |
| 14. RH fuel selector            | <i>RIGHT</i>  |
| 15. LH fuel selector            | <i>LEFT</i>   |
| 16. RH Electrical Fuel Pump     | <i>ON, check fuel pressure gauge correct operation.</i> |
| 17. RH Electrical Fuel pump     | <i>OFF, check pressure decreased at zero</i>            |
| 18. LH Electrical Fuel Pump     | <i>ON, check fuel pressure gauge correct operation.</i> |
| 19. LH Electrical Fuel pump     | <i>OFF, check pressure decreased at zero</i>            |
| 20. Strobe light                | <i>ON</i>   |
| 21. Landing gear lights         | <i>TEST</i>   |
| 22. ELT                         | <i>CHECK set to ARM</i>                                 |
| 23. Fire detector               | <i>TEST</i>   |
| 24. Engine levers friction      | <i>Adjust if required</i>                               |
| 25. Flight controls             | <i>CHECK free</i>                                       |

- |     |   |   |
|-----|---|---|
| 26. | Alternate static port                             | <i>CHECK closed</i>   |
| 27. | Cabin heat  | <i>CLOSED</i>   |
| 28. | Flaps   | <i>Operate control to FULL position.<br/>Verify extension. Retract flaps.</i> |
| 29. | Pitch trim control                                | <i>Set to neutral position.</i>   |
| 30. | Rudder trim control                               | <i>Set to neutral position.</i>   |
| 31. | Eng. Starting Battery Voltmeter<br>(if installed) | <i>Check 12 to 14 Volt</i>  |

### 3.4 ENGINE STARTING

**CAUTION**

*Avionics switches must be set OFF during engine starting to prevent avionic equipment damage.*

- |   |                 |                         |
|---|-----------------|-------------------------|
| 1 | Start clearance | <i>Obtain if needed</i> |
| 2 | CHRONOMETER     | <i>START</i>            |

#### **Right engine starting**

- |   |                    |                       |
|---|--------------------|-----------------------|
| 1 | RH Throttle lever  | <i>IDLE</i>           |
| 2 | RH Carburetor heat | <i>OFF</i>            |
| 3 | RH Propeller Lever | <i>FULL FORWARD</i>   |
| 4 | RH Choke           | <i>ON if required</i> |

#### **NOTE**

##### ***Cold engine***

*Throttles idle (fully closed), chokes fully opened.*

*Soon after starting, advance the throttle to let the propeller reach 800 RPM and slowly close the choke. Keep engine at 900 RPM for warm up period.*

##### ***Hot engine***

*Park the aircraft with the nose pointing into wind in order to aid cooling. Keep chokes closed and slowly open the throttles one inch while cranking.*

##### ***Flooded Engine after engine start failure***

*Keep chokes closed, open throttle fully and start the engine, then quickly reduce throttles to idle*

- |   |                          |   |
|---|--------------------------|---|
| 5 | RH Electrical Fuel pump  | <i>ON, check advisory light ON and positive fuel press build up</i> |
| 6 | STROBES                  | <i>ON</i>   |
| 7 | RH engine propeller zone | <i>CHECK free</i>   |
| 8 | RH ignitions switches    | <i>BOTH ON</i>  |

**WARNING**

*Ensure that the area around engine propeller disc is clear from people and obstacles. Call out for propeller free.*

9	RH start pushbutton	<i>PUSH</i>
10	RH Field	<i>ON</i>
11	RH engine oil gauge	<i>CHECK if increasing within 10 sec. (max 7 bar in cold operation)</i>
12	RH Throttle lever	<i>Advance to reach 1200 RPM</i>
13	RH Choke	<i>OFF</i>
14	RH Avionics	<i>ON</i>
15	RH Cross bus	<i>ON</i>
16	RH Ammeter	<i>CHECK Amps positive</i>
17	Voltmeter	<i>CHECK 12 to 14 Volt</i>
18	Chronometer	<i>Start</i>

**Left engine starting**

1	LH Throttle lever	<i>IDLE</i>
2	LH Carburetor heat	<i>OFF</i>
3	LH Propeller Lever	<i>FULL FORWARD</i>
4	LH Choke	<i>ON if required</i>
5	LH Electrical Fuel pump	<i>ON, check advisory light ON and positive fuel press build up</i>
6	LH engine propeller zone	<i>CHECK free</i>
7	LH ignitions switches	<i>BOTH ON</i>

**WARNING**

*Ensure that the area around engine propeller disc is clear from people and obstacles. Call out for propeller free.*

8	LH start pushbutton	<i>PUSH</i>
9	LH Field	<i>ON</i>
10	LH engine oil gauge	<i>CHECK if increasing within 10 sec. (max 7 bar in cold operation)</i>
11	LH Throttle lever	<i>ADVANCE to reach 1200 RPM</i>

- |    |              |                            |
|----|--------------|----------------------------|
| 12 | LH Choke     | <i>OFF</i>                 |
| 13 | LH Avionics  | <i>ON</i>                  |
| 14 | LH Cross bus | <i>ON</i>                  |
| 15 | LH Ammeter   | <i>CHECK Amps positive</i> |

### 3.5 BEFORE TAXIING

- |   |  |                        |
|---|--|------------------------|
| 1 | Let the engines warm up to a minimum oil temperature of 50°C at 1200 RPM |                        |
| 2 | Nav , Taxi and Landing lights  | <i>ON</i>              |
| 3 | Transponder  | <i>Stand-by</i>        |
| 4 | Passengers and crews seat belts  | <i>Fastened</i>        |
| 5 | Passengers and crews headphones  | <i>Set as required</i> |

### 3.6 TAXIING

**NOTE**

*Ensure that the main and passengers' doors warning lights are turned off.*

- |   |                         |  |
|---|-------------------------|--|
| 1 | LH/RH Fuel Selector     | <i>As required</i>                                       |
| 2 | LH and RH fuel pressure | <i>Monitor</i>   |
| 3 | Parking Brake           | <i>RELEASE</i>   |
| 4 | Flight instruments      | <i>CHECK</i>   |
| 5 | Engine instruments      | <i>CHECK</i>   |
| 6 | Altimeter               | <i>SET both and crosscheck<br/>max difference 150 ft</i> |
| 7 | Brakes                  | <i>TEST</i>  |



### 3.7 PRIOR TO TAKEOFF

- |    |  |  |
|----|--|--|
| 1  | Parking Brake  | ENGAGED  |
| 2  | RH Fuel Selector                                       | RIGHT  |
| 3  | LH Fuel Selector                                       | LEFT   |
| 4  | LH and RH fuel pressure                                | CHECK  |
| 5  | LH and RH Engine parameters checks:                    |  |
|    | ≠ Oil temperature:                                     | 90° ≡ 110° C<br>(or 50° ÷ 130 ° C, if MOD2006/002 is applied).   |
|    | • CHT / CT:  | 50° ≡ 135° / 120° C  |
|    | • Oil pressure:  | 2-5 bar (above 1400 RPM): 0.8 bar (below 1400 RPM)   |
|    | • Fuel pressure:                                       | 2.2 – 5.8 psi (0.15 - 0.40 bar)<br>*2.2 – 7.26 psi (0.15 – 0.50 bar)   |
|    | *applicable for fuel pump part no.893110 and no.893114 |  |
| 6  | LH and RH Generator lights                             | CHECK BOTH OFF   |
| 7  | LH and RH Propeller Lever                              | FULL FORWARD   |
| 8  | LH and RH Throttle Lever                               | 1650 RPM   |
| 9  | RH Ignitions switches                                  | Set L / R / BOTH (RPM drop with single ignition circuit selected must not exceed 130 prop's RPM; maximum RPM difference by use of either circuits LEFT or RIGHT cannot overcome 50 RPM)  |
| 10 | RH Propeller Lever                                     | GOVERNOR CHECK<br>a) Reduce prop speed to 1200 RPM;<br>b) move propeller lever back to full forward position;<br>c) repeat a) and b) 3 times;<br>d) verify that the governor closely and firmly controls the RPM;<br>e) verify that 1650 prop RPM are restored with prop lever in full forward position. |
- NOTE** Do not cause the propeller speed drop below 1150 RPM in any case.
- |    |                       |   |
|----|-----------------------|---|
| 11 | RH Carburettor heat   | ON, verify propeller RPM decreasing about 100 RPM   |
| 12 | RH Carburettor heat   | OFF   |
| 13 | RH engine instruments | CHECK parameters if within green arcs   |
| 14 | LH Ignitions switches | Set L / R / BOTH (RPM drop with single ignition circuit selected must not exceed 130 prop's RPM; maximum RPM difference by use of either circuits LEFT or RIGHT cannot overcome 50 RPM) |

**15 LH Propeller Lever****GOVERNOR CHECK**

- a) Reduce prop speed to 1200 RPM;*
- b) move propeller lever back to full forward position;*
- c) repeat a) and b) 3 times;*
- d) verify that the governor closely and firmly controls the RPM;*
- e) verify that 1650 prop RPM are restored with prop lever in full forward position.*

**NOTE**

*Do not cause the propeller speed drop below 1150 RPM in any case.*

**16 LH Carburettor heat**

*ON, verify propeller RPM decreasing about 100 RPM*

**17 LH Carburettor heat**

*OFF*

**18 LH engine instruments**

*CHECK parameters if within green arcs*

**19 LH and RH Fuel quantity indicator**

*CHECK consistent with fuel plan*

**20 Flaps**

*T/O or as required (see Section 5, Take OFF performances)*

**21 Pitch trim and rudder trim**

*SET neutral position*

**22 Flight controls**

*Check free*

**23 Seat belts fastened and doors closed and locked**

*CHECK*

**3.8 LINE-UP****1 Parking Brake**

*RELEASE, check full in*

**2 Annunciator window**

*CHECK cautions and warnings OFF*

**3 RH Fuel Selector**

*RIGHT*

**4 LH Fuel Selector**

*LEFT*

**5 Pitot heat**

*as required*

**6 XPDR**

*SET ALT*

**7 Magnetic compass**

*CHECK*

**8 AHRS**

*CROSS CHECK*

## 3.9 TAKEOFF AND CLIMB

- |   |                                |                              |
|---|--------------------------------|------------------------------|
| 1 | Landing light                  | ON                           |
| 2 | LH and RH Electrical Fuel pump | BOTH ON                      |
| 3 | Carburettors heat              | CHECK OFF                    |
| 4 | LH and RH Propeller Lever      | FULL FORWARD                 |
| 5 | LH and RH Throttle Lever       | FULL POWER                   |
| 6 | Engines instruments            | Parameters within green arcs |
| 7 | Rotation speed                 |                              |

MTOW 1180kg	MTOW 1230 kg
Vr = 64 KIAS	Vr = 65 KIAS

- |    |                                     |  |
|----|-------------------------------------|--|
| 8  | Apply brakes to stop wheel spinning |  |
| 9  | Landing gear control knob           | UP: check green lights and TRANS light turned OFF within about 20" |
| 10 | Landing and taxi lights             | OFF above 10000 ft   |
| 11 | LH and RH Propeller Lever           | Set max cont power at safe altitude                                |

**CAUTION**

Max take off power must be limited to 5 minutes. Reduce Throttles MAP power before retracting Propeller to 2200 RPM or below.

- |    |                                |          |
|----|--------------------------------|----------|
| 12 | LH and RH Electrical Fuel pump | BOTH OFF |
|----|--------------------------------|----------|

NOTE

*It is recommended to retract landing gear when a positive climb rate is ensured at the applicable best speed (V<sub>Y</sub> or V<sub>X</sub> as necessary).*

*It has been demonstrated that best climb rate is always obtained with flaps in UP position: refer to Section 5, "Take off rate of climb" and "Enroute rate of climb" tables.*

*Noteworthy best climb gradient speed (V<sub>X</sub>) flaps UP is lower than best climb speed (V<sub>X</sub>) flaps T/O up to 6000 ft (density altitude). Refer to Section 5, "Best climb gradient speed" table.*

### 3.10 CRUISE

- 1 LH and RH Propeller Lever *SET to 1900-2250 RPM*

**CAUTION**

*Throttles MAP decrease should be made before propeller speed reduction below 2200 RPM, as, contrariwise, Propeller Lever increase RPM should be set before engine Throttle Levers are advanced.*

- 2 Engine parameters check (LH and RH)

≠ Oil temperature:  $90^{\circ} - 110^{\circ} C$   
*(or  $50^{\circ} - 130^{\circ} C$ , if MOD2006/002 is applied).*

≠ CHT/CT:  $50^{\circ} - 135^{\circ} / 50^{\circ} - 120^{\circ} C$

≠ Oil pressure:  $2 - 5 \text{ bar}$ .

≠ Fuel pressure:  $2.2 - 5.8 \text{ psi}$   
 $*2.2 - 7.26 \text{ psi } (0.15 - 0.50 \text{ bar})$

*\*applicable for fuel pump part no.893110 and no.893114*

- 3 Carburettor heat as needed (*see also instructions addressed on Section 3.*)

**WARNING**

*Deselect and do not use Auto Pilot if possible icing condition area is inadvertently entered.*

- 4 Fuel balance and crossfeed *check as necessary*

**NOTE**

*To evaporate possibly accumulated condensation water, once per flight day (for approximately 5 minutes)  $100^{\circ} C$  ( $212^{\circ} F$ ) oil temperature must be reached.*

### 3.11 TURBULENT AIR OPERATION

In keeping with good operating practice used in all aircraft, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural loads caused by gusts and to allow for inadvertent speed build-ups, which may occur as a result of the turbulence or of distractions caused by the conditions.

## 3.12 DESCENT AND APPROACH

- |   |                   |                                       |
|---|-------------------|---------------------------------------|
| 1 | Propellers        | <i>Set to Max Continuous 2250 RPM</i> |
| 2 | Carburettors heat | <i>As required</i>                    |
| 3 | Altimeter setting | <i>QNH set and crosscheck</i>         |

## 3.13 BEFORE LANDING

- | 1                              | Rear passengers seats  | <i>Seats set at full aft and lower position</i>  |              |                                |                                |                               |
|--------------------------------|--|--|--------------|--------------------------------|--------------------------------|-------------------------------|
| 2                              | LH and RH Electrical Fuel pump   | <i>BOTH ON</i>   |              |                                |                                |                               |
| 3                              | On downwind leg:   |  |              |                                |                                |                               |
|                                | <table border="1" style="width: 100%;"> <tr> <th style="width: 50%;">MTOW 1180kg</th> <th style="width: 50%;">MTOW 1230 kg</th> </tr> <tr> <td><i>V<sub>FE</sub>= 119KIAS</i></td> <td><i>V<sub>FE</sub>=122KIAS</i></td> </tr> </table> | MTOW 1180kg  | MTOW 1230 kg | <i>V<sub>FE</sub>= 119KIAS</i> | <i>V<sub>FE</sub>=122KIAS</i>  | <i>Flaps T/O</i>              |
| MTOW 1180kg                    | MTOW 1230 kg   |  |              |                                |                                |                               |
| <i>V<sub>FE</sub>= 119KIAS</i> | <i>V<sub>FE</sub>=122KIAS</i>  |  |              |                                |                                |                               |
| 4                              | Speed below applicable VLO/VLE   | <i>Landing gear control knob - DOWN –<br/>Check green lights ON</i>  |              |                                |                                |                               |
| 5                              | Carburettors heat  | <i>CHECK OFF</i>   |              |                                |                                |                               |
| 6                              | LH and RH Propeller Lever  | <i>FULL FORWARD</i>  |              |                                |                                |                               |
| 7                              | On final leg: speed below 93 KIAS  | <i>Flaps FULL</i>  |              |                                |                                |                               |
| 8                              | Final Approach Speed   | <table border="1" style="width: 100%;"> <tr> <th style="width: 50%;">MTOW 1180kg</th> <th style="width: 50%;">MTOW 1230 kg</th> </tr> <tr> <td><i>V<sub>APP</sub>= 70KIAS</i></td> <td><i>V<sub>APP</sub>=71KIAS</i></td> </tr> </table> | MTOW 1180kg  | MTOW 1230 kg                   | <i>V<sub>APP</sub>= 70KIAS</i> | <i>V<sub>APP</sub>=71KIAS</i> |
| MTOW 1180kg                    | MTOW 1230 kg   |  |              |                                |                                |                               |
| <i>V<sub>APP</sub>= 70KIAS</i> | <i>V<sub>APP</sub>=71KIAS</i>  |  |              |                                |                                |                               |
| 9                              | Landing and taxi light   | <i>ON</i>  |              |                                |                                |                               |
| 10                             | Touchdown speed  | <i>65 KIAS</i>   |              |                                |                                |                               |

## 3.14 BALKED LANDING/MISSED APPROACH

- |   |                           |                     |
|---|---------------------------|---------------------|
| 1 | LH and RH Propeller Lever | <i>FULL FORWARD</i> |
| 2 | LH and RH Throttle Lever  | <i>FULL POWER</i>   |

**CAUTION**

*Propeller Lever increase to max RPM should be attained before engine Throttle Levers are advanced to max take off power. Max take off power must be limited to 5 minutes.*

- |   |              |   |
|---|--------------|---|
| 3 | Flaps        | <i>T/O</i>  |
| 4 | Speed        | <i>Keep over 62 KIAS, climb to V<sub>Y</sub> or V<sub>X</sub> as applicable</i> |
| 5 | Landing gear | <i>UP as positive climb is achieved</i>   |
| 6 | Flaps        | <i>UP</i>   |

NOTE

*It is recommended to retract landing gear when a positive climb rate is ensured at the applicable best speed (V<sub>Y</sub> or V<sub>X</sub> as necessary). It has been demonstrated that best climb rate is always obtained with flaps in UP position: refer to Section 5, "Take off rate of climb" and "Enroute rate of climb" tables.*

*Noteworthy best climb gradient speed (V<sub>X</sub>) flaps UP is lower than best climb speed (V<sub>X</sub>) flaps T/O up to 6000 ft (density altitude). Refer to Section 5, "Best climb gradient speed" table.*

## 3.15 AFTER LANDING

- |   |                                |                 |
|---|--------------------------------|-----------------|
| 1 | LH and RH Electrical Fuel pump | <i>BOTH OFF</i> |
| 2 | Flaps                          | <i>0°</i>       |
| 3 | Landing light                  | <i>OFF</i>      |

### 3.16 PARKING/SHUT DOWN

**NOTE**

*It is always suggested to park the aircraft with the nose pointing into wind to improve cooling after shut down.*

- |   |                       |   |
|---|-----------------------|---|
| 1 | Parking brake         | Engage  |
| 2 | Taxi light            | OFF   |
| 3 | Engines               | Allow for cooling down 1 minute at idle power |
| 4 | LH and RH AVIONIC BUS | OFF   |
| 5 | LH and RH CROSS BUS   | OFF   |
| 6 | Flaps                 | Check in UP                                   |
| 7 | Trims                 | Check neutrals                                |
| 8 | Navigation lights     | OFF   |

**NOTE**

*Ensure the engine is at its lowest possible idle speed before selecting ignitions off.*

- |    |                              |                      |
|----|------------------------------|----------------------|
| 9  | Ignitions                    | Turn OFF one at time |
| 10 | Doors safety locks           | Check OFF            |
| 11 | LH/RH Field                  | OFF                  |
| 12 | All external lights          | OFF                  |
| 13 | Master Switch                | OFF                  |
| 14 | Emg Batt / Emg cockpit light | Check OFF            |



**WARNING**

*Before disembarkation verify propellers are fully stopped.*



**CAUTION**

*Instruct passengers to fully open pax door (against nacelle stop) and depart alongside aircraft fuselage, avoiding contact with hot / oily parts such as engine exhaust pipes, drainage tubes and wheel brakes, or sharp wing control surfaces edges.*



**CAUTION**

*Crew should avoid propeller disc area crossing while proceeding alongside a fully opened pilot's door (up to 110°).*

### 3.17 POSTFLIGHT CHECKS

- |   |  |                          |
|---|--|--------------------------|
| 1 | Protective cover for Pitot tubes, stall warning and static port plugs. | <i>Install</i>           |
| 2 | Lock one control wheel with safety belt.                               |                          |
| 3 | Wheel chocks   | <i>Place under MLG</i>   |
| 4 | Aileron lock   | <i>Place and tighten</i> |
| 5 | Pilot and passengers doors.  | <i>Close and latch</i>   |



#### 4. ADDITIONAL GUIDANCE FOR RNAV

Experience of RNAV systems, and Flight FMS in general, has identified the pitfalls of way-point entry error at the receiver as well as inaccuracies and errors in the database itself.

Research and experience have both shown that human error, often the result of a lack of familiarity with the airborne equipment, represents the major hazard in operations using RNAV systems. Therefore, it is imperative that pilots understand their system thoroughly and are able to determine whether it is safe to proceed.

This requires robust procedures, which check for possible errors in the computer database, monitor continued performance of the RNAV systems and enable pilots to identify and avoid not only their own mistakes but also errors in the information presented to them.

Flight planning on RNAV routes should include the following recommendation.

- During the pre-flight planning phase, given a GPS constellation of 23 satellites or less (22 or less for GPS stand-alone equipment that incorporate pressure altitude aiding), the availability of GPS integrity (RAIM) should be confirmed for the intended flight (route and time). This should be obtained from a prediction program either ground-based, or provided as an equipment function, or from an alternative method acceptable to the Authority;
- Where a navigation data base is installed, the data base validity (current AIRAC cycle) should be checked before flight;
- Traditional navigation equipment (e.g. VOR, DME and ADF) should be selected to available aids so as to allow immediate cross-checking or reversion in the event of loss of GPS navigation capability.

##### 1) Pre-flight Planning

During the pre-flight planning phase, the availability of the navigation infrastructure, required for the intended operation, including any non-RNAV contingencies, must be confirmed for the period of intended operation. Availability of the onboard navigation equipment necessary for the route to be flown must be confirmed. The onboard navigation database must be appropriate for the region of intended operation and must include the navigation aids, waypoints, and coded terminal airspace procedures for the departure, arrival and alternate airfields.

Where the responsible airspace authority has specified in the AIP that dual P-RNAV systems are required for specific terminal P-RNAV procedure, the availability of dual P-RNAV systems must be confirmed. This typically will apply where procedures are effective below the applicable minimum obstacle clearance altitude or where radar coverage is inadequate for the purposes of supporting P-RNAV. This will also take into account the particular hazards of a terminal area and the feasibility of contingency procedures following loss of P-RNAV capability.

RAIM availability must be confirmed with account taken of the latest information

## 2) *Departure*

At system initialisation, the flight crew must confirm that the navigation database is current and verify that the aircraft position has been entered correctly. The active flight plan should be checked by comparing the charts, SID or other applicable documents, with the map display. This includes confirmation of the waypoint sequence, reasonableness of track angles and distances, any altitude or speed constraints, and, where possible, which waypoints are fly-by and which are fly-over. If required by a procedure, a check will need to be made to confirm that updating will use a specific navigation aid(s), or to confirm exclusion of a specific navigation aid. A procedure shall not be used if doubt exists as to the validity of the procedure in the navigation database

**The creation of new waypoints by manual entry into the RNAV system by the flight crew is not permitted as it would invalidate the affected P-RNAV procedure.**

Route modifications in the terminal area may take the form of radar headings or 'direct to' clearances and the flight crew must be capable of reacting in a timely fashion. This may include the insertion in the flight plan of waypoints loaded from the database.

During the procedure and where feasible, flight progress should be monitored for navigational reasonableness, by cross-checks, with conventional navigation aids using the primary display

## 3) *Arrival*

Prior to the arrival phase, the flight crew should verify that the correct terminal procedure has been loaded. The active flight plan should be checked by comparing the charts with the map display. This includes confirmation of the waypoint sequence, reasonableness of track angles and distances, any altitude or speed constraints, and, where possible, which waypoints are fly-by and which are fly-over. If required by a procedure, a check will need to be made to confirm that updating will exclude a particular navigation aid. A procedure shall not be used if doubt exists as to the validity of the procedure in the navigation database.

Note: as a minimum, the arrival checks could be a simple inspection of a suitable map display that achieves the objectives of this paragraph.

**The creation of new waypoints by manual entry into the RNAV system by the flight crew would invalidate the P-RNAV procedure and is not permitted.**

Where the contingency to revert to a conventional arrival procedure is required, the flight crew must make the necessary preparation.

During the procedure and where feasible, flight progress should be monitored for navigational reasonableness by cross-checks with conventional navigation aids using the primary display

Route modifications in the terminal area may take the form of radar headings or 'direct to' clearances and the flight crew must be capable of reacting in a timely fashion.

Although a particular method is not mandated, any published altitude and speed constraints must be observed.

In the event that either the GPS or the EGNOS signal is not available at the destination, by the nature of the system, and its susceptibility to interference, there exists the possibility that it will also be unavailable over a wide area. Therefore, it is probable that the signal will also be unavailable at a nearby diversion aerodrome.

Notwithstanding any normal operational requirements for the identification of an alternate aerodrome, where a RNAV approach is to be flown in conditions where a visual approach will not be possible; pilots should always ensure that either:

- 1) A different type of approach system is available at the destination, not dependent on GPS data and for which the weather is forecast to be suitable to enable a landing to be made from that approach, or;
- 2) There is at least one alternate destination within range, where a different type of approach system is available, which is not dependent on GPS data and for which the weather is forecast to be suitable to enable a landing to be made from that approach.

#### 4.1 APPROACH APPLICATIONS

##### NOTE

*When GPS is not approved for the selected final approach course, the message “NOT APPROVED FOR GPS” is displayed. GPS provides guidance for the approach, but the HIS must be switched to a NAV receiver to fly the final course of the approach*

##### NOTE

*If certain GPS parameters (SBAS, RAIM, etc.) are not available, some published approach procedures for the desired airport may not be displayed in the list of available approaches.*

An Approach Procedure (APPR) can be loaded at any airport that has one available, and provides guidance for non-precision and precision approaches to airports with published instrument approach procedures.

##### NOTE

*Only one approach can be loaded at a time in a flight plan. If an approach is loaded when another approach is already in the active flight plan, the new approach replaces the previous approach. The route is defined by selection of an approach and the transition waypoints.*

Whenever an approach is selected, the choice to either “load” or “activate” is given. “Loading” adds the approach to the end of the flight plan without immediately using it for navigation guidance. This allows continued navigation via the intermediate waypoints in the original flight plan, but keeps the procedure available on the Active Flight Plan Page for quick activation when needed. “Activating” also adds the procedure to the end of the flight plan but immediately begins to provide guidance to the first waypoint in the approach.

When selecting an approach, a “GPS” designation to the right of the procedure name indicates the procedure can be flown using the GPS receiver. Some procedures do not have


this designation, meaning the GPS receiver can be used for supplemental navigation guidance only.

**NOTE**

*If the GPS receiver cannot be used for primary guidance, the appropriate navigation receiver must be used for the selected approach (e.g., VOR or ILS). The final course segment of ILS approaches, for example, must be flown by tuning the NAV receiver to the proper frequency and selecting that NAV receiver on the CDI*

The G1000 SBAS GPS allows for flying LNAV and LPV approach service levels according to the published chart.

A sample of how the active approach service level is annunciated on the HSI is shown in the following table:

HSI Annunciation	Description	Example on HSI
LNAV	RNAV GPS approach using published LNAV minima	 <p><b>Approach Service Level</b></p>
LPV (available only if SBAS available)	RNAV GPS approach using published LPV minima	

Before reaching the IAF, the flight crew should verify that the correct procedure has been loaded into the receiver's route or flight plan. A comparison with the approach chart should be made including the following:

- The waypoint sequence.
- Reasonableness of the tracks and distances of the approach legs, accuracy of the inbound course and mileage of the FAS.
- Verify from the charts, map display or CDU, which waypoints are fly-by and which are fly-over.
- Check any map display to ensure the track lines actually 'fly-over' or 'fly-by' the respective waypoints in the procedure.

By the time the aircraft reaches the IAF the pilot should have completed the above and been cleared for the approach. Also, the approach must have been activated in the receiver at least by this time.

Approach Applications which are classified as RNP Approach (APCH) in accordance with ICAO Doc 9613 Performance Based Navigation (PBN) Manual (and ICAO state Letter SP65/4-10/53) give access to minima (on an instrument approach procedure) designated as:

**LNAV (Lateral Navigation)**

This is a Non-Precision or 2D Approach with Lateral only navigation guidance provided by GNSS and an Aircraft Based Augmentation System (ABAS). Receiver Autonomous Integrity Monitoring (RAIM) is a form of ABAS. Lateral guidance is linear with accuracy to within +/- 0.3 NM parallel to either side of the final approach track.

**LPV (Localiser Performance with Vertical Guidance)**

This is an Approach Procedure with Vertical Guidance. The Lateral and Vertical guidance is provided by GPS and SBAS. Lateral and vertical guidance are angular with increasing sensitivity as the aircraft progresses down the final approach track; much like an ILS indication. LPV approach and annunciation on HSI is available only if SBAS is available.



*Before selecting a LPV approach, make sure SBAS is indicated ACTIVE in the GPS status box on AUX-GPS STATUS page on MFD.*

*If DISABLED highlight the appropriate SBAS SELECTION Box under SBAS softkey under AUX-GPS Status Page on MFD*



*Should SBAS signal be lost, augmentation is lost. It may be possible to continue with LNAV only but this is reliant on the availability of RAIM.*

**NOTE:** The instrument approach procedures associated with RNP APCH are entitled RNAV (GNSS) to reflect that GNSS is the primary navigation system. With the inherent onboard performance monitoring and alerting provided by GNSS, the navigation specification qualifies as RNP, however these procedures pre-date PBN, so the chart name has remained as RNAV.

**Missed approach procedures**

Before commencing an RNAV (GNSS) missed approach, a MAP should be possible without reference to GPS derived navigation so that, in the event of a loss of GPS accuracy or loss of integrity during the approach, a safe return to above Minimum Sector Altitude can be made.

This may be possible by dead reckoning (DR) navigation but where this is not possible and the MAP requires reference to terrestrial navigation aids, these must be available, tuned and correctly identified before passing the IAF and remain available throughout the approach.

Reasons for a missed approach are many and if GPS information remains available for the MAP, the pilot must be able to sequence the system correctly past the MAP, in order to follow the published MAP correctly.

Pilots should be fully competent in the necessary selection routines required by their own equipment, in order to transition to the MAP and preserve accurate navigation throughout.

When GPS navigation is NOT available for the MAP, it may be necessary to reset the display function of the HSI/CDI to disengage GPS information and regain VOR/LOC display. Pilots must be fully conversant with navigation display selections in order safely to follow the MAP.



**Abnormal procedures for approaches**

As the aircraft approaches the FAF (LNAV Only, without SBAS), the receiver automatically perform a final RAIM prediction for the approach. The receiver will not enter the approach mode if this RAIM prediction is negative. In this case, the approach should be discontinued.

However, this RAIM check assumes availability of the full constellation and will not take account of scheduled interruptions or failures. This can lead to a successful RAIM prediction at this point when the RAIM function itself is not available.

If RAIM is lost after passing the FAF the equipment should continue to provide navigation, where possible for five minutes, before giving a RAIM loss indication and this should be enough to complete the approach.

Should RAIM detect an out of tolerance situation, a warning will be given and a missed approach should be initiated immediately

The approach should always be discontinued:

- (a) If the receiver fails to engage the correct approach mode or;
- (b) In case of Loss Of Integrity (LOI) monitoring or;
- (c) Whenever the HSI/CDI indication (or GP indication where applicable) exceeds half scale displacement or;
- (d) If a RAIM (or equivalent) warning is activated or;
- (e) If RAIM (or equivalent) function is not available and annunciated before passing the FAF.

**4.2 PBN (RNAV & RNP) OPERATIONAL ELIGIBILITY**

The Garmin GNSS navigation system as installed in this airplane is approved for navigation using GPS and SBAS (within the coverage of a Satellite Based Augmentation System complying with ICAO Annex 10) for IFR en-route, terminal area, precision and non-precision approach operations.

Both GNSS receivers are required to be operating and receiving usable signals except for routes requiring only one Long Range Navigation sensor.

The G1000 System has been shown to be eligible for:

- B-RNAV (RNAV-5)
- RNAV1 / P-RNAV (RNP-1) Enroute and Terminal navigation
- RNP APCH LNAV (does not include APV BARO-VNAV operation which is not cleared)
- LPV with SBAS

provided that the G1000 is receiving usable navigation information from at least one GPS receiver.

## 5. GROUND TOWING, PARKING AND MOORING

### 5.1 TOWING

**CAUTION**

*When the a/c is moved on the ground, the Master Switch must be turned ON until the a/c is parked.*

To tow the aircraft it is necessary to use a metal stiff bar connected to the nose gear.

**WARNING**

*Do not turn nose wheel above 20° either side of center: greater steering angles can damage the wheel stop. The tow bar must be removed before engines starting.*

### 5.2 PARKING

#### **General**

Under normal weather conditions, the airplane may be parked and headed in a direction that will facilitate servicing without regard to prevailing winds. Ensure that it is sufficiently protected against adverse weather conditions and present no danger to other aircraft.

#### **Procedure**

1. Position airplane on levelled surface, headed into the prevailing wind, if practical.
2. Engage parking brake and install control locks
3. Secure pilot control wheel by wrapping the seat belt around it.

**NOTE:**

*Do not engage the parking brakes at low ambient temperature; accumulation of moisture may cause the brakes to freeze. In this case use wheel chocks.*

In case of long time parking or overnight parking, it is recommended to moor the a/c as shown on Para. 4.3.

**CAUTION**

*Moorings is strongly recommended when the wind is more than 15 knots and the a/c is completely refuelled.*

### 5.3 MOORING

The aircraft is moored to insure its immovability, protection, and security under various weather conditions.



**CAUTION**

*Mooring is strongly recommended when the wind is more than 15 knots and the a/c is completely refuelled.*

#### Procedure

1. Position airplane on levelled surface and headed into the prevailing wind.
2. Center nose wheel, engage parking brake and/or use the wheel chocks.


#### **NOTE:**

*Do not engage the parking brakes at low ambient temperature; accumulation of moisture may cause the brakes to freeze. In this case use wheel chocks.*

3. Secure pilot control wheel by wrapping the seat belt around it
4. Assure flaps are retracted
5. Electrically ground airplane, by connecting ground cable to the engine muffle
6. Install control locks and protective plugs.
7. Close and lock cabin doors.
8. Secure tie-down cables to the nose gear leg (in correspondence of the wheel fork) and to the wings and tail cone tie-down rings at approximately 45 degree with respect to the ground. (Refer to following figures)


#### **NOTE:**

*Additional preparation for high winds includes tie-down ropes from the main landing gear forks employment.*



**Mooring – front view**





Mooring – side view

INTENTIONALLY LEFT BLANK

<b>Supplement G19: pages replacement instructions</b>
---

## SECTION 5 - PERFORMANCES

Apply following instruction:

**Supplement G19 – PERFORMANCES pages replace  
basic AFM Section 5 as a whole.**

INTENTIONALLY LEFT BLANK

## SECTION 5 - PERFORMANCES

## INDEX

1.	Introduction.....	1
2.	Use of performances charts .....	2
3.	Airspeed indicator system calibration.....	3
4.	ICAO Standard Atmosphere .....	4
5.	Stall speed.....	5
6.	Crosswind.....	6
7.	Takeoff performances .....	7
8.	Take-off Rate of Climb at $V_y$ .....	10
9.	Take-off Rate of Climb at $V_x$ .....	11
10.	Enroute Rate of Climb at $V_y$ .....	12
11.	Enroute Rate of Climb at $V_x$ .....	13
12.	One-Engine Rate of Climb at $V_{ySE}$ .....	14
13.	One-Engine Rate of Climb at $V_{xSE}$ .....	15
14.	Cruise performances .....	16
15.	Landing performances .....	19
16.	Balked landing climb gradient .....	22
17.	Noise data .....	22

## 1. INTRODUCTION

This section provides all necessary data for an accurate and comprehensive planning of flight activity from takeoff to landing.

Data reported in graphs and/or in tables were determined using:

- “Flight Test Data” under conditions prescribed by EASA CS-23 regulation
- aircraft and engine in good condition
- average piloting techniques

Each graph or table was determined according to ICAO Standard Atmosphere (ISA - s.l.); evaluations of the impact on performances were carried out by theoretical means for:

- airspeed
- external temperature
- altitude
- weight
- runway type and condition

## 2. USE OF PERFORMANCES CHARTS

Performances data are presented in tabular or graphical form to illustrate the effect of different variables such as altitude, temperature and weight. Given information is sufficient to plan the mission with required precision and safety.

Additional information is provided for each table or graph.

### 3. AIRSPEED INDICATOR SYSTEM CALIBRATION

Graph shows calibrated airspeed  $V_{CAS}$  as a function of indicated airspeed  $V_{IAS}$ .




Figure 1 - IAS/CAS chart

*Example:*


**Given**

KIAS 75

**Find**

KCAS 74

## 4. ICAO STANDARD ATMOSPHERE



a. Temperature = 20°C

b. Pressure altitude = 1600'

c. Corresponding Density Altitude = 2250'

Given

A. Pressure altitude = 1600'

ISA condition

Find

B. ISA Air Temperature = 12°C



## 5. STALL SPEED

**Weight:** 1230 kg (2712 lb)**Throttle Levers:** IDLE**Landing Gear:** Down**CG:** Most Forward (16.5%)**No ground effect**

WEIGHT [kg]	BANK ANGLE [deg]	STALL SPEED					
		FLAPS 0°		FLAPS T/O		FLAPS FULL	
		KIAS	KCAS	KIAS	KCAS	KIAS	KCAS
<b>1230</b> (FWD C.G.)	<b>0</b>	66	65	59	57	54	55
	<b>15</b>	67	66	58	58	55	56
	<b>30</b>	71	70	61	61	59	59
	<b>45</b>	79	78	68	68	65	65
	<b>60</b>	95	93	83	81	79	78

**NOTE**

Altitude loss during conventional stall recovery, as demonstrated during flight tests is approximately 250 ft with banking below 30°.

## 6. CROSSWIND

Maximum demonstrated crosswind is 17 Kts

⇒ Example:

### Given

Wind direction (with respect to aircraft longitudinal axis) =  $30^\circ$

Wind speed = 20 Kts

### Find

Headwind = 17.5 Kts

Crosswind = 10 Kts




Figure 3 – Crosswind diagram

## 7. TAKEOFF PERFORMANCES

<b>Weight = 1230 kg (2712 lb)</b>						
		<b>Corrections</b>				
<b>Flaps: T/O</b>		<b>Headwind: - 2.5m for each kt (8 ft/kt)</b>				
<b>Speed at Lift-Off = 65 KIAS</b>		<b>Tailwind: + 10m for each kt (33ft/kt)</b>				
<b>Speed Over 50ft Obstacle = 70 KIAS</b>		<b>Paved Runway: - 6% to Ground Roll</b>				
<b>Throttle Levers: Full Forward</b>		<b>Runway slope: + 5% to Ground Roll for each</b>				
<b>Runway: Grass</b>		<b>+1%</b>				
Pressure Altitude [ft]		Distance [m]				
		Temperature [°C]				ISA
		-25	0	25	50	
S.L.	Ground Roll	207	263	328	401	301
	At 50 ft AGL	271	345	429	525	394
1000	Ground Roll	231	294	366	447	330
	At 50 ft AGL	303	385	479	586	432
2000	Ground Roll	258	328	409	500	362
	At 50 ft AGL	338	430	535	654	474
3000	Ground Roll	289	367	457	559	398
	At 50 ft AGL	378	480	598	731	521
4000	Ground Roll	323	411	511	625	438
	At 50 ft AGL	423	537	669	818	573
5000	Ground Roll	362	460	572	700	481
	At 50 ft AGL	473	602	749	916	630
6000	Ground Roll	405	515	642	785	530
	At 50 ft AGL	531	675	840	1027	694
7000	Ground Roll	455	578	720	880	584
	At 50 ft AGL	595	757	942	1152	765
8000	Ground Roll	511	650	809	989	645
	At 50 ft AGL	669	850	1059	1295	844
9000	Ground Roll	575	730	909	1112	712
	At 50 ft AGL	752	956	1190	1456	932
10000	Ground Roll	647	822	1023	1252	786
	At 50 ft AGL	847	1076	1340	1638	1029

**Weight = 1080 kg (2381 lb)****Flaps: T/O****Speed at Lift-Off = 65 KIAS****Speed Over 50ft Obstacle = 70 KIAS****Throttle Levers: Full Forward****Runway: Grass****Corrections****Headwind: - 2.5m for each kt (8 ft/kt)****Tailwind: + 10m for each kt (33ft/kt)****Paved Runway: - 6% to Ground Roll****Runway slope: + 5% to Ground Roll for each +1%**

Pressure Altitude [ft]		Distance [m]				
		Temperature [°C]				ISA
		-25	0	25	50	
<b>S.L.</b>	<b>Ground Roll</b>	148	188	234	286	<b>215</b>
	<b>At 50 ft AGL</b>	193	246	306	374	<b>281</b>
<b>1000</b>	<b>Ground Roll</b>	165	210	261	319	<b>235</b>
	<b>At 50 ft AGL</b>	216	274	341	418	<b>308</b>
<b>2000</b>	<b>Ground Roll</b>	184	234	291	356	<b>258</b>
	<b>At 50 ft AGL</b>	241	306	381	466	<b>338</b>
<b>3000</b>	<b>Ground Roll</b>	206	262	326	398	<b>284</b>
	<b>At 50 ft AGL</b>	269	342	426	521	<b>372</b>
<b>4000</b>	<b>Ground Roll</b>	230	293	364	446	<b>312</b>
	<b>At 50 ft AGL</b>	301	383	477	583	<b>409</b>
<b>5000</b>	<b>Ground Roll</b>	258	328	408	499	<b>343</b>
	<b>At 50 ft AGL</b>	338	429	534	653	<b>449</b>
<b>6000</b>	<b>Ground Roll</b>	289	368	457	559	<b>378</b>
	<b>At 50 ft AGL</b>	378	481	599	732	<b>495</b>
<b>7000</b>	<b>Ground Roll</b>	324	412	513	628	<b>417</b>
	<b>At 50 ft AGL</b>	425	540	672	822	<b>545</b>
<b>8000</b>	<b>Ground Roll</b>	364	463	577	705	<b>460</b>
	<b>At 50 ft AGL</b>	477	606	755	923	<b>602</b>
<b>9000</b>	<b>Ground Roll</b>	410	521	648	793	<b>508</b>
	<b>At 50 ft AGL</b>	536	682	849	1038	<b>664</b>
<b>10000</b>	<b>Ground Roll</b>	461	586	730	893	<b>561</b>
	<b>At 50 ft AGL</b>	604	767	955	1168	<b>734</b>

**Weight = 930 kg (2051 lb)****Corrections****Flaps:** *T/O***Speed at Lift-Off = 65 KIAS****Speed Over 50ft Obstacle = 70 KIAS****Throttle Levers:** *Full Forward***Runway:** *Grass***Headwind:** - 2.5m for each kt (8 ft/kt)**Tailwind:** + 10m for each kt (33ft/kt)**Paved Runway:** - 6% to Ground Roll**Runway slope:** + 5% to Ground Roll for each +1%

Pressure Altitude [ft]		Distance [m]				
		Temperature [°C]				ISA
		-25	0	25	50	
<b>S.L.</b>	<b>Ground Roll</b>	100	127	158	194	<b>146</b>
	<b>At 50 ft AGL</b>	131	167	207	254	<b>190</b>
<b>1000</b>	<b>Ground Roll</b>	112	142	177	216	<b>160</b>
	<b>At 50 ft AGL</b>	146	186	231	283	<b>209</b>
<b>2000</b>	<b>Ground Roll</b>	125	159	197	242	<b>175</b>
	<b>At 50 ft AGL</b>	163	208	258	316	<b>229</b>
<b>3000</b>	<b>Ground Roll</b>	140	177	221	270	<b>192</b>
	<b>At 50 ft AGL</b>	183	232	289	353	<b>252</b>
<b>4000</b>	<b>Ground Roll</b>	156	198	247	302	<b>212</b>
	<b>At 50 ft AGL</b>	204	260	323	395	<b>277</b>
<b>5000</b>	<b>Ground Roll</b>	175	222	277	338	<b>233</b>
	<b>At 50 ft AGL</b>	229	291	362	443	<b>305</b>
<b>6000</b>	<b>Ground Roll</b>	196	249	310	379	<b>256</b>
	<b>At 50 ft AGL</b>	257	326	406	496	<b>335</b>
<b>7000</b>	<b>Ground Roll</b>	220	280	348	426	<b>282</b>
	<b>At 50 ft AGL</b>	288	366	455	557	<b>370</b>
<b>8000</b>	<b>Ground Roll</b>	247	314	391	478	<b>312</b>
	<b>At 50 ft AGL</b>	323	411	512	626	<b>408</b>
<b>9000</b>	<b>Ground Roll</b>	278	353	440	538	<b>344</b>
	<b>At 50 ft AGL</b>	364	462	575	704	<b>450</b>
<b>10000</b>	<b>Ground Roll</b>	313	397	495	605	<b>380</b>
	<b>At 50 ft AGL</b>	409	520	648	792	<b>498</b>

8. TAKE-OFF RATE OF CLIMB AT  $V_Y$ 

Power Setting: Maximum Continuous Power							
Flaps: Take-Off							
Landing Gear: Up							
Weight	Pressure Altitude	Climb Speed V <sub>y</sub>	Rate of Climb [ft/min]				ISA
			Temperature [°C]				
[kg]	[ft]	[KIAS]	-25	0	25	50	
1230	S.L.	86	1276	1088	920	768	985
	2000	83	1133	948	783	634	873
	4000	79	990	809	646	500	761
	6000	76	848	670	510	366	649
	8000	73	707	531	374	233	537
	10000	70	565	393	239	100	425
	12000	67	425	256	104	-32	313
	14000	64	285	118	-30	-164	201
1080	S.L.	85	1507	1302	1119	954	1190
	2000	82	1351	1150	970	808	1068
	4000	79	1196	998	822	662	946
	6000	76	1041	847	674	517	825
	8000	73	887	696	526	372	703
	10000	69	734	546	379	228	581
	12000	66	581	397	232	84	459
	14000	63	428	248	86	-59	338
930	S.L.	85	1803	1575	1372	1189	1451
	2000	82	1630	1406	1206	1026	1315
	4000	79	1457	1238	1041	864	1180
	6000	75	1286	1070	877	703	1045
	8000	72	1114	902	713	542	909
	10000	69	944	735	549	382	774
	12000	65	774	569	387	222	639
	14000	62	604	404	224	63	503

9. TAKE-OFF RATE OF CLIMB AT  $V_x$ 

<b>Power Setting:</b> Maximum Continuous Power <b>Flaps:</b> Take-Off <b>Landing Gear:</b> Up							
Weight	Pressure Altitude	Climb Speed $V_x$	Rate of Climb at $V_x$ [ft/min]				
			Temperature [°C]				ISA
[kg]	[ft]	[KIAS]	-25	0	25	50	
1230	S.L.	78	1214	1037	880	738	941
	1000	76	1147	972	816	675	888
	2000	75	1080	906	751	612	836
	3000	74	1013	841	687	549	783
	4000	73	946	776	623	486	731
	5000	72	879	710	560	424	678
	6000	71	813	645	496	361	626
	7000	70	746	580	432	299	574
1080	S.L.	78	1283	1102	940	794	1002
	1000	76	1214	1034	874	729	949
	2000	75	1145	967	808	664	895
	3000	74	1076	900	742	600	841
	4000	73	1008	833	676	535	787
	5000	72	939	766	611	471	733
	6000	71	871	699	545	407	679
	7000	70	803	632	480	342	625
930	S.L.	78	1435	1243	1072	918	1138
	1000	76	1362	1172	1002	849	1081
	2000	75	1289	1101	932	780	1024
	3000	74	1216	1030	863	712	967
	4000	73	1144	958	793	644	910
	5000	72	1071	888	724	576	853
	6000	71	999	817	654	508	796
	7000	69	927	746	585	440	739



**10. ENROUTE RATE OF CLIMB AT  $V_Y$** 

Power Setting: Maximum Continuous Power							
Flaps: Up							
Landing Gear: Up							
Weight	Pressure Altitude	Climb Speed V <sub>y</sub>	Rate of Climb [ft/min]				ISA
			Temperature [°C]				
[kg]	[ft]	[KIAS]	-25	0	25	50	
1230	S.L.	84	1317	1135	973	827	1036
	2000	83	1179	1000	841	697	928
	4000	81	1041	865	709	568	819
	6000	80	904	731	577	439	711
	8000	78	767	598	446	310	603
	10000	77	631	464	316	182	495
	12000	75	495	332	186	54	387
	14000	73	360	199	56	-73	279
1080	S.L.	83	1560	1360	1182	1022	1251
	2000	82	1408	1212	1037	879	1132
	4000	80	1257	1064	892	737	1014
	6000	78	1106	917	748	595	895
	8000	76	956	770	604	454	776
	10000	74	807	624	461	314	658
	12000	72	657	478	318	173	539
	14000	70	509	333	175	34	420
930	S.L.	82	1873	1649	1449	1269	1527
	2000	81	1703	1483	1286	1109	1393
	4000	79	1533	1317	1124	950	1260
	6000	77	1364	1151	962	791	1127
	8000	75	1196	987	800	632	994
	10000	73	1028	823	639	474	861
	12000	71	860	659	479	317	727
	14000	69	693	496	319	160	594



11. ENROUTE RATE OF CLIMB AT  $V_x$ 

Power Setting: Maximum Continuous Power							
Flaps: Up							
Landing Gear: Up							
Weight [kg]	Pressure Altitude [ft]	Climb Speed $V_x$ [KIAS]	Rate of Climb at $V_x$ [ft/min]				
			Temperature [°C]				ISA
			-25	0	25	50	
1230	S.L.	72	1241	1073	924	789	982
	1000	72	1177	1011	863	729	932
	2000	72	1114	949	802	669	882
	3000	72	1050	887	741	609	832
	4000	72	986	825	680	550	782
	5000	72	923	763	619	490	732
	6000	71	860	701	559	431	682
	7000	71	797	639	498	371	632
1080	S.L.	72	1480	1295	1130	981	1194
	1000	72	1410	1226	1062	915	1139
	2000	72	1340	1158	995	848	1084
	3000	72	1269	1089	928	782	1029
	4000	71	1199	1020	861	717	973
	5000	71	1129	952	794	651	918
	6000	71	1059	884	727	585	863
	7000	71	990	815	660	520	808
930	S.L.	72	1787	1578	1391	1223	1463
	1000	72	1707	1500	1315	1148	1401
	2000	71	1628	1422	1239	1074	1339
	3000	71	1549	1345	1163	999	1277
	4000	71	1470	1268	1087	925	1215
	5000	71	1391	1190	1012	851	1153
	6000	71	1312	1113	936	777	1090
	7000	70	1233	1036	861	703	1028

12. ONE-ENGINE RATE OF CLIMB AT  $V_{YSE}$ 

Power Setting: Maximum Continuous Power (operative engine) propeller feathered (inoperative engine)							
Flaps: Up							
Landing Gear: Up							
Weight	Pressure Altitude	Climb Speed V <sub>YSE</sub>	Rate of Climb [ft/min]				
			Temperature [°C]				ISA
[kg]	[ft]	[KIAS]	-25	0	25	50	
1230	S.L.	84	330	230	142	62	176
	1000	83	292	193	106	26	147
	2000	82	254	157	69	-9	117
	3000	81	216	120	33	-44	87
	4000	80	179	83	-3	-80	58
	5000	79	141	46	-38	-115	28
	6000	79	104	10	-74	-150	-1
	7000	78	67	-27	-110	-185	-31
1080	S.L.	80	436	330	235	149	271
	1000	80	396	290	196	111	240
	2000	79	355	251	157	73	208
	3000	79	315	211	118	35	176
	4000	79	275	172	80	-3	145
	5000	79	234	132	41	-41	113
	6000	78	194	93	3	-78	81
	7000	78	154	54	-35	-116	50
930	S.L.	79	574	455	349	253	390
	1000	79	529	411	305	211	355
	2000	79	483	367	262	168	319
	3000	78	438	322	219	126	284
	4000	78	393	278	176	83	248
	5000	78	348	235	133	41	213
	6000	78	304	191	90	-1	178
	7000	77	259	147	47	-43	142

13. ONE-ENGINE RATE OF CLIMB AT  $V_{XSE}$ 

<b>Power Setting:</b> Maximum Continuous Power (operative engine) propeller feathered (inoperative engine) <b>Flaps:</b> Up <b>Landing Gear:</b> Up							
Weight [kg]	Pressure Altitude [ft]	Climb Speed $V_{XSE}$ [KIAS]	Rate of Climb at $V_{XSE}$ [ft/min]				
			Temperature [°C]				ISA
			-25	0	25	50	
1230	S.L.	83	325	227	140	61	174
	1000	82	288	191	104	26	145
	2000	81	251	155	69	-9	116
	3000	81	214	118	33	-44	86
	4000	80	177	82	-2	-78	57
	5000	79	140	46	-38	-113	28
	6000	78	103	10	-73	-148	-1
	7000	77	66	-26	-108	-183	-30
1080	S.L.	79	424	321	229	147	265
	1000	79	385	283	192	110	234
	2000	79	346	245	155	73	204
	3000	79	307	207	117	37	173
	4000	79	268	169	80	0	143
	5000	78	229	131	43	-36	112
	6000	78	190	93	6	-73	81
	7000	78	152	55	-31	-109	51
930	S.L.	78	556	442	341	249	380
	1000	78	513	400	299	209	346
	2000	78	469	358	258	168	312
	3000	78	426	316	217	128	279
	4000	78	383	274	176	87	245
	5000	78	340	232	134	47	211
	6000	77	298	190	93	7	177
	7000	77	255	148	52	-34	143

## 14. CRUISE PERFORMANCES

Weight: 1150 kg (2535 lb)										
Pressure Altitude: 0 ft										
RPM*	MAP [inHg]	ISA – 30°C (-15°C)			ISA (15°C)			ISA + 30°C (45°C)		
		PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]
2250	29.5	103%	143	28.6	97%	145	27.1	92%	146	25.8
2250	28	88%	134	24.5	83%	136	23.2	79%	138	22
2250	26	69%	122	19.2	65%	124	18.2	62%	125	17.3
2250	24	59%	115	16.6	56%	116	15.7	53%	117	14.9
2250	22	46%	103	12.8	43%	103	12.1	41%	103	11.5
2250	20	39%	96	11	37%	95	10.4	35%	94	9.9
2100	28	84%	132	23.5	80%	134	22.2	76%	135	21.1
2100	26	66%	121	18.5	63%	122	17.5	60%	123	16.7
2100	24	57%	114	16	54%	114	15.1	52%	115	14.4
2100	22	43%	100	12.1	41%	100	11.5	39%	100	10.9
2100	20	37%	92	10.2	35%	91	9.7	33%	89	9.2
1900	26	61%	117	17.1	58%	118	16.2	55%	119	15.4
1900	24	53%	110	14.9	50%	111	14.1	48%	111	13.4
1900	22	41%	97	11.4	39%	97	10.8	37%	96	10.2
1900	20	35%	89	9.6	33%	88	9.1	31%	85	8.7
* Propeller RPM										
** Fuel Consumption for each Engine										

Weight: 1150 kg (2535 lb) Pressure Altitude: 3000 ft										
RPM*	MAP [inHg]	ISA – 30°C (-21°C)			ISA (9°C)			ISA + 30°C (39°C)		
		PWR	KTAS	F.C.** [lt/hr]	PWR	TCAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]
2388	26.4	92%	141	25.7	87%	143	24.3	83%	144	23.1
2250	26.4	89%	139	25	85%	141	23.6	80%	143	22.4
2250	26	85%	137	23.9	81%	138	22.6	77%	140	21.5
2250	24	72%	128	20	68%	129	18.9	64%	130	18
2250	22	57%	116	16	54%	117	15.1	51%	118	14.3
2250	20	48%	108	13.4	45%	108	12.7	43%	108	12.1
2100	26.4	85%	137	23.9	81%	138	22.6	77%	140	21.4
2100	26	82%	134	22.8	77%	136	21.6	73%	137	20.5
2100	24	69%	125	19.2	65%	127	18.1	62%	128	17.2
2100	22	54%	114	15.2	51%	114	14.3	49%	115	13.6
2100	20	45%	104	12.6	43%	104	11.9	41%	104	11.3
1900	26.4	78%	132	21.9	74%	134	20.7	70%	135	19.6
1900	26	75%	130	20.9	71%	131	19.8	67%	132	18.8
1900	24	63%	121	17.7	60%	122	16.7	57%	123	15.9
1900	22	50%	110	14.1	48%	110	13.3	45%	110	12.6
1900	20	42%	101	11.7	40%	101	11.1	38%	100	10.6
* Propeller RPM										
** Fuel Consumption for each Engine										

Weight: 1150 kg (2535 lb) Pressure Altitude: 6000 ft										
RPM*	MAP [inHg]	ISA – 30°C (-27°C)			ISA (3°C)			ISA + 30°C (33°C)		
		PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]
2388	23.6	83%	139	23.3	79%	141	22	75%	142	20.9
2250	23.6	81%	138	22.6	76%	139	21.4	73%	141	20.3
2250	22	68%	129	19.1	65%	130	18.1	61%	131	17.2
2250	20	57%	119	15.8	54%	120	14.9	51%	120	14.2
2250	18	46%	108	12.9	44%	108	12.2	41%	107	11.6
2100	23.6	77%	135	21.6	73%	137	20.4	69%	138	19.4
2100	22	65%	126	18.2	62%	127	17.2	59%	128	16.4
2100	20	54%	116	15	51%	116	14.1	48%	117	13.4
2100	18	44%	106	12.4	42%	106	11.7	40%	105	11.1
1900	23.6	71%	130	19.8	67%	132	18.7	64%	133	17.8
1900	22	60%	122	16.8	57%	123	15.8	54%	123	15
1900	20	50%	112	13.9	47%	112	13.1	44%	112	12.4
1900	18	41%	102	11.6	39%	102	10.9	37%	100	10.4
* Propeller RPM										

**\*\* Fuel Consumption for each Engine**

**Weight: 1150 kg (2535 lb)**

**Pressure Altitude: 9000 ft**

RPM*	MAP [inHg]	ISA – 30°C (-33°C)			ISA (-3°C)			ISA + 30°C (27°C)		
		PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]
<b>2388</b>	<b>21.1</b>	75%	137	20.9	71%	139	19.7	67%	140	18.7
<b>2250</b>	<b>21.1</b>	73%	136	20.3	69%	137	19.2	65%	138	18.2
<b>2250</b>	<b>20</b>	65%	130	18.3	62%	131	17.2	58%	131	16.3
<b>2250</b>	<b>18</b>	53%	118	14.9	50%	119	14	48%	118	13.3
<b>2100</b>	<b>21.1</b>	69%	133	19.4	65%	134	18.3	62%	135	17.4
<b>2100</b>	<b>20</b>	62%	127	17.4	59%	128	16.4	56%	128	15.6
<b>2100</b>	<b>18</b>	51%	116	14.2	48%	116	13.4	46%	116	12.7
<b>1900</b>	<b>21.1</b>	64%	128	17.8	60%	129	16.8	57%	130	15.9
<b>1900</b>	<b>20</b>	57%	122	16	54%	123	15.1	51%	123	14.3
<b>1900</b>	<b>18</b>	47%	112	13.2	44%	112	12.4	42%	111	11.8

\* Propeller RPM

\*\* Fuel Consumption for each Engine

**Weight: 1150 kg (2535 lb)**

**Pressure Altitude: 12000 ft**

RPM*	MAP [inHg]	ISA – 30°C (-39°C)			ISA (-9°C)			ISA + 30°C (21°C)		
		PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]	PWR	KTAS	F.C.** [lt/hr]
<b>2388</b>	<b>18.8</b>	67%	135	18.8	63%	136	17.7	60%	136	16.7
<b>2250</b>	<b>18.8</b>	65%	133	18.2	61%	134	17.2	58%	134	16.3
<b>2250</b>	<b>18</b>	60%	129	16.8	57%	129	15.9	54%	129	15
<b>2100</b>	<b>18.8</b>	62%	130	17.4	59%	131	16.4	56%	132	15.5
<b>2100</b>	<b>18</b>	58%	126	16.1	54%	126	15.2	51%	126	14.4
<b>1900</b>	<b>18.8</b>	57%	125	15.9	54%	126	15	51%	126	14.2
<b>1900</b>	<b>18</b>	53%	121	14.8	50%	121	13.9	47%	121	13.2

\* Propeller RPM

\*\* Fuel Consumption for each Engine

## 15. LANDING PERFORMANCES

<b>Weight = 1230 kg (2712 lb)</b>		<b>Corrections</b>				
<b>Flaps: LAND</b>		<b>Headwind: - 5m for each kt (16 ft/kt)</b>				
<b>Short Final Approach Speed = 70 KIAS</b>		<b>Tailwind: + 11m for each kt (36ft/kt)</b>				
<b>Throttle Levers: Idle</b>		<b>Paved Runway: - 2% to Ground Roll</b>				
<b>Runway: Grass</b>		<b>Runway slope: - 2.5% to Ground Roll for each +1%</b>				
Pressure Altitude [ft]		Distance [m]				
		Temperature [°C]				ISA
		-25	0	25	50	
S.L.	Ground Roll	199	219	239	259	231
	At 50 ft AGL	308	334	359	384	349
1000	Ground Roll	206	227	248	269	238
	At 50 ft AGL	318	344	370	396	358
2000	Ground Roll	214	236	257	279	245
	At 50 ft AGL	328	355	382	408	367
3000	Ground Roll	222	244	267	289	252
	At 50 ft AGL	348	377	406	434	385
4000	Ground Roll	230	254	277	300	260
	At 50 ft AGL	348	377	406	434	385
5000	Ground Roll	239	263	287	311	268
	At 50 ft AGL	359	389	419	448	395
6000	Ground Roll	248	273	298	323	276
	At 50 ft AGL	371	402	432	463	405
7000	Ground Roll	258	284	310	336	285
	At 50 ft AGL	382	415	446	478	416
8000	Ground Roll	268	295	322	349	294
	At 50 ft AGL	395	428	461	494	427
9000	Ground Roll	278	306	334	362	303
	At 50 ft AGL	408	442	476	510	438
10000	Ground Roll	289	318	348	377	313
	At 50 ft AGL	421	457	492	527	450

**Weight = 1080 kg (2381 lb)****Flaps: LAND****Short Final Approach Speed = 70 KIAS****Throttle Levers: Idle****Runway: Grass****Corrections****Headwind: - 5m for each kt (16 ft/kt)****Tailwind: + 11m for each kt (36ft/kt)****Paved Runway: - 2% to Ground Roll****Runway slope: - 2.5% to Ground Roll for each +1%**

Pressure Altitude [ft]		Distance [m]				
		Temperature [°C]				ISA
		-25	0	25	50	
S.L.	Ground Roll	175	192	210	227	203
	At 50 ft AGL	271	293	315	337	306
1000	Ground Roll	181	199	218	236	209
	At 50 ft AGL	279	302	325	348	314
2000	Ground Roll	188	207	226	245	215
	At 50 ft AGL	288	311	335	358	322
3000	Ground Roll	195	215	234	254	222
	At 50 ft AGL	306	331	356	381	338
4000	Ground Roll	202	223	243	263	228
	At 50 ft AGL	306	331	356	381	338
5000	Ground Roll	210	231	252	273	235
	At 50 ft AGL	315	342	368	394	347
6000	Ground Roll	218	240	262	284	243
	At 50 ft AGL	325	353	380	406	356
7000	Ground Roll	226	249	272	295	250
	At 50 ft AGL	336	364	392	420	365
8000	Ground Roll	235	259	283	306	258
	At 50 ft AGL	347	376	405	434	375
9000	Ground Roll	244	269	294	318	266
	At 50 ft AGL	358	388	418	448	385
10000	Ground Roll	254	280	305	331	275
	At 50 ft AGL	370	401	432	463	395



**Weight = 930 kg (2051 lb)****Flaps: LAND****Short Final Approach Speed = 70 KIAS****Throttle Levers: Idle****Runway: Grass****Corrections****Headwind: - 5m for each kt (16 ft/kt)****Tailwind: + 11m for each kt (36ft/kt)****Paved Runway: - 2% to Ground Roll****Runway slope: - 2.5% to Ground Roll for each +1%**

Pressure Altitude [ft]		Distance [m]				
		Temperature [°C]				ISA
		-25	0	25	50	
S.L.	Ground Roll	150	166	181	196	175
	At 50 ft AGL	233	252	271	290	264
1000	Ground Roll	156	172	187	203	180
	At 50 ft AGL	240	260	280	299	270
2000	Ground Roll	162	178	194	211	185
	At 50 ft AGL	248	268	288	309	277
3000	Ground Roll	168	185	202	219	191
	At 50 ft AGL	263	285	307	328	291
4000	Ground Roll	174	192	209	227	197
	At 50 ft AGL	263	285	307	328	291
5000	Ground Roll	181	199	217	235	203
	At 50 ft AGL	272	294	317	339	299
6000	Ground Roll	188	207	226	244	209
	At 50 ft AGL	280	304	327	350	307
7000	Ground Roll	195	215	234	254	215
	At 50 ft AGL	289	313	338	361	315
8000	Ground Roll	203	223	243	264	222
	At 50 ft AGL	299	324	349	373	323
9000	Ground Roll	210	232	253	274	229
	At 50 ft AGL	308	334	360	386	331
10000	Ground Roll	219	241	263	285	237
	At 50 ft AGL	319	346	372	399	340

**16. BALKED LANDING CLIMB GRADIENT**

Flight conditions (ISA and SL):

<b>Weight:</b>	<i>1230 kg (2712 lb)</i>
<b>Throttle levers</b>	<i>Both FULL FORWARD</i>
<b>Flaps</b>	<i>T/O</i>
<b>Landing gear</b>	<i>DOWN</i>
<b>Weight</b>	<i>MTOW 1230kg (2712 lb)</i>
<b>Speed</b>	<i>72 KIAS</i>
<b>Climb gradient</b>	<i>9.4% (5.4°)</i>

**17. NOISE DATA**

Noise level, determined in accordance with ICAO/Annex 16 4th Ed., July 2005, Vol. I°, Chapter 10, is **72.82** dB(A).

**Supplement G19: page replacement instructions**

## SECTION 6 - WEIGHT AND BALANCE

**See Basic AFM – Section 6**

INTENTIONALLY LEFT BLANK

**Supplement G19: page replacement instructions**

## SECTION 7 - AIRFRAME and SYSTEMS DESCRIPTION

Apply following page replacement procedure:

<b>Supplement G19 – AIRFRAME and SYSTEMS DESCRIPTION page</b>		<b>Basic AFM Section 7 page</b>
S7-1 thru S7-2	<b>REPLACE</b>	7-1 thru 7-2
S7-29 thru S7-42	<b>REPLACE</b>	7-29 thru 42

INTENTIONALLY LEFT BLANK

**SECTION 7 – AIRFRAME and SYSTEMS DESCRIPTION****INDEX**

1. INTRODUCTION .....	3
2. AIRFRAME.....	3
3. POWERPLANT .....	9
4. PEDESTAL CONTROLS.....	12
5. CABIN OVER-HEAD PANEL CONTROLS.....	15
6. INTERNAL LIGHTS.....	16
7. EXTERNAL LIGHTS .....	17
8. FUEL SYSTEM.....	19
9. LANDING GEAR SYSTEM .....	21
10. BRAKES.....	25
11. VENTILATION .....	26
12. CABIN HEAT.....	26
13. SEATS AND SAFETY BELTS .....	26
14. DOORS.....	27
15. BAGGAGE COMPARTMENT.....	28
16. MD302 ALTERNATIVE STANDBY INSTRUMENT.....	29
17. PLACARDS.....	31
18. INSTRUMENTS PANEL.....	37
19. ELECTRICAL SYSTEM.....	39

INTENTIONALLY LEFT BLANK



## 16. MD302 ALTERNATIVE STAND-BY INSTRUMENT

In order to improve the digital version cockpit layout of the P2006T in terms of human-machine interface, weight saving and reliability this backup instrument V.1.0.5 is installed.

For more details refer to MOD2006/212.



*All MD302 Stand-by Attitude Module settings, set up during the aircraft delivery or after a maintenance activity, must not be modified.*



*In case of replacement of MD302 Stand-by Attitude Module, verify proper software load and confirm that its software version number is compliance with that one showed above, before install it.*





INTENTIONALLY LEFT BLANK






## 17. PLACARDS







In addition to the limitation placards reported on Section 2, following placards are installed on the aircraft.




**NOTE**

*Additionally, nearby the placards listed below (English language), directly-translated placards in the language of the country in which the airplane is registered can be installed, when required by the specific NAA.*

Description	Placard	Place
ELT equipment location		Baggage compartment, right side
First Aid Kit location		Baggage compartment, aft cover panel
Fire extinguisher location		Cockpit floor, pilot side
Emergency gear extension compartment location		Removable cap

Description	Placard	Place
Emergency gear extension instructions		Emergency distributors compartment
Alternate static port location		Central pedestal, left side
Alternate static port operating instructions		Central pedestal, right side
Static ports location	STATIC PORT KEEP CLEAN	Static ports: fuselage - both sides
Battery compartment location		Fuselage tail, left side
EXT power connection: socket schematic and instructions		Fuselage tail, left side

Description	Placard	Place
Landing gear hydraulic accumulator: low pressure limit		LG hydraulic compartment cap (fuselage tail, left side)
LG hydraulic compartment location		Fuselage tail, left side, in correspondence of LG hydraulic compartment cap
Towing limitations		Nose LG forward door
Stabilator excursion range		Fuselage tail, left side, in correspondence of the stabilator leading edge
Aircraft grounding		Close to the fuel filler cap
Engine coolant expansion tank location		Engine nacelle top side

Description	Placard	Place
Steel boards: a/c identification marks	 <p>(Sample)</p>	Fuselage tail, left side
Main LG tires inflation pressure values		MLG leg, LH and RH
Nose LG tire inflation pressure values		Nose LG fork

INTENTIONALLY LEFT BLANK

INTENTIONALLY LEFT BLANK



## 18. INSTRUMENTS PANEL



GARMIN G1000 NXi - Instruments panel (typical layout)

Item	Description
1	GDU 1050 (PFD)
2	Audio Panel
3	A/P Programmer/Computer
4	GDU 1050 (MFD)
5	Main bus breaker panel
6	Ess bus breaker panel (RH)
7	Ess bus breaker panel (LH)
8	Avionic bus breaker panel (LH & RH)
9	Battery and Alternators (LH & RH) breakers
10	Cabin ventilation (RH)
11	Instrument light switch
12	Strobe light switch

Item	Description
13	Navigation light switch
14	Taxi light switch
15	Landing light switch
16	Cabin/Instruments/Panel lights dimmers
17	Flaps switch
18	MD-302 Standby Attitude Module
19	Cross bus 2 switch
20	RH battery switch
21	Cross bus 1 switch
22	Master switch
23	Avionics master switch 2
24	Avionics master switch 1
25	LH Battery Switch
26	Landing gear lever
27	Windshield defrost
28	Cabin heat
29	Cabin ventilation
30	Emergency Locator Transmitter switch
31	A/P master switch
32	Pitot heating switch
33	Rudder trim disconnect switch
34	Pitch trim disconnect switch
35	Electric fan switch
36	Fire detection system test switch

## 19. ELECTRICAL SYSTEM

Primary DC power is provided by two engine-driven generators which, during normal operations, operate in parallel.

Each generator is rated of 40 Amps and 14 VDC, as the two voltage regulators. An automatic overvoltage device protects the circuits and the electric components from an excessive voltage caused by generator failures.

The power rating of each generator is such that if one generator fails the other one can still supply the airplane equipment to maintain flight safety.

Secondary DC power is provided by a main battery (lead type - 12 V, 23-Ah) and a secondary battery (lead type - 12V, 13 Ah).

An external DC power source can be connected to the aircraft distribution system in order to have it fed without starting the engine.

The ammeter section of the G1000 EIS can indicate the current supplied by either left or right generator switching a dedicated selector.

There are five different buses:

- Battery bus,
- LH Generator bus,
- RH Generator bus,
- LH Avionics bus,
- RH Avionics bus.

The distribution system operates as a single bus with power being supplied by the battery and both generators but it is possible to separate the left busses from the right busses when required by means of the Cross Bus switches.

The switches to enable and disable the alternators and battery are grouped in the master switches group and are located in the centre side of the instrument panel. Only the emergency switch, that allow to put in parallel both batteries is located in left side of the instrument panel.

All electrical loads are divided among the five busses on the basis of their importance and required power: equipment with duplicate functions is connected to separate busses.

The Battery bus, which supplies the most important loads, is energized from three sources: the battery and both generators. This allows the bus for remaining active also in case of two independent faults in the supply paths.

The following loads are connected to the battery bus:

Breaker ID
Start LH
Start RH
Instr. Light
Fuel Pump LH
Fuel Pump RH
Strobe Light
E.I.S. 1
E.I.S. 2
COM 1
GPS/NAV 1
P.F.D.
A.D.I.
Turn Coordinator
Audio Panel
Cabin Fan
Actuator Flap
Door
Cabin Light
Fire
Cross LH
Cross RH
Instrument
Backup Battery
Landing Gear
Relay Landing Gear
Light Landing Gear
Fan

- In addition, Emergency Light is connected directly on the battery.

LH Cross Bus	RH Cross Bus	Avionic Bus LH	Avionic Bus RH
Field LH	Field RH	Trim A/P	COM 2
Taxi Light	Rudder Trim	A/P	M.F.D.
Pitot Heat	Stall Warning	XPDR	A.D.F.
Regulator LH	Nav Light	D.M.E.	GPS/NAV 2
	Landing Light		A.D.C.
	Regulator RH		Converter 12/24
			AHRS

On the central pedestal (see Figure below) there are seven switches disposed on two rows: on the first row there is the MASTER SWITCH which allows for connecting, through the battery relay, the battery to the battery bus.

LH and RH FIELD switches control the pertinent generator: setting the switch to OFF puts the pertinent generator off-line.

In correspondence of the second row there are 4 switches LH/RH AVIONIC and LH/ RH CROSS BUS.



Central pedestal switches console

The first two switches allow, through a relay, to cut off the power supply to the pertinent avionic bus.

The second ones allow, through a relay, for realizing the parallel connection between the pertinent generator bus and the battery bus. Setting these ones to OFF, the pertinent generator bus (and related avionic bus supplied) is separated from the battery bus and from opposite generator bus.

When both generators are correctly operating and all above mentioned switches are in ON position, all the busses are connected to the generators.

The ignition switches, two for each engine and grouped on the over head panel, are instead independent from the airplane electrical system (generation and distribution); they only control and open the engine electrical circuit.



*If ignition switches are turned ON, a propeller movement can cause the engine starting with consequent hazard for people nearby.*

**Supplement G19: page replacement instructions**

## SECTION 8 – AIRCRAFT CARE AND MAINTENANCE

**See Basic AFM – Section 8**

INTENTIONALLY LEFT BLANK



**SUPPLEMENT NO. G20 - GARMIN GTX345R TRANSPONDER****Record of Revisions**

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval or Under DOA Privileges
			DO	OoA	HDO	
0	-	First issue	A. Sabino	M. Oliva	L. Pascale	Approved under DOA No. EASA.21J.335 privileges.

**List of Effective Pages**

Page	Revision	Page	Revision
<b>G20-1</b>	Rev 0	<b>G20-3</b>	Rev 0
<b>G20-2</b>	Rev 0	<b>G20-4</b>	Rev 0

## INTRODUCTION

This section contains supplemental information to operate the aircraft in a safe and efficient manner when equipped with Garmin GTX345R device.

## GENERAL

Garmin GTX345R is a transponder operating with A, C and S mode. Its user interface is part of GARMIN G950 NXi software

## LIMITATIONS

Garmin GTX345R manuals do not address operating limitations more severe than those usually applicable to the P2006T.

## EMERGENCY PROCEDURES

In case of emergency conditions, transponder is able to sent codified messages to the Air Traffic Control; messages are classified as follows:

Code	Condition
7500	Aircraft subjected to illegal interference
7600	Loss of radio communications
7700	Emergencies

## NORMAL OPERATIONS

### DETAILED OPERATING PROCEDURES

Normal operating procedures are described on GARMIN G950 NXi Pilot's guide (P/N 190-02286-00) rev. 00 or later versions.

**NOTE**

*GARMIN G950 NXi Pilot's guide (P/N 190-02286-00) - rev. 00 or later versions - must be carried onboard the airplane at all times.*

## **PERFORMANCES**

Garmin GTX345R employment does not affect the aircraft performances

## **WEIGHT AND BALANCE**

See Section 6 of this Manual.

## **SYSTEMS**

GTX 345R is a Mode S transponder with ADS-B extended squitter capability and also includes UAT and 1090 receivers for ADS-B IN/OUT capabilities. It is mounted on a rack, located behind the PFD.

It delivers up to 250 watts of nominal power. The PFD displays the code, reply symbol and mode of operation; in the event of PFD failure the system switches to reversionary mode and the transponder interface can be operated from MFD.

The GTX 345R is connected to both GIA63W and to XPDR antenna.



**Figure 1 – Garmin GTX 345R**

INTENTIONALLY LEFT BLANK

## **Section 9 - Supplements**

**Supplement no. G20 – GARMIN GTX345R Transponder**

## SUPPLEMENT NO. G21

## BECKER 3500 ADF FOR GARMIN NXi

## Record of Revisions

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval or Under DOA Privileges
			DO	OoA	HDO	
0	-	First issue	A. Sabino	C. Caruso	M. Oliva	Approved under DOA privileges.

## List of Effective Pages

Page	Revision
<b>G21-1</b>	Rev 0
<b>G21-2</b>	Rev 0

## GENERAL

Refer to basic AFM.

## LIMITATIONS

Refer to basic AFM.

## EMERGENCY PROCEDURES

Refer to basic AFM.

## NORMAL PROCEDURES

The user interface of Becker 3500 ADF system is part of the GARMIN NXi Suite software.

Normal operating procedures are described on GARMIN NXi Pilot's guide.

### NOTE

*GARMIN NXi Pilot's guide (P/N 190-02286-00) - rev. 00 or later versions - must be carried onboard the airplane at all times.*

## PERFORMANCE

Refer to basic AFM.

## WEIGHT AND BALANCE

Refer to basic AFM.

## AIRFRAME AND SYSTEMS DESCRIPTION

Refer to basic AFM.

## AIRCRAFT CARE AND MAINTENANCE

Refer to basic AFM.

## SUPPLEMENT NO. G22

## GARMIN GTS800 TAS FOR GARMIN NXi

## Record of Revisions

Rev	Revised page	Description of Revision	Tecnam Approval			EASA Approval or Under DOA Privileges
			DO	OoA	HDO	
0	-	First issue	A. Sabino	C. Caruso	M. Oliva	Approved under DOA privileges.

## List of Effective Pages

Page	Revision
<b>G21-1</b>	Rev 0
<b>G21-2</b>	Rev 0

## GENERAL

Refer to basic AFM.

## LIMITATIONS

Refer to basic AFM.

## EMERGENCY PROCEDURES

Refer to basic AFM.

## NORMAL PROCEDURES

The user interface of GARMIN GTS800 TAS system is part of the GARMIN Suite software.

Normal operating procedures are described on GARMIN NXi Pilot's guide .

### NOTE

*GARMIN G950 Pilot's guide (P/N 190-02286-00) - rev. 00 or later versions - must be carried onboard the airplane at all times.*

## PERFORMANCE

Refer to basic AFM.

## WEIGHT AND BALANCE

Refer to basic AFM.

## AIRFRAME AND SYSTEMS DESCRIPTION

Refer to basic AFM.

## AIRCRAFT CARE AND MAINTENANCE

Refer to basic AFM.